# FANUC Robot series

# R-30*i*B/R-30*i*B Plus CONTROLLER MAINTENANCE MANUAL

MAREBCNTR04121E REV. I

©2017 FANUC America Corporation All Rights Reserved.

This publication contains proprietary information of FANUC America Corporation furnished for customer use only. No other uses are authorized without the express written permission of FANUC America Corporation.

> FANUC America Corporation 3900 W. Hamlin Road Rochester Hills, Michigan 48309–3253

> > B-83195EN/09

#### **Copyrights and Trademarks**

This new publication contains proprietary information of FANUC America Corporation furnished for customer use only. No other uses are authorized without the express written permission of FANUC America Corporation.

The descriptions and specifications contained in this manual were in effect at the time this manual was approved for printing. FANUC America Corporation, hereinafter referred to as FANUC, reserves the right to discontinue models at any time or to change specifications or design without notice and without incurring obligations.

FANUC manuals present descriptions, specifications, drawings, schematics, bills of material, parts, connections and/or procedures for installing, disassembling, connecting, operating and programming FANUC products and/or systems. Such systems consist of robots, extended axes, robot controllers, application software, the KAREL® programming language, INSIGHT® vision equipment, and special tools.

FANUC recommends that only persons who have been trained in one or more approved FANUC Training Course(s) be permitted to install, operate, use, perform procedures on, repair, and/or maintain FANUC products and/or systems and their respective components. Approved training necessitates that the courses selected be relevant to the type of system installed and application performed at the customer site.

# A WARNING

This equipment generates, uses, and can radiate radiofrequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. As temporarily permitted by regulation, it has not been tested for compliance with the limits for Class A computing devices pursuant to Subpart J and Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference. Operation of the equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measure may be required to correct the interference. FANUC conducts courses on its systems and products on a regularly scheduled basis at the company's world headquarters in Rochester Hills, Michigan. For additional information contact

FANUC America Corporation Training Department 3900 W. Hamlin Road Rochester Hills, Michigan 48309-3253 www.fanucamerica.com

For customer assistance, including Technical Support, Service, Parts & Part Repair, and Marketing Requests, contact the Customer Resource Center, 24 hours a day, at 1-800-47-ROBOT (1-800-477-6268). International customers should call 011-1-248-377-7159.

Send your comments and suggestions about this manual to: product.documentation@fanucamerica.com

# Copyright © 2017 by FANUC America Corporation All Rights Reserved

The information illustrated or contained herein is not to be reproduced, copied, downloaded, translated into another language, published in any physical or electronic format, including internet, or transmitted in whole or in part in any way without the prior written consent of FANUC America Corporation.

# AccuStat®, ArcTool®, *i*RVision®, KAREL®, PaintTool®, PalletTool®, SOCKETS®, SpotTool®, SpotWorks®, and TorchMate® are Registered Trademarks of FANUC.

FANUC reserves all proprietary rights, including but not limited to trademark and trade name rights, in the following names:

AccuAir<sup>TM</sup>, AccuCal<sup>TM</sup>, AccuChop<sup>TM</sup>, AccuFlow<sup>TM</sup>, AccuPath<sup>TM</sup>, AccuSeal<sup>TM</sup>, ARC Mate<sup>TM</sup>, ARC Mate Sr.<sup>TM</sup>, ARC Mate System 1<sup>TM</sup>, ARC Mate System 2<sup>TM</sup>, ARC Mate System 3<sup>TM</sup>, ARC Mate System 4<sup>TM</sup>, ARC Mate System 5<sup>TM</sup>, ARCWorks Pro<sup>TM</sup>, AssistTool<sup>TM</sup>, AutoNormal<sup>TM</sup>, AutoTCP<sup>TM</sup>, BellTool<sup>TM</sup>, BODYWorks<sup>TM</sup>, Cal Mate<sup>TM</sup>, Cell Finder<sup>TM</sup>, Center Finder<sup>TM</sup>, Clean Wall<sup>TM</sup>, DualARM<sup>TM</sup>, LR Tool<sup>TM</sup>, MIG Eye<sup>TM</sup>, MotionParts<sup>TM</sup>, MultiARM<sup>TM</sup>, NoBots<sup>TM</sup>, Paint Stick<sup>TM</sup>, PaintPro<sup>TM</sup>, PaintTool 100<sup>TM</sup>, PAINTWorks<sup>TM</sup>, PAINTWorks II<sup>TM</sup>, PAINTWorks III<sup>TM</sup>, PalletMate<sup>TM</sup>, PalletMate PC<sup>TM</sup>, PalletTool PCTM, PayloadIDTM, RecipToolTM, RemovalToolTM, Robo Chop<sup>TM</sup>, Robo Spray<sup>TM</sup>, S-420i<sup>TM</sup>, S-430i<sup>TM</sup>, ShapeGen<sup>TM</sup>, SoftFloat<sup>TM</sup>, SOFT PARTS<sup>TM</sup>, SpotTool+<sup>TM</sup>, SR Mate<sup>TM</sup>, SR ShotTool<sup>TM</sup>, SureWeld<sup>TM</sup>, SYSTEM R-J2 Controller<sup>TM</sup>, SYSTEM R-J3 Controller<sup>™</sup>, SYSTEM R-J3*i*B Controller<sup>™</sup>, SYSTEM R-J3*i*C Controller<sup>™</sup>, SYSTEM R-30*i*A Controller<sup>™</sup>, SYSTEM R-30*i*A Mate Controller<sup>™</sup>, SYSTEM R-30*i*B Controller<sup>™</sup>, SYSTEM R-30*i*B Mate Controller<sup>™</sup>, SYSTEM R-30*i*B Plus Controller<sup>TM</sup>. SYSTEM R-30*i*B Mate Plus Controller<sup>TM</sup>. TCP Mate<sup>TM</sup>. TorchMate<sup>TM</sup>, TripleARM<sup>TM</sup>, TurboMove<sup>TM</sup>, visLOC<sup>TM</sup>, visPRO-3D<sup>TM</sup>, visTRACTM, WebServerTM, WebTPTM, and YagToolTM.

#### ©FANUC CORPORATION 2017

- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.

#### Patents

One or more of the following U.S. patents might be related to the FANUC products described in this manual.

#### **FANUC** America Corporation Patent List

 $\begin{array}{l} 4,630,567\ 4,639,878\ 4,707,647\ 4,708,175\ 4,708,580\ 4,942,539\ 4,984,745\\ 5,238,029\ 5,239,739\ 5,272,805\ 5,293,107\ 5,293,911\ 5,331,264\ 5,367,944\\ 5,373,221\ 5,421,218\ 5,434,489\ 5,644,898\ 5,670,202\ 5,696,687\ 5,737,218\\ 5,823,389\ 5,853,027\ 5,887,800\ 5,941,679\ 5,959,425\ 5,987,726\ 6,059,092\\ 6,064,168\ 6,070,109\ 6,086,294\ 6,122,062\ 6,147,323\ 6,204,620\ 6,243,621\\ 6,253,799\ 6,285,920\ 6,313,595\ 6,325,302\ 6,345,818\ 6,356,807\ 6,360,143\\ 6,378,190\ 6,385,508\ 6,425,177\ 6,477,913\ 6,490,369\ 6,518,980\ 6,540,104\\ 6,541,757\ 6,560,513\ 6,569,258\ 6,612,449\ 6,703,079\ 6,705,361\ 6,726,773\\ 6,768,078\ 6,845,295\ 6,945,483\ 7,149,606\ 7,149,606\ 7,211,978\ 7,266,422\\ 7,399,363\end{array}$ 

#### **FANUC CORPORATION Patent List**

4,571,694 4,626,756 4,700,118 4,706,001 4,728,872 4,732,526 4,742,207 4,835,362 4,894,596 4,899,095 4,920,248 4,931,617 4,934,504 4,956,594 4,967,125 4,969,109 4,970,370 4,970,448 4,979,127 5,004,968 5,006,035 5,008,834 5,063,281 5,066,847 5,066,902 5,093,552 5,107,716 5,111,019 5,130,515 5,136,223 5,151,608 5,170,109 5,189,351 5,267,483 5,274,360 5,292,066 5,300,868 5,304,906 5,313,563 5,319,443 5,325,467 5,327,057 5,329,469 5,333,242 5,337,148 5,371,452 5,375,480 5,418,441 5,432,316 5,440,213 5,442,155 5,444,612 5,449,875 5,451,850 5,461,478 5,463,297 5,467,003 5,471,312 5,479,078 5,485,389 5,485,552 5,486,679 5,489,758 5,493,192 5,504,766 5,511,007 5,520,062 5,528,013 5,532,924 5,548,194 5,552,687 5,558,196 5,561,742 5,570,187 5,570,190 5,572,103 5,581,167 5,582,750 5,587,635 5,600,759 5,608,299 5,608,618 5,624,588 5,630,955 5,637,969 5,639,204 5,641,415 5,650,078 5,658,121 5,668,628 5,687,295 5,691,615 5,698,121 5,708,342 5,715,375 5,719,479 5,727,132 5,742,138 5,742,144 5,748,854 5,749,058 5,760,560 5,773,950 5,783,922 5,799,135 5,812,408 5,841,257 5,845,053 5,872,894 5,887,122 5,911,892 5,912,540 5,920,678 5,937,143 5,980,082 5,983,744 5,987,591 5,988,850 6,023,044 6,032,086 6,040,554 6,059,169 6,088,628 6,097,169 6,114,824 6,124,693 6,140,788 6,141,863 6,157,155 6,160,324 6,163,124 6,177,650 6,180,898 6,181,096 6,188,194 6,208,105 6,212,444 6,219,583 6,226,181 6,236,011 6,236,896 6,250,174 6,278,902 6,279,413 6,285,921 6,298,283 6,321,139 6,324,443 6,328,523 6,330,493 6,340,875 6,356,671 6,377,869 6,382,012 6,384,371 6,396,030 6,414,711 6,424,883 6,431,018 6,434,448 6,445,979 6,459,958 6,463,358 6,484,067 6,486,629 6,507,165 6,654,666 6,665,588 6,680,461 6,696,810 6,728,417 6,763,284 6,772,493 6,845,296 6,853,881 6,888,089 6,898,486 6,917,837 6,928,337 6,965,091 6,970,802 7,038,165 7,069,808 7,084,900 7,092,791 7,133,747 7,143,100 7,149,602 7,131,848 7,161,321 7,171,041 7,174,234 7,173,213 7,177,722 7,177,439 7,181,294 7,181,313 7,280,687 7,283,661 7,291,806 7,299,713 7,315,650 7,324,873 7,328,083 7,330,777 7,333,879 7,355,725 7,359,817 7,373,220 7,376,488 7,386,367 7,464,623 7,447,615 7,445,260 7,474,939 7,486,816 7,495,192 7,501,778 7,502,504 7,508,155 7,512,459 7,525,273 7,526,121

### Conventions

### 

Information appearing under the "WARNING" caption concerns the protection of personnel. It is boxed and bolded to set it apart from the surrounding text.

# 

Information appearing under the "CAUTION" caption concerns the protection of equipment, software, and data. It is boxed and bolded to set it apart from the surrounding text.

Note Information appearing next to NOTE concerns related information or useful hints.

# • Original Instructions

Thank you very much for purchasing FANUC Robot.

Before using the Robot, be sure to read the "FANUC Robot SAFETY HANDBOOK (B-80687EN)" and understand the content.

- No part of this manual may be reproduced in any form.
- The appearance and specifications of this product are subject to change without notice.

The products in this manual are controlled based on Japan's "Foreign Exchange and Foreign Trade Law". The export from Japan may be subject to an export license by the government of Japan. Further, re-export to another country may be subject to the license of the government of the country from where the product is re-exported. Furthermore, the product may also be controlled by re-export regulations of the United States government. Should you wish to export or re-export these products, please contact FANUC for advice.

The products in this manual are manufactured under strict quality control. However, when using any of the products in a facility in which a serious accident or loss is predicted due to a failure of the product, install a safety device.

In this manual, we endeavor to include all pertinent matters. There are, however, a very large number of operations that must not or cannot be performed, and if the manual contained them all, it would be enormous in volume. It is, therefore, requested to assume that any operations that are not explicitly described as being possible are "not possible".

# Safety

FANUC America Corporation is not and does not represent itself as an expert in safety systems, safety equipment, or the specific safety aspects of your company and/or its work force. It is the responsibility of the owner, employer, or user to take all necessary steps to guarantee the safety of all personnel in the workplace.

The appropriate level of safety for your application and installation can be best determined by safety system professionals. FANUC America Corporation therefore, recommends that each customer consult with such professionals in order to provide a workplace that allows for the safe application, use, and operation of FANUC America Corporation systems.

According to the industry standard ANSI/RIA R15-06, the owner or user is advised to consult the standards to ensure compliance with its requests for Robotics System design, usability, operation, maintenance, and service. Additionally, as the owner, employer, or user of a robotic system, it is your responsibility to arrange for the training of the operator of a robot system to recognize and respond to known hazards associated with your robotic system and to be aware of the recommended operating procedures for your particular application and robot installation.

Ensure that the robot being used is appropriate for the application. Robots used in classified (hazardous) locations must be certified for this use.

FANUC America Corporation therefore, recommends that all personnel who intend to operate, program, repair, or otherwise use the robotics system be trained in an approved FANUC America Corporation training course and become familiar with the proper operation of the system. Persons responsible for programming the system–including the design, implementation, and debugging of application programs–must be familiar with the recommended programming procedures for your application and robot installation.

The following guidelines are provided to emphasize the importance of safety in the workplace.

## **CONSIDERING SAFETY FOR YOUR ROBOT INSTALLATION**

Safety is essential whenever robots are used. Keep in mind the following factors with regard to safety:

- The safety of people and equipment
- Use of safety enhancing devices
- Techniques for safe teaching and manual operation of the robot(s)
- Techniques for safe automatic operation of the robot(s)
- Regular scheduled inspection of the robot and workcell
- Proper maintenance of the robot

#### **Keeping People Safe**

The safety of people is always of primary importance in any situation. When applying safety measures to your robotic system, consider the following:

- External devices
- Robot(s)
- Tooling
- Workpiece

#### **Using Safety Enhancing Devices**

Always give appropriate attention to the work area that surrounds the robot. The safety of the work area can be enhanced by the installation of some or all of the following devices:

- Safety fences, barriers, or chains
- Light curtains
- Interlocks
- Pressure mats
- Floor markings
- Warning lights
- Mechanical stops
- EMERGENCY STOP buttons
- DEADMAN switches

#### Setting Up a Safe Workcell

A safe workcell is essential to protect people and equipment. Observe the following guidelines to ensure that the workcell is set up safely. These suggestions are intended to supplement and not replace existing federal, state, and local laws, regulations, and guidelines that pertain to safety.

- Sponsor your personnel for training in approved FANUC America Corporation training course(s) related to your application. Never permit untrained personnel to operate the robots.
- Install a lockout device that uses an access code to prevent unauthorized persons from operating the robot.
- Use anti-tie-down logic to prevent the operator from bypassing safety measures.
- Arrange the workcell so the operator faces the workcell and can see what is going on inside the cell.
- Clearly identify the work envelope of each robot in the system with floor markings, signs, and special barriers. The work envelope is the area defined by the maximum motion range of the robot, including any tooling attached to the wrist flange that extend this range.

- Position all controllers outside the robot work envelope.
- Never rely on software or firmware based controllers as the primary safety element unless they comply with applicable current robot safety standards.
- Mount an adequate number of EMERGENCY STOP buttons or switches within easy reach of the operator and at critical points inside and around the outside of the workcell.
- Install flashing lights and/or audible warning devices that activate whenever the robot is operating, that is, whenever power is applied to the servo drive system. Audible warning devices shall exceed the ambient noise level at the end–use application.
- Wherever possible, install safety fences to protect against unauthorized entry by personnel into the work envelope.
- Install special guarding that prevents the operator from reaching into restricted areas of the work envelope.
- Use interlocks.
- Use presence or proximity sensing devices such as light curtains, mats, and capacitance and vision systems to enhance safety.
- Periodically check the safety joints or safety clutches that can be optionally installed between the robot wrist flange and tooling. If the tooling strikes an object, these devices dislodge, remove power from the system, and help to minimize damage to the tooling and robot.
- Make sure all external devices are properly filtered, grounded, shielded, and suppressed to prevent hazardous motion due to the effects of electro-magnetic interference (EMI), radio frequency interference (RFI), and electro-static discharge (ESD).
- Make provisions for power lockout/tagout at the controller.
- Eliminate *pinch points*. Pinch points are areas where personnel could get trapped between a moving robot and other equipment.
- Provide enough room inside the workcell to permit personnel to teach the robot and perform maintenance safely.
- Program the robot to load and unload material safely.
- If high voltage electrostatics are present, be sure to provide appropriate interlocks, warning, and beacons.
- If materials are being applied at dangerously high pressure, provide electrical interlocks for lockout of material flow and pressure.

#### Staying Safe While Teaching or Manually Operating the Robot

Advise all personnel who must teach the robot or otherwise manually operate the robot to observe the following rules:

- Never wear watches, rings, neckties, scarves, or loose clothing that could get caught in moving machinery.
- Know whether or not you are using an intrinsically safe teach pendant if you are working in a hazardous environment.

- Before teaching, visually inspect the robot and work envelope to make sure that no potentially hazardous conditions exist. The work envelope is the area defined by the maximum motion range of the robot. These include tooling attached to the wrist flange that extends this range.
- The area near the robot must be clean and free of oil, water, or debris. Immediately report unsafe working conditions to the supervisor or safety department.
- FANUC America Corporation recommends that no one enter the work envelope of a robot that is on, except for robot teaching operations. However, if you must enter the work envelope, be sure all safeguards are in place, check the teach pendant DEADMAN switch for proper operation, and place the robot in teach mode. Take the teach pendant with you, turn it on, and be prepared to release the DEADMAN switch. Only the person with the teach pendant should be in the work envelope.

# 

Never bypass, strap, or otherwise deactivate a safety device, such as a limit switch, for any operational convenience. Deactivating a safety device is known to have resulted in serious injury and death.

- Know the path that can be used to escape from a moving robot; make sure the escape path is never blocked.
- Isolate the robot from all remote control signals that can cause motion while data is being taught.
- Test any program being run for the first time in the following manner:

## 

Stay outside the robot work envelope whenever a program is being run. Failure to do so can result in injury.

- Using a low motion speed, single step the program for at least one full cycle.
- Using a low motion speed, test run the program continuously for at least one full cycle.
- Using the programmed speed, test run the program continuously for at least one full cycle.
- Make sure all personnel are outside the work envelope before running production.

#### **Staying Safe During Automatic Operation**

Advise all personnel who operate the robot during production to observe the following rules:

• Make sure all safety provisions are present and active.

- Know the entire workcell area. The workcell includes the robot and its work envelope, plus the area occupied by all external devices and other equipment with which the robot interacts.
- Understand the complete task the robot is programmed to perform before initiating automatic operation.
- Make sure all personnel are outside the work envelope before operating the robot.
- Never enter or allow others to enter the work envelope during automatic operation of the robot.
- Know the location and status of all switches, sensors, and control signals that could cause the robot to move.
- Know where the EMERGENCY STOP buttons are located on both the robot control and external control devices. Be prepared to press these buttons in an emergency.
- Never assume that a program is complete if the robot is not moving. The robot could be waiting for an input signal that will permit it to continue its activity.
- If the robot is running in a pattern, do not assume it will continue to run in the same pattern.
- Never try to stop the robot, or break its motion, with your body. The only way to stop robot motion immediately is to press an EMERGENCY STOP button located on the controller panel, teach pendant, or emergency stop stations around the workcell.

#### **Staying Safe During Inspection**

When inspecting the robot, be sure to

- Turn off power at the controller.
- Lock out and tag out the power source at the controller according to the policies of your plant.
- Turn off the compressed air source and relieve the air pressure.
- If robot motion is not needed for inspecting the electrical circuits, press the EMERGENCY STOP button on the operator panel.
- Never wear watches, rings, neckties, scarves, or loose clothing that could get caught in moving machinery.
- If power is needed to check the robot motion or electrical circuits, be prepared to press the EMERGENCY STOP button, in an emergency.
- Be aware that when you remove a servomotor or brake, the associated robot arm will fall if it is not supported or resting on a hard stop. Support the arm on a solid support before you release the brake.

#### **Staying Safe During Maintenance**

When performing maintenance on your robot system, observe the following rules:

- Never enter the work envelope while the robot or a program is in operation.
- Before entering the work envelope, visually inspect the workcell to make sure no potentially hazardous conditions exist.

- Never wear watches, rings, neckties, scarves, or loose clothing that could get caught in moving machinery.
- Consider all or any overlapping work envelopes of adjoining robots when standing in a work envelope.
- Test the teach pendant for proper operation before entering the work envelope.
- If it is necessary for you to enter the robot work envelope while power is turned on, you must be sure that you are in control of the robot. Be sure to take the teach pendant with you, press the DEADMAN switch, and turn the teach pendant on. Be prepared to release the DEADMAN switch to turn off servo power to the robot immediately.
- Whenever possible, perform maintenance with the power turned off. Before you open the controller front panel or enter the work envelope, turn off and lock out the 3-phase power source at the controller.
- Be aware that when you remove a servomotor or brake, the associated robot arm will fall if it is not supported or resting on a hard stop. Support the arm on a solid support before you release the brake.

## 

Lethal voltage is present in the controller WHENEVER IT IS CONNECTED to a power source. Be extremely careful to avoid electrical shock. HIGH VOLTAGE IS PRESENT at the input side whenever the controller is connected to a power source. Turning the disconnect or circuit breaker to the OFF position removes power from the output side of the device only.

- Release or block all stored energy. Before working on the pneumatic system, shut off the system air supply and purge the air lines.
- Isolate the robot from all remote control signals. If maintenance must be done when the power is on, make sure the person inside the work envelope has sole control of the robot. The teach pendant must be held by this person.
- Make sure personnel cannot get trapped between the moving robot and other equipment. Know the path that can be used to escape from a moving robot. Make sure the escape route is never blocked.
- Use blocks, mechanical stops, and pins to prevent hazardous movement by the robot. Make sure that such devices do not create pinch points that could trap personnel.

# 

Do not try to remove any mechanical component from the robot before thoroughly reading and understanding the procedures in the appropriate manual. Doing so can result in serious personal injury and component destruction.

- Be aware that when you remove a servomotor or brake, the associated robot arm will fall if it is not supported or resting on a hard stop. Support the arm on a solid support before you release the brake.
- When replacing or installing components, make sure dirt and debris do not enter the system.
- Use only specified parts for replacement. To avoid fires and damage to parts in the controller, never use nonspecified fuses.
- Before restarting a robot, make sure no one is inside the work envelope; be sure that the robot and all external devices are operating normally.

## **KEEPING MACHINE TOOLS AND EXTERNAL DEVICES SAFE**

Certain programming and mechanical measures are useful in keeping the machine tools and other external devices safe. Some of these measures are outlined below. Make sure you know all associated measures for safe use of such devices.

#### **Programming Safety Precautions**

Implement the following programming safety measures to prevent damage to machine tools and other external devices.

- Back-check limit switches in the workcell to make sure they do not fail.
- Implement "failure routines" in programs that will provide appropriate robot actions if an external device or another robot in the workcell fails.
- Use *handshaking* protocol to synchronize robot and external device operations.
- Program the robot to check the condition of all external devices during an operating cycle.

#### **Mechanical Safety Precautions**

Implement the following mechanical safety measures to prevent damage to machine tools and other external devices.

- Make sure the workcell is clean and free of oil, water, and debris.
- Use DCS (Dual Check Safety), software limits, limit switches, and mechanical hardstops to prevent undesired movement of the robot into the work area of machine tools and external devices.

## **KEEPING THE ROBOT SAFE**

Observe the following operating and programming guidelines to prevent damage to the robot.

### **Operating Safety Precautions**

The following measures are designed to prevent damage to the robot during operation.

- Use a low override speed to increase your control over the robot when jogging the robot.
- Visualize the movement the robot will make before you press the jog keys on the teach pendant.
- Make sure the work envelope is clean and free of oil, water, or debris.
- Use circuit breakers to guard against electrical overload.

#### **Programming Safety Precautions**

The following safety measures are designed to prevent damage to the robot during programming:

- Establish *interference zones* to prevent collisions when two or more robots share a work area.
- Make sure that the program ends with the robot near or at the home position.
- Be aware of signals or other operations that could trigger operation of tooling resulting in personal injury or equipment damage.
- In dispensing applications, be aware of all safety guidelines with respect to the dispensing materials.
- **NOTE**: Any deviation from the methods and safety practices described in this manual must conform to the approved standards of your company. If you have questions, see your supervisor.

## ADDITIONAL SAFETY CONSIDERATIONS FOR PAINT ROBOT INSTALLATIONS

Process technicians are sometimes required to enter the paint booth, for example, during daily or routine calibration or while teaching new paths to a robot. Maintenance personnel also must work inside the paint booth periodically.

Whenever personnel are working inside the paint booth, ventilation equipment must be used. Instruction on the proper use of ventilating equipment usually is provided by the paint shop supervisor.

Although paint booth hazards have been minimized, potential dangers still exist. Therefore, today's highly automated paint booth requires that process and maintenance personnel have full awareness of the system and its capabilities. They must understand the interaction that occurs between the vehicle moving along the conveyor and the robot(s), hood/deck and door opening devices, and high–voltage electrostatic tools.

## A CAUTION

Ensure that all ground cables remain connected. Never operate the paint robot with ground provisions disconnected. Otherwise, you could injure personnel or damage equipment.

Paint robots are operated in three modes:

- Teach or manual mode
- Automatic mode, including automatic and exercise operation
- Diagnostic mode

During both teach and automatic modes, the robots in the paint booth will follow a predetermined pattern of movements. In teach mode, the process technician teaches (programs) paint paths using the teach pendant.

In automatic mode, robot operation is initiated at the System Operator Console (SOC) or Manual Control Panel (MCP), if available, and can be monitored from outside the paint booth. All personnel must remain outside of the booth or in a designated safe area within the booth whenever automatic mode is initiated at the SOC or MCP.

In automatic mode, the robots will execute the path movements they were taught during teach mode, but generally at production speeds.

When process and maintenance personnel run diagnostic routines that require them to remain in the paint booth, they must stay in a designated safe area.

#### Paint System Safety Features

Process technicians and maintenance personnel must become totally familiar with the equipment and its capabilities. To minimize the risk of injury when working near robots and related equipment, personnel must comply strictly with the procedures in the manuals.

This section provides information about the safety features that are included in the paint system and also explains the way the robot interacts with other equipment in the system.

The paint system includes the following safety features:

• Most paint booths have red warning beacons that illuminate when the robots are armed and ready to paint. Your booth might have other kinds of indicators. Learn what these are.

- Some paint booths have a blue beacon that, when illuminated, indicates that the electrostatic devices are enabled. Your booth might have other kinds of indicators. Learn what these are.
- EMERGENCY STOP buttons are located on the robot controller and teach pendant. Become familiar with the locations of all E–STOP buttons.
- An intrinsically safe teach pendant is used when teaching in hazardous paint atmospheres.
- A DEADMAN switch is located on each teach pendant. When this switch is held in, and the teach pendant is on, power is applied to the robot servo system. If the engaged DEADMAN switch is released or pressed harder during robot operation, power is removed from the servo system, all axis brakes are applied, and the robot comes to an EMERGENCY STOP. Safety interlocks within the system might also E–STOP other robots.

## 

An EMERGENCY STOP will occur if the DEADMAN switch is released on a bypassed robot.

- Overtravel by robot axes is prevented by software limits. All of the major and minor axes are governed by software limits. DCS (Dual Check Safety), limit switches and hardstops also limit travel by the major axes.
- EMERGENCY STOP limit switches and photoelectric eyes might be part of your system. Limit switches, located on the entrance/exit doors of each booth, will EMERGENCY STOP all equipment in the booth if a door is opened while the system is operating in automatic or manual mode. For some systems, signals to these switches are inactive when the switch on the SOC is in teach mode.
- When present, photoelectric eyes are sometimes used to monitor unauthorized intrusion through the entrance/exit silhouette openings.
- System status is monitored by computer. Severe conditions result in automatic system shutdown.

### **Staying Safe While Operating the Paint Robot**

When you work in or near the paint booth, observe the following rules, in addition to all rules for safe operation that apply to all robot systems.

## 

Observe all safety rules and guidelines to avoid injury.

Safety

## 

Never bypass, strap, or otherwise deactivate a safety device, such as a limit switch, for any operational convenience. Deactivating a safety device is known to have resulted in serious injury and death.

# A WARNING

Enclosures shall not be opened unless the area is known to be nonhazardous or all power has been removed from devices within the enclosure. Power shall not be restored after the enclosure has been opened until all combustible dusts have been removed from the interior of the enclosure and the enclosure purged. Refer to the Purge chapter for the required purge time.

- Know the work area of the entire paint station (workcell).
- Know the work envelope of the robot and hood/deck and door opening devices.
- Be aware of overlapping work envelopes of adjacent robots.
- Know where all red, mushroom-shaped EMERGENCY STOP buttons are located.
- Know the location and status of all switches, sensors, and/or control signals that might cause the robot, conveyor, and opening devices to move.
- Make sure that the work area near the robot is clean and free of water, oil, and debris. Report unsafe conditions to your supervisor.
- Become familiar with the complete task the robot will perform BEFORE starting automatic mode.
- Make sure all personnel are outside the paint booth before you turn on power to the robot servo system.
- Never enter the work envelope or paint booth before you turn off power to the robot servo system.
- Never enter the work envelope during automatic operation unless a safe area has been designated.
- Never wear watches, rings, neckties, scarves, or loose clothing that could get caught in moving machinery.
- Remove all metallic objects, such as rings, watches, and belts, before entering a booth when the electrostatic devices are enabled.
- Stay out of areas where you might get trapped between a moving robot, conveyor, or opening device and another object.
- Be aware of signals and/or operations that could result in the triggering of guns or bells.
- Be aware of all safety precautions when dispensing of paint is required.
- Follow the procedures described in this manual.

### **Special Precautions for Combustible Dusts (Powder Paint)**

When the robot is used in a location where combustible dusts are found, such as the application of powder paint, the following special precautions are required to insure that there are no combustible dusts inside the robot.

- Purge maintenance air should be maintained at all times, even when the robot power is off. This will insure that dust can not enter the robot.
- A purge cycle will not remove accumulated dusts. Therefore, if the robot is exposed to dust when maintenance air is not present, it will be necessary to remove the covers and clean out any accumulated dust. Do not energize the robot until you have performed the following steps.
- 1. Before covers are removed, the exterior of the robot should be cleaned to remove accumulated dust.
- 2. When cleaning and removing accumulated dust, either on the outside or inside of the robot, be sure to use methods appropriate for the type of dust that exists. Usually lint free rags dampened with water are acceptable. Do not use a vacuum cleaner to remove dust as it can generate static electricity and cause an explosion unless special precautions are taken.
- 3. Thoroughly clean the interior of the robot with a lint free rag to remove any accumulated dust.
- 4. When the dust has been removed, the covers must be replaced immediately.
- 5. Immediately after the covers are replaced, run a complete purge cycle. The robot can now be energized.

#### **Staying Safe While Operating Paint Application Equipment**

When you work with paint application equipment, observe the following rules, in addition to all rules for safe operation that apply to all robot systems.

### 

When working with electrostatic paint equipment, follow all national and local codes as well as all safety guidelines within your organization. Also reference the following standards: NFPA 33 Standards for Spray Application Using Flammable or Combustible Materials, and NFPA 70 National Electrical Code.

- **Grounding**: All electrically conductive objects in the spray area must be grounded. This includes the spray booth, robots, conveyors, workstations, part carriers, hooks, paint pressure pots, as well as solvent containers. Grounding is defined as the object or objects shall be electrically connected to ground with a resistance of not more than 1 megohms.
- **High Voltage**: High voltage should only be on during actual spray operations. Voltage should be off when the painting process is completed. Never leave high voltage on during a cap cleaning process.
- Avoid any accumulation of combustible vapors or coating matter.
- Follow all manufacturer recommended cleaning procedures.
- Make sure all interlocks are operational.

- No smoking.
- Post all warning signs regarding the electrostatic equipment and operation of electrostatic equipment according to NFPA 33 Standard for Spray Application Using Flammable or Combustible Material.
- Disable all air and paint pressure to bell.
- Verify that the lines are not under pressure.

#### **Staying Safe During Maintenance**

When you perform maintenance on the painter system, observe the following rules, and all other maintenance safety rules that apply to all robot installations. Only qualified, trained service or maintenance personnel should perform repair work on a robot.

- Paint robots operate in a potentially explosive environment. Use caution when working with electric tools.
- When a maintenance technician is repairing or adjusting a robot, the work area is under the control of that technician. All personnel not participating in the maintenance must stay out of the area.
- For some maintenance procedures, station a second person at the control panel within reach of the EMERGENCY STOP button. This person must understand the robot and associated potential hazards.
- Be sure all covers and inspection plates are in good repair and in place.
- Always return the robot to the "home" position before you disarm it.
- Never use machine power to aid in removing any component from the robot.
- During robot operations, be aware of the robot's movements. Excess vibration, unusual sounds, and so forth, can alert you to potential problems.
- Whenever possible, turn off the main electrical disconnect before you clean the robot.
- When using vinyl resin observe the following:
  - Wear eye protection and protective gloves during application and removal.
  - Adequate ventilation is required. Overexposure could cause drowsiness or skin and eye irritation.
  - If there is contact with the skin, wash with water.
  - Follow the Original Equipment Manufacturer's Material Safety Data Sheets.
- When using paint remover observe the following:
  - Eye protection, protective rubber gloves, boots, and apron are required during booth cleaning.
  - Adequate ventilation is required. Overexposure could cause drowsiness.
  - If there is contact with the skin or eyes, rinse with water for at least 15 minutes. Then seek medical attention as soon as possible.
  - Follow the Original Equipment Manufacturer's Material Safety Data Sheets.

# SAFETY PRECAUTIONS

This chapter describes the precautions which must be followed to ensure the safe use of the robot. Before using the robot, be sure to read this chapter thoroughly.

For detailed functions of the robot operation, read the relevant operator's manual to understand fully its specification.

For the safety of the operator and the system, follow all safety precautions when operating a robot and its peripheral equipments installed in a work cell.

In addition, refer to the "FANUC Robot SAFETY HANDBOOK (B-80687EN)".

**1** DEFINITON OF USER

The user can be classified as follows.

Operator:

- Turns robot controller power ON/OFF
- Starts robot program from Contact your local FANUC representative

Programmer:

- Operates the robot
- Teaches robot inside the safety fence

Maintenance engineer:

- Operates the robot
- Teaches robot inside the safety fence
- Maintenance (repair, adjustment, replacement)
- An operator cannot work inside the safety fence.
- A programmer, teaching operator, and maintenance engineer can work inside the safety fence. The working activities inside the safety fence include lifting, setting, teaching, adjusting, maintenance, etc.
- To work inside the fence, the person must be trained on proper robot operation.

During the operation, programming, and maintenance of your robotic system, the programmer, teaching operator, and maintenance engineer should take additional care of their safety by using the following safety precautions.

- Use adequate clothing or uniforms during system operation
- Wear safety shoes
- Use helmet

2

# NOTATION OF "WARNING", "CAUTION" and "NOTE"

To ensure the safety of users and prevent damage to the machine, this manual indicates each precaution on safety with "WARNING" or "CAUTION" according to its severity. Supplementary information is indicated by "NOTE". Read the contents of each "WARNING", "CAUTION" and "NOTE" before using the robot.

Symbol	Definitions
	Used if hazard resulting in the death or serious injury of the user will be expected to occur if he or she fails to follow the approved procedure.
	Used if a hazard resulting in the minor or moderate injury of the user, or equipment damage may be expected to occur if he or she fails to follow the approved procedure.
NOTE	Used if a supplementary explanation not related to any of WARNING and CAUTION is to be indicated.

• Check this manual thoroughly, and keep it handy for the future reference.

# **3** USER SAFETY

User safety is the primary safety consideration. Because it is very dangerous to enter the operating space of the robot during automatic operation, adequate safety precautions must be observed. The following lists the general safety precautions. Careful consideration must be made to ensure user safety.

(1) Have the robot system users attend the training courses held by FANUC.

FANUC provides various training courses. Contact our sales office for details.

- (2) Even when the robot is stationary, it is possible that the robot is still in a ready to move state, and is waiting for a signal. In this state, the robot is regarded as still in motion. To ensure user safety, provide the system with an alarm to indicate visually or aurally that the robot is in motion.
- (3) Install a safety fence with a gate so that no user can enter the work area without passing through the gate. Install an interlocking device, a safety plug, and so forth in the safety gate so that the robot is stopped as the safety gate is opened.

The controller is designed to receive this interlocking signal of the door switch. When the gate is opened and this signal received, the controller stops the robot (Please refer to "STOP TYPE OF ROBOT" in "SAFETY PRECAUTIONS" for detail of stop type). For connection, see Fig. 3 (b).

- (4) Provide the peripheral equipments with appropriate earth (Class A, Class B, Class C, and Class D).
- (5) Try to install the peripheral equipments outside the robot operating space.
- (6) Draw an outline on the floor, clearly indicating the range of the robot operating space, including the tools such as a hand.
- (7) Install a mat switch or photoelectric switch on the floor with an interlock to a visual or aural alarm that stops the robot when a user enters the work area.
- (8) If necessary, install a safety lock so that no one except the user in charge can turn on the power of the robot.

The circuit breaker installed in the controller is designed to disable anyone from turning it on when it is locked with a padlock.

- (9) When adjusting each peripheral equipment independently, be sure to turn off the power of the robot.
- (10) Operators should be ungloved while manipulating the operator panel or teach pendant. Operation with gloved fingers could cause an operation error.
- (11) Programs, system variables, and other information can be saved on memory card or USB memories. Be sure to save the data periodically in case the data is lost in an accident. (refer to Controller OPERATOR'S MANUAL.)
- (12) The robot should be transported and installed by accurately following the procedures recommended by FANUC. Wrong transportation or installation may cause the robot to fall, resulting in severe injury to workers.
- (13) In the first operation of the robot after installation, the operation should be restricted to low speeds. Then, the speed should be gradually increased to check the operation of the robot.
- (14) Before the robot is started, it should be checked that no one is inside the safety fence. At the same time, a check must be made to ensure that there is no risk of hazardous situations. If detected, such a situation should be eliminated before the operation.
- (15) When the robot is used, the following precautions should be taken. Otherwise, the robot and peripheral equipment can be adversely affected, or workers can be severely injured.
  - Avoid using the robot in a flammable environment.
  - Avoid using the robot in an explosive environment.
  - Avoid using the robot in an environment full of radiation.
  - Avoid using the robot under water or at high humidity.
  - Avoid using the robot to carry a person or animal.
  - Avoid using the robot as a stepladder. (Never climb up on or hang from the robot.)
  - Outdoor
- (16) When connecting the peripheral equipments related to stop (safety fence etc.) and each signal (external emergency, fence etc.) of robot, be sure to confirm the stop movement and do not take the wrong connection.
- (17) When preparing footstep, please consider security for installation and maintenance work in high place according to Fig. 3 (c). Please consider footstep and safety belt mounting position.






Fig. 3 (a) Safety fence and safety gate

### 

When you close a fence, please confirm that there is not a person from all directions of the robot.








Fig. 3 (c) Pedestal for maintenance

# **3.1** OPERATOR SAFETY

The operator is a person who operates the robot system. In this sense, a worker who operates the teach pendant is also an operator. However, this section does not apply to teach pendant operators.

- (1) If you do not have to operate the robot, turn off the power of the robot controller or press the EMERGENCY STOP button, and then proceed with necessary work.
- (2) Operate the robot system at a location outside of the safety fence
- (3) Install a safety fence with a safety gate to prevent any worker other than the operator from entering the work area unexpectedly and to prevent the worker from entering a dangerous area.
- (4) Install one or more necessary quantity of EMERGENCY STOP button(s) within the operator's reach in appropriate location(s) based on the system layout.

The robot controller is designed to be connected to an external EMERGENCY STOP button. With this connection, the controller stops the robot operation (Please refer to "STOP TYPE OF ROBOT" in SAFETY PRECAUTIONS for detail of stop type), when the external EMERGENCY STOP button is pressed. For connection, see Fig.3.1.




Fig. 3.1 Connection Diagram for External Emergency Stop Button

# **3.2** SAFETY OF THE PROGRAMMER

While teaching the robot, the operator must enter the work area of the robot. The operator must ensure the safety of the teach pendant operator especially.

- (1) Unless it is specifically necessary to enter the robot work area, carry out all tasks outside the area.
- (2) Before teaching the robot, check that the robot and its peripheral devices are all in the normal operating condition.
- (3) If it is inevitable to enter the robot work area to teach the robot, check the locations, settings, and other conditions of the safety devices (such as the EMERGENCY STOP button, the DEADMAN switch on the teach pendant) before entering the area.
- (4) The programmer must be extremely careful not to let anyone else enter the robot work area.
- (5) Programming should be done outside the area of the safety fence as far as possible. If programming needs to be done in the area of the safety fence, the programmer should take the following precautions:

- Before entering the area of the safety fence, ensure that there is no risk of dangerous situations in the area.

- Be prepared to press the emergency stop button whenever necessary.
- Robot motions should be made at low speeds.

- Before starting programming, check the entire system status to ensure that no remote instruction to the peripheral equipment or motion would be dangerous to the user.

The operator panel is provided with an emergency stop button and a key switch (mode switch) for selecting the automatic operation mode (AUTO) and the teach modes (T1 and T2). Before entering the inside of the safety fence for the purpose of teaching, set the switch to a teach mode, remove the key from the mode switch to prevent other people from changing the operation mode carelessly, then open the safety gate. If the safety gate is opened with the automatic operation mode set, the robot stops (Please refer to "STOP TYPE OF ROBOT" in SAFETY PRECAUTIONS for detail of stop type). After the switch is set to a teach mode, the safety gate is disabled. The programmer should understand that the safety gate is disabled and is responsible for keeping other people from entering the inside of the safety fence.

The teach pendant is provided with an enable/disable switch, DEADMAN switch as well as an emergency stop button. These button and switch function as follows:

- (1) Emergency stop button: Causes the stop of the robot (Please refer to "STOP TYPE OF ROBOT" in SAFETY PRECAUTIONS for detail of stop type) when pressed.
- (2) DEADMAN switch: Functions differently depending on the teach pendant enable/disable switch setting status.
  - (a) Disable: The DEADMAN switch is disabled.
  - (b) Enable: Servo power is turned off when the operator releases the DEADMAN switch or when the operator presses the switch strongly.
  - Note) The DEADMAN switch is provided to stop the robot when the operator releases the teach pendant or presses the pendant strongly in case of emergency. The R-30*i*B/R-30*i*B Plus employs a 3-position DEADMAN switch, which allows the robot to operate when the 3-position DEADMAN switch is pressed to its intermediate point. When the operator releases the DEADMAN switch or presses the switch strongly, the robot stops immediately.

Based on the risk assessment by FANUC, number of operation of DEADMAN SW should not exceed about 10000 times per year.

The operator's intention of starting teaching is determined by the controller through the dual operation of setting the teach pendant enable/disable switch to the enable position and pressing the DEADMAN switch. The operator should make sure that the robot could operate in such conditions and be responsible in carrying out tasks safely.

The teach pendant, operator panel, and peripheral device interface send each robot start signal. However the validity of each signal changes as follows depending on the mode switch of the operator panel, the teach pendant enable/disable switch and the remote condition on the software.

Mode	Teach pendant enable/disable switch	Software remote condition	Teach pendant	Operator panel	Peripheral device
AUTO mode	On	Local	Not allowed	Not allowed	Not allowed
		Remote	Not allowed	Not allowed	Not allowed
	Off	Local	Not allowed	Allowed to start	Not allowed
		Remote	Not allowed	Not allowed	Allowed to start
T1, T2 mode	On	Local	Allowed to start	Not allowed	Not allowed
		Remote	Allowed to start	Not allowed	Not allowed
	Off	Local	Not allowed	Not allowed	Not allowed
		Remote	Not allowed	Not allowed	Not allowed

T1,T2 mode: DEADMAN switch is effective.

- (6) To start the system using the Contact your local FANUC representative, make certain that nobody is the robot work area and that there are no abnormal conditions in the robot work area.
- (7) When a program is completed, be sure to carry out a test operation according to the procedure below.
  - (a) Run the program for at least one operation cycle in the single step mode at low speed.
  - (b) Run the program for at least one operation cycle in the continuous operation mode at low speed.
  - (c) Run the program for one operation cycle in the continuous operation mode at the intermediate speed and check that no abnormalities occur due to a delay in timing.
  - (d) Run the program for one operation cycle in the continuous operation mode at the normal operating speed and check that the system operates automatically without trouble.
  - (e) After checking the completeness of the program through the test operation above, execute it in the automatic operation mode.
- (8) While operating the system in the automatic operation mode, the teach pendant operator should leave the robot work area.

# **3.3** SAFETY OF THE MAINTENANCE ENGINEER

For the safety of maintenance engineer personnel, pay utmost attention to the following.

- (1) During operation, never enter the robot operating space.
- (2) A hazardous situation may arise when the robot or the system, are kept with their power-on during maintenance operations. Therefore, for any maintenance operation, the robot and the system should be put into the power-off state. If necessary, a lock should be in place in order to prevent any other person from turning on the robot and/or the system. In case maintenance needs to be executed in the power-on state, the emergency stop button must be pressed.
- (3) If it becomes necessary to enter the robot operating space while the power is on, press the emergency stop button on the operator box or operator panel, or the teach pendant before entering the range. The maintenance worker must indicate that maintenance work is in progress and be careful not to allow other people to operate the robot carelessly.
- (4) When entering the area enclosed by the safety fence, the worker must check the whole robot system in order to make sure no dangerous situations exist. In case the worker needs to enter the safety area whilst a dangerous situation exists, extreme care must be taken, and whole robot system status must be carefully monitored.
- (5) Before the maintenance of the pneumatic system is started, the supply pressure should be shut off and the pressure in the piping should be reduced to zero.
- (6) Before the start of maintenance work, check that the robot and its peripheral equipments are all in the normal operating condition.
- (7) Do not operate the robot in the automatic operation while anybody is in the robot operating space.
- (8) When you maintain the robot alongside a wall or instrument, or when multiple users are working nearby, make certain that their escape path is not obstructed.
- (9) When a tool is mounted on the robot, or when any movable device other than the robot is installed, such as belt conveyor, pay careful attention to its motion.
- (10) If necessary, have a user who is familiar with the robot system stand beside the operator panel and observe the work being performed. If any danger arises, the user should be ready to press the EMERGENCY STOP button at any time.
- (11) When replacing a part, please contact your local FANUC representative. If a wrong procedure is followed, an accident may occur, causing damage to the robot and injury to the user.
- (12) When replacing or reinstalling components, take care to prevent foreign material from entering the system.
- (13) When handling each unit or printed circuit board in the controller during inspection, turn off the circuit breaker to protect against electric shock.

If there are two cabinets, turn off the both circuit breaker.

- (14) A part should be replaced with a part recommended by FANUC. If other parts are used, malfunction or damage would occur. Especially, a fuse that is not recommended by FANUC should not be used. Such a fuse may cause a fire.
- (15) When restarting the robot system after completing maintenance work, make sure in advance that there is no person in the operating space and that the robot and the peripheral equipments are not abnormal.
- (16) When a motor or brake is removed, the robot arm should be supported with a crane or other equipment beforehand so that the arm would not fall during the removal.
- (17) Whenever grease is spilled on the floor, it should be removed as quickly as possible to prevent dangerous falls.
- (18) The following parts are heated. If a maintenance user needs to touch such a part in the heated state, the user should wear heat-resistant gloves or use other protective tools.
  - Servo motor
  - Inside the controller
  - Reducer
  - Gearbox

- Wrist unit
- (19) Maintenance should be done under suitable light. Care must be taken that the light would not cause any danger.
- (20) When a motor, reducer, or other heavy load is handled, a crane or other equipment should be used to protect maintenance workers from excessive load. Otherwise, the maintenance workers would be severely injured.
- (21) The robot should not be stepped on or climbed up during maintenance. If it is attempted, the robot would be adversely affected. In addition, a misstep can cause injury to the worker.
- (22) When performing maintenance work in high place, secure a footstep and wear safety belt.
- (23) After the maintenance is completed, spilled oil or water and metal chips should be removed from the floor around the robot and within the safety fence.
- (24) When a part is replaced, all bolts and other related components should put back into their original places. A careful check must be given to ensure that no components are missing or left not mounted.
- (25) In case robot motion is required during maintenance, the following precautions should be taken :Foresee an escape route. And during the maintenance motion itself, monitor continuously the whole robot system so that your escape route will not become blocked by the robot, or by peripheral equipment.

- Always pay attention to potentially dangerous situations, and be prepared to press the emergency stop button whenever necessary.

- (26) The robot should be periodically inspected. (Refer to the robot mechanical manual and controller maintenance manual.) A failure to do the periodical inspection can adversely affect the performance or service life of the robot and may cause an accident
- (27) After a part is replaced, a test execution should be given for the robot according to a predetermined method. (See TESTING section of "Controller operator's manual".) During the test execution, the maintenance worker should work outside the safety fence.

# 4 SAFETY OF THE TOOLS AND PERIPHERAL DEVICES

# 4.1 PRECAUTIONS IN PROGRAMMING

- (1) Use a limit switch or other sensor to detect a dangerous condition and, if necessary, design the program to stop the robot when the sensor signal is received.
- (2) Design the program to stop the robot when an abnormal condition occurs in any other robots or peripheral devices, even though the robot itself is normal.
- (3) For a system in which the robot and its peripheral devices are in synchronous motion, particular care must be taken in programming so that they do not interfere with each other.
- (4) Provide a suitable interface between the robot and its peripheral devices so that the robot can detect the states of all devices in the system and can be stopped according to the states.

# 4.2 PRECAUTIONS FOR MECHANISM

- (1) Keep the component cells of the robot system clean, operate the robot where insulated from the influence of grease, water, and dust.
- (2) Don't use unconfirmed liquid for cutting fluid and cleaning fluid.
- (3) Adopt limit switches or mechanical stoppers to limit the robot motion, and avoid the robot from collisions against peripheral devices or tools.
- (4) Observe the following precautions about the mechanical unit cables. Failure to follow precautions may cause mechanical troubles.
  - Use mechanical unit cable that have required user interface.

- Do not add user cable or hose to inside of mechanical unit.
- Please do not obstruct the movement of the mechanical unit when cables are added to outside of mechanical unit.
- In the case of the model that a cable is exposed, please do not perform remodeling (Adding a protective cover and fix an outside cable more) obstructing the behavior of the outcrop of the cable.
- When installing user peripheral equipment on the robot mechanical unit, please pay attention that equipment does not interfere with the robot itself.
- (5) The frequent power-off stop for the robot during operation causes the trouble of the robot. Please avoid the system construction that power-off stop would be operated routinely. (Refer to bad case example.) Please perform power-off stop after reducing the speed of the robot and stopping it by hold stop or cycle stop when it is not urgent. (Please refer to "STOP TYPE OF ROBOT" in SAFETY PRECAUTIONS for detail of stop type.)
  - (Bad case example)
  - Whenever poor product is generated, a line stops by emergency stop and power-off of the robot is incurred.
  - When alteration is necessary, safety switch is operated by opening safety fence and power-off stop is incurred for the robot during operation.
  - An operator pushes the emergency stop button frequently, and a line stops.
  - An area sensor or a mat switch connected to safety signal operates routinely and power-off stop is incurred for the robot.
  - Power-off stop is regularly incurred due to an inappropriate setting for Dual Check Safety (DCS).
- (6) Power-off stop of Robot is executed when collision detection alarm (SRVO-050) etc. occurs. Please try to avoid unnecessary power-off stops. It may cause the trouble of the robot, too. So remove the causes of the alarm.

# **5** SAFETY OF THE ROBOT MECHANISM

# 5.1 PRECAUTIONS IN OPERATION

- (1) When operating the robot in the jog mode, set it at an appropriate speed so that the operator can manage the robot in any eventuality.
- (2) Before pressing the jog key, be sure you know in advance what motion the robot will perform in the jog mode.

# 5.2 PRECAUTIONS IN PROGRAMMING

- (1) When the work areas of robots overlap, make certain that the motions of the robots do not interfere with each other.
- (2) Be sure to specify the predetermined work origin in a motion program for the robot and program the motion so that it starts from the origin and terminates at the origin.Make it possible for the operator to easily distinguish at a glance that the robot motion has terminated.

# **5.3** PRECAUTIONS FOR MECHANISMS

(1) Keep the work areas of the robot clean, and operate the robot in an environment free of grease, water, and dust.

# **5.4** PROCEDURE TO MOVE ARM WITHOUT DRIVE POWER IN EMERGENCY OR ABNORMAL SITUATIONS

For emergency or abnormal situations (e.g. persons trapped in or pinched by the robot), brake release unit can be used to move the robot axes without drive power.

Please refer to this manual and mechanical unit operator's manual for using method of brake release unit and method of supporting robot.

# **6** SAFETY OF THE END EFFECTOR

# 6.1 **PRECAUTIONS IN PROGRAMMING**

- (1) To control the pneumatic, hydraulic and electric actuators, carefully consider the necessary time delay after issuing each control command up to actual motion and ensure safe control.
- (2) Provide the end effector with a limit switch, and control the robot system by monitoring the state of the end effector.

# **7** STOP TYPE OF ROBOT

The following three robot stop types exist:

### Power-Off Stop (Category 0 following IEC 60204-1)

Servo power is turned off and the robot stops immediately. Servo power is turned off when the robot is moving, and the motion path of the deceleration is uncontrolled.

The following processing is performed at Power-Off stop.

- An alarm is generated and servo power is turned off.
- The robot operation is stopped immediately. Execution of the program is paused.

## Controlled stop (Category 1 following IEC 60204-1)

The robot is decelerated until it stops, and servo power is turned off.

The following processing is performed at Controlled stop.

- The alarm "SRVO-199 Controlled stop" occurs along with a decelerated stop. Execution of the program is paused.
- An alarm is generated and servo power is turned off.

## Hold (Category 2 following IEC 60204-1)

The robot is decelerated until it stops, and servo power remains on.

The following processing is performed at Hold.

The robot operation is decelerated until it stops. Execution of the program is paused.

#### 

The stopping distance and stopping time of Controlled stop are longer than the stopping distance and stopping time of Power-Off stop. A risk assessment for the whole robot system, which takes into consideration the increased stopping distance and stopping time, is necessary when Controlled stop is used.

When the E-Stop button is pressed or the FENCE is open, the stop type of robot is Power-Off stop or Controlled stop. The configuration of stop type for each situation is called *stop pattern*. The stop pattern is different according to the controller type or option configuration.

Stop pattern	Mode	E-Stop button	External E-Stop	FENCE open	SVOFF input
A	AUTO	P-Stop	P-Stop	C-Stop	C-Stop
	T1	P-Stop	P-Stop	-	C-Stop
	T2	P-Stop	P-Stop	-	C-Stop
С	AUTO	C-Stop	C-Stop	C-Stop	C-Stop
	T1	P-Stop	P-Stop	-	C-Stop
	T2	P-Stop	P-Stop	-	C-Stop

There are the following 2 Stop patterns.

P-Stop: Power-Off stop

C-Stop: Controlled stop

-: Disable

#### 

In this manual, the term "Emergency-stop" is used for the stop by above safety signals. Please refer to above table for actual stop type.

The following table indicates the Stop pattern according to the controller type or option configuration.

Option	Stop pattern
Standard	А
Controlled stop by E-Stop (A05B-2600-J570)	C

The stop pattern of the controller is displayed in "Stop pattern" line in software version screen. Please refer "Software version" in operator's manual of controller for the detail of software version screen.

### "Controlled stop by E-Stop" option

"Controlled stop by E-Stop" option (A05B-2600-J570) is an optional function. When this option is loaded, the stop type of the following alarms becomes Controlled stop but only in AUTO mode. In T1 or T2 mode, the stop type is Power-Off stop which is the normal operation of the system.

Alarm	Condition
SRVO-001 Operator panel E-stop	Operator panel E-stop is pressed.
SRVO-002 Teach pendant E-stop	Teach pendant E-stop is pressed.
SRVO-007 External emergency stops	External emergency stop input (EES1-EES11, EES2-EES21) is
	open.
SRVO-408 DCS SSO Ext Emergency Stop	In DCS Safe I/O connect function, SSO[3] is OFF.
SRVO-409 DCS SSO Servo Disconnect	In DCS Safe I/O connect function, SSO[4] is OFF.

Controlled stop is different from Power-Off stop as follows:

- In Controlled stop, the robot is stopped on the program path. This function is effective for a system where the robot can interfere with other devices if it deviates from the program path.
- In Controlled stop, physical impact is less than Power-Off stop. This function is effective for systems where the physical impact to the mechanical unit or EOAT (End Of Arm Tool) should be minimized.
- The stopping distance and stopping time of Controlled stop is longer than the stopping distance and stopping time of Power-Off stop, depending on the robot model and axis. Please refer to the operator's manual of a particular robot model for the data of stopping distance and stopping time.

### SAFETY PRECAUTIONS

When this option is loaded, this function can not be disabled.

The stop type of DCS Position and Speed Check functions is not affected by the loading of this option.

### 

The stopping distance and stopping time of Controlled stop are longer than the stopping distance and stopping time of Power-Off stop. A risk assessment for the whole robot system, which takes into consideration the increased stopping distance and stopping time, is necessary when this option is loaded.

# 8 WARNING & CAUTION LABEL

(1) Step-on prohibitive label



Fig.8 (a) Step-on prohibitive label

Description

Do not step on or climb the robot or controller as it may adversely affect the robot or controller and you may get hurt if you lose your footing.

(2) High-temperature warning label



Fig.8 (b) High-Temperature warning label

Description

Be cautious about a section where this label is affixed, as the section generates heat. If you must touch such a section when it is hot, use a protective provision such as heat-resistant gloves.

(3) High-voltage warning label




Fig.8 (c) High-voltage warning label

Description

A high voltage is applied to the places where this label is attached.

Before starting maintenance, turn the power to the controller off, and turn the circuit breaker off to avoid electric shock hazards. Take additional precautions with the servo amplifier and other equipment, because high-voltage remains in these units for a certain amounts of time

### PREFACE

This manual describes the following models (R-30*i*B/R-30*i*B Plus controller).

Model		Abbreviation
FANUC Robot R-2000iB/165F	R-2000 <i>i</i> B/165F	
FANUC Robot R-2000iB/210F	R-2000 <i>i</i> B/210F	
FANUC Robot R-2000iB/250F	R-2000 <i>i</i> B/250F	
FANUC Robot R-2000iB/125L	R-2000 <i>i</i> B/125L	
FANUC Robot R-2000iB/175L	R-2000 <i>i</i> B/175L	
FANUC Robot R-2000iB/185L	R-2000 <i>i</i> B/185L	
FANUC Robot R-2000iB/165R	R-2000 <i>i</i> B/165R	
FANUC Robot R-2000iB/200R	R-2000 <i>i</i> B/200R	
FANUC Robot R-2000iB/170CF	R-2000 <i>i</i> B/170CF	R-2000 <i>i</i> B
FANUC Robot R-2000iB/100P	R-2000 <i>i</i> B/100P	
FANUC Robot R-2000iB/100H	R-2000 <i>i</i> B/100H	
FANUC Robot R-2000iB/150U	R-2000 <i>i</i> B/150U	
FANUC Robot R-2000iB/200T	R-2000 <i>i</i> B/200T	
FANUC Robot R-2000iB/220U	R-2000 <i>i</i> B/220U	
FANUC Robot R-2000iB/210WE	R-2000 <i>i</i> B/210WE	
FANUC Robot R-2000iB/210FS	R-2000 <i>i</i> B/210FS	
FANUC Robot R-2000iB/220US	R-2000 <i>i</i> B/220US	
FANUC Robot R-2000iC/125L	R-2000 <i>i</i> C/125L	
FANUC Robot R-2000iC/165F	R-2000 <i>i</i> C/165F	
FANUC Robot R-2000iC/165R	R-2000 <i>i</i> C/165R	
FANUC Robot R-2000iC/210F	R-2000 <i>i</i> C/210F	R-2000 <i>i</i> C
FANUC Robot R-2000iC/210R	R-2000 <i>i</i> C/210R	
FANUC Robot R-2000iC/210L	R-2000 <i>i</i> C/210L	
FANUC Robot R-2000iC/270F	R-2000 <i>i</i> C/270F	
FANUC Robot R-1000iA/80F	R-1000 <i>i</i> A/80F	
FANUC Robot R-1000iA/100F	R-1000 <i>i</i> A/100F	R-1000 <i>i</i> A
FANUC Robot R-1000iA/80H	R-1000 <i>i</i> A/80H	
FANUC Robot R-1000iA/120F-7B	R-1000 <i>i</i> A/120F-7B	
FANUC Robot M-10 <i>i</i> A	M-10 <i>i</i> A	
FANUC Robot M-10 <i>i</i> A/6L	M-10 <i>i</i> A/6L	
FANUC Robot M-10 <i>i</i> A/7L	M-10 <i>i</i> A/7L	
FANUC Robot M-10 <i>i</i> A/8L	M-10 <i>i</i> A/8L	
FANUC Robot M-10iA/10S	M-10 <i>i</i> A/10S	M-10 <i>i</i> A
FANUC Robot M-10 <i>i</i> A/10M	M-10 <i>i</i> A/10M	
FANUC Robot M-10 <i>i</i> A/10MS	M-10 <i>i</i> A/10MS	
FANUC Robot M-10 <i>i</i> A/12	M-10 <i>i</i> A/12	
FANUC Robot M-10 <i>i</i> A/12S	M-10 <i>i</i> A/12S	
FANUC Robot M-20 <i>i</i> A	M-20 <i>i</i> A	
FANUC Robot M-20 <i>i</i> A/10L	M-20 <i>i</i> A/10L	
FANUC Robot M-20 <i>i</i> A/12L	M-20 <i>i</i> A/12L	
FANUC Robot M-20 <i>i</i> A/20T	M-20 <i>i</i> A/20T	M-20iA
FANUC Robot M-20iA/20M	M-20 <i>i</i> A/20M	
FANUC Robot M-20 <i>i</i> A/20MT	M-20 <i>i</i> A/20MT	
FANUC Robot M-20iA/35M	M-20 <i>i</i> A/35M	
FANUC Robot M-20 <i>i</i> A/35MT	M-20 <i>i</i> A/35MT	
FANUC Robot M-20 <i>i</i> B/25	M-20 <i>i</i> B/25	M-20 <i>i</i> B

Model		Abbreviation
FANUC Robot ARC Mate 100iC	ARC Mate 100 <i>i</i> C	
FANUC ROBOWELD 100 <i>i</i> C		
FANUC Robot ARC Mate 100Ic/6L	ARC Mate 100 <i>i</i> C/6L	
FANUC ROBOWELD 100 <i>i</i> C/6L		
FANUC Robot ARC Mate 100 <i>i</i> C /7L	ARC Mate 100 <i>i</i> C/7L	ARC Mate 100 <i>i</i> C
FANUC Robot ARC Mate 100 <i>i</i> C /8L	ARC Mate 100 <i>i</i> C/8L	
FANUC Robot ARC Mate 100 <i>i</i> C/10S	ARC Mate 100iC/10S	
FANUC Robot ARC Mate 100 <i>i</i> C/12	ARC Mate 100iC/12	
FANUC Robot ARC Mate 100 <i>i</i> C/12S	ARC Mate 100iC/12S	
FANUC Robot ARC Mate 120 <i>i</i> C	ARC Mate 120 <i>i</i> C	
FANUC ROBOWELD 120 <i>i</i> C		
FANUC Robot ARC Mate 120 <i>i</i> C/10L	ARC Mate 120 <i>i</i> C/10L	ARC Mate 120 <i>i</i> C
FANUC ROBOWELD 120 <i>i</i> C/10L		
FANUC Robot ARC Mate 120 <i>i</i> C/12L	ARC Mate 120 <i>i</i> C/12L	
FANUC Robot ARC Mate 120 <i>i</i> C/20T	ARC Mate 120 <i>i</i> C/20T	
FANUC Robot M-710 <i>i</i> C/70	M-710 <i>i</i> C/70	
FANUC Robot M-710 <i>i</i> C/70T	M-710 <i>i</i> C/70T	
FANUC Robot M-710 <i>i</i> C/50	M-710 <i>i</i> C/50	
FANUC Robot M-710 <i>i</i> C/50S	M-710 <i>i</i> C/50S	
FANUC Robot M-710 <i>i</i> C/50T	M-710 <i>i</i> C/50T	
FANUC Robot M-710 <i>i</i> C/50E	M-710 <i>i</i> C/50E	M-710 <i>i</i> C
FANUC Robot M-710 <i>i</i> C/50H	M-710 <i>i</i> C/50H	
FANUC Robot M-710 <i>i</i> C/45M	M-710 <i>i</i> C/45M	
FANUC Robot M-710 <i>i</i> C/20L	M-710 <i>i</i> C/20L	
FANUC Robot M-710 <i>i</i> C/20M	M-710 <i>i</i> C/20M	
FANUC Robot M-710 <i>i</i> C/12L	M-710 <i>i</i> C/12L	
FANUC Robot M-2iA/3S	M-2 <i>i</i> A/3S	
FANUC Robot M-2iA/3SL	M-2iA/3SL	
FANUC Robot M-2 <i>i</i> A/6H	M-2 <i>i</i> A/6H	—— M-2 <i>i</i> A
FANUC Robot M-2 <i>i</i> A/6HL	M-2iA/6HL	
FANUC Robot M-2iA/3A	M-2 <i>i</i> A/3A	
FANUC Robot M-2iA/3AL	M-2iA/3AL	
FANUC Robot M-3 <i>i</i> A/6A	M-3 <i>i</i> A/6A	
FANUC Robot M-3 <i>i</i> A/6S	M-3iA/6S	M-3iA
FANUC Robot M-3iA/12H	M-3 <i>i</i> A/12H	
FANUC Robot M-410 <i>i</i> B/140H	M-410 <i>i</i> B/140H	
FANUC Robot M-410 <i>i</i> B/160	M-410 <i>i</i> B/160	
FANUC Robot M-410 <i>i</i> B/300	M-410 <i>i</i> B/300	M-410 <i>i</i> B
FANUC Robot M-410 <i>i</i> B/450	M-410 <i>i</i> B/450	
FANUC Robot M-410 <i>i</i> B/700	M-410 <i>i</i> B/700	
FANUC Robot M-410 <i>i</i> C/185	M-410 <i>i</i> C/185	
FANUC Robot M-410 <i>i</i> C/315	M-410 <i>i</i> C/315	M-410 <i>i</i> C
FANUC Robot M-410 <i>i</i> C/500	M-410 <i>i</i> C/500	
FANUC Robot M-420 <i>i</i> A	M-420 <i>i</i> A	
FANUC Robot M-421 <i>i</i> A	M-421 <i>i</i> A	

Model		Abbreviation
FANUC Robot M-430 <i>i</i> A/2P	M-430iA/2P	
FANUC Robot M-430 <i>i</i> A/2PH	M-430 <i>i</i> A/2PH	M-430 <i>i</i> A
FANUC Robot M-430 <i>i</i> A/4FH	M-430 <i>i</i> A/4FH	
FANUC Robot M-900iA/260L	M-900iA/260L	
FANUC Robot M-900iA/350	M-900iA/350	
FANUC Robot M-900 <i>i</i> A/150P	M-900 <i>i</i> A/150P	M-900 <i>i</i> A
FANUC Robot M-900iA/200P	M-900iA/200P	W-900/A
FANUC Robot M-900 <i>i</i> A/400L	M-900iA/400L	
FANUC Robot M-900iA/600	M-900 <i>i</i> A/600	
FANUC Robot M-900 <i>i</i> B/280	M-900 <i>i</i> B/280	
FANUC Robot M-900 <i>i</i> B/360	M-900 <i>i</i> B/360	
FANUC Robot M-900 <i>i</i> B/700	M-900 <i>i</i> B/700	M-900 <i>i</i> B
FANUC Robot M-900 <i>i</i> B/400L	M-900 <i>i</i> B/400L	
FANUC Robot M-900 <i>i</i> B/280L	M-900iB/280L	
FANUC Robot M-2000iA/900L	M-2000iA/900L	
FANUC Robot M-2000iA/1200	M-2000iA/1200	M-2000 <i>i</i> A
FANUC Robot M-2000iA/1700L	M-2000iA/1700L	M-2000/A
FANUC Robot M-2000iA/2300	M-2000iA/2300	
FANUC Robot F-100 <i>i</i> A	F-100 <i>i</i> A	
FANUC Robot F-200 <i>i</i> B	F-200 <i>i</i> B	
FANUC Robot CR-35 <i>i</i> A	CR-35 <i>i</i> A	

# TABLE OF CONTENTS

SAF	ETY P	RECAUTIONS	<b>;-1</b>
PRE	FACE	p	<b>)-1</b>
I. N	IAINT	ENANCE	
1	OVER	VIEW	3
2	<b>CONF</b> 2.1 2.2 2.3	<b>IGURATION</b> EXTERNAL VIEW OF THE CONTROLLER COMPONENT FUNCTIONS CHECKS AND MAINTENANCE	4 9
3	-		
	3.1 3.2 3.3 3.4 3.5 3.6 3.7 3.7	POWER CANNOT BE TURNED ON         ALARM SCREEN         STOP SIGNALS         MASTERING         TROUBLESHOOTING USING THE ERROR CODE         FUSE-BASED TROUBLESHOOTING         TROUBLESHOOTING BASED ON LED INDICATIONS         3.7.1       Troubleshooting Using the LEDS on the Main Board         3.7.2       Troubleshooting by LEDs on Power Supply Unit.         3.7.3       Troubleshooting by LEDs on the Process I/O Board.         3.7.4       Troubleshooting by LEDs on the 6-Axis Servo Amplifier         3.7.5       Troubleshooting by LEDs on the caiPS         3.7.7       Troubleshooting by LEDs on the Sensor I/F Unit for CR-35iA         MANUAL OPERATION IMPOSSIBLE         LEDS ON UNITS SUPPORTING I/O LINK i         3.9.1       Meanings of LEDs on Units Supporting I/O Link i	12 16 19 20 22 74 80 80 80 80 85 87 91 93 94 95 95
4	<b>PRINT</b> 4.1	TED CIRCUIT BOARDS	<b>97</b> 97
	4.2 4.3 4.4 4.5 4.6 4.7 4.8 4.9	EMERGENCY STOP BOARD         A-cabinet:A20B-2200-0650/B-cabinet:A20B-2102-0050         BACKPLANE         PROCESS I/O BOARD JA (A16B-2204-0010)         PROCESS I/O BOARD JB (A16B-2204-0011)         PROCESS I/O BOARD MA (A20B-2004-0380, A20B-2004-0381)         PROCESS I/O BOARD MA (A20B-2004-0380, A20B-2004-0381)         PROCESS I/O BOARD MB (A20B-2101-0730, A20B-2101-0731)         PROCESS I/O BOARD KA (A20B-2101-0560)         1         PROCESS I/O BOARD KB (A20B-2101-0561)	01 01 02 04 07 09 10
5	<b>6-AXIS</b> 5.1 5.2	<b>S SERVO AMPLIFIERS1</b> LEDS OF 6-AXIS SERVO AMPLIFIER1 SETTING OF 6-AXIS SERVO AMPLIFIER	19

	5.3	6-AXIS SERVO AMPLIFIER SPECIFICATIONS	121
6	POW	ER SUPPLY	122
	6.1	BLOCK DIAGRAM OF THE POWER SUPPLY	122
	6.2	TRANSFORMER	124
	6.3	CHECKING THE POWER SUPPLY UNIT (A16B-2203-0910)	126
7	SENS	OR I/F UNIT FOR CR-35 <i>i</i> A	127
8	REPL	ACING UNITS	128
	8.1	REPLACING THE PRINTED-CIRCUIT BOARDS	
		8.1.1 Replacing the Backplane Board (Unit)	129
		8.1.2 Replacing the Power Unit and Printed-Circuit Boards on the Backplane	
	8.2	REPLACING CARDS AND MODULES ON THE MAIN BOARD	
	8.3	REPLACING THE E-STOP UNIT	
	8.4	REPLACING THE EMERGENCY STOP BOARD	
	8.5	REPLACING THE TRANSFORMER	
	8.6	REPLACING THE REGENERATIVE RESISTOR UNIT	
	8.7	REPLACING SERVO AMPLIFIERS	-
	8.8	REPLACING I/O UNIT-MODEL A	
		<ul><li>8.8.1 Replacing the Base Unit of I/O Unit-MODEL A</li><li>8.8.2 Replacing a Module</li></ul>	
	8.9	REPLACING THE TEACH PENDANT	
	8.10	REPLACING THE CONTROL SECTION FAN MOTOR	
	8.11 8.11	REPLACING THE AC FAN MOTOR	
	0.11	8.11.1 Replacing the Heat Exchanger and Door Fan Unit (A-cabinet)	
		8.11.2 Replacing Rear Fan Unit (A-cabinet)	
		8.11.3 Replacing External Fan Unit and Door Fan (B-cabinet)	
	8.12	REPLACING THE BATTERY	
		8.12.1 Battery for Memory Backup (3 VDC)	155
11.	CONN	ECTIONS	
1	OVEF	<b>VIEW</b>	159
2	BLOC	K DIAGRAM	160
3	<b>FI FC</b>	TRICAL CONNECTIONS	
U	3.1	CONNECTIONS BETWEEN THE CONTROLLER AND THE MECHAN	
	0.1	UNIT AND OTHER GENERAL CONTROLLER CONNECTIONS	
	3.2	CONNECTION TO FANUC I/O LINK AND FANUC I/O LINK i	
	0.2	3.2.1 Connection of I/O Link by Using JD1A Connector	
		3.2.1.1 Connection of the I/O Link cable by using JD1A connector	
		3.2.1.2 Cable connection diagram of the I/O Link cable when using	
		JD1A connector	
		3.2.2 Connection of I/O Link and I/O Link <i>i</i> when Using JRL8 Connector 3.2.2.1 Connection of the I/O Link cable when using JRL8 connector	
		3.2.2.1 Connection of the 1/0 Enk cable when using TKE's connector	
		JRL8 connector	
	3.3	EXTERNAL CABLE WIRING DIAGRAM	167

		3.3.2	Teach Pendant Cable	
		3.3.3	Connecting the Input Power	
			3.3.3.1 Connecting the input power cable	
			3.3.3.2 Leakage breaker	
			3.3.3.3 Check input voltage	
			3.3.3.4 ON/OFF timing by the breaker	
		3.3.4	Connecting the External Power Supply ON/OFF Switch	
		3.3.5	Connecting the External Emergency Stop	181
		3.3.6	Connecting the Non-Teaching Enabling (NTED) Signal	
			(CRMA96)(For B-cabinet)	
		3.3.7	Connecting the Auxiliary Axis Brake (CRR65 A/B)	
		3.3.8	Connecting the Auxiliary Axis Over Travel (CRM68)	191
4	PERI	PHER/	AL DEVICE, ARC WELDING, AND EE INTERFACES	192
	4.1	PERIF	PHERAL DEVICE INTERFACE BLOCK DIAGRAM	195
		4.1.1	When Process I/O Board JA/JB is Used (B-cabinet)	195
		4.1.2	When Process I/O Board MA is Used (A-cabinet)	
		4.1.3	When Process I/O Board MB is Used (A-cabinet)	
		4.1.4	When Process I/O Board KA/KB is Used (A-cabinet)	
		4.1.5	When I/O Unit-MODEL A is Used	
		1.1.0	4.1.5.1 In case of A-cabinet	
			4.1.5.2 In case of B-cabinet	
		4.1.6	When Two or More Process I/O Board and I/O Unit-MODEL A are Used	
			4.1.6.1 In case of B-cabinet	
	4.2		ESS I/O BOARD SIGNALS	
			RFACE FOR PERIPHERAL DEVICES	
	4.3			
		4.3.1	Peripheral Device and Controller Connection (Source Type DO)	
		4.3.2	Connection between the Process I/O Board MA and Peripheral Devices	
	4.4		RFACE FOR WELDER	
		4.4.1	Connection between the Process I/O Board MB and Welding Machines	
		4.4.2	Connection between the Process I/O Board KA, KB and Welding Machines	s222
	4.5	EE IN	TERFACE	225
		4.5.1	Connection between the Mechanical Unit and End Effector	225
	4.6	DIGIT	AL I/O SIGNAL SPECIFICATIONS	227
	1.0	4.6.1	Peripheral Device Interface A	
		4.6.2	EE Interface	
		4.6.3	I/O Signal Specifications for ARC-Welding Interface	
		4.0.5	(A-cabinet/Process I/O Board MB)	230
	4.7	SDEC	IFICATIONS OF THE CABLES USED FOR PERIPHERAL	
	4.7			000
			CES AND WELDERS	233
		4.7.1	Peripheral Device Interface A Cable	
			(CRMA5*: Honda Tsushin, 50 pins)	233
		4.7.2	Peripheral Device Interface B Cable	
			(CRMA6*: Honda Tsushin, 20 pins)	233
		4.7.3	Peripheral Device Interface B1 and B2 Cables	
			(CRMA52; TE Connectivity 30 pin)	234
		4.7.4	ARC Weld Connection Cables	
			(CRW11; TE Connectivity 20 pin)	234
	4.8	CABL	E CONNECTION FOR THE PERIPHERAL DEVICES, END	
	-		CTORS, AND ARC WELDERS	235
		4.8.1	Peripheral Device Connection Cable	
		4.8.2	Peripheral Device Connection Cable	
		4.8.3	End Effector Cable Connector (EE interface)	
		т.0.5	Life Effector Cable Connector (EE interface)	

		4.8.4	Recommended Cables	241
4	.9	CONN	IECTION OF HDI	
		4.9.1	Connecting HDI	
		4.9.2	Input Signal Rules for the High-speed Skip (HDI)	
4	1.10	CONN	IECTING THE COMMUNICATION UNIT	
		4.10.1	RS232C Interface	
			4.10.1.1 Interface	
			4.10.1.2 RS232C interface signals	
			4.10.1.3 Connection between RS232C interface and I/O device	
		4.10.2	Ethernet Interface	247
			4.10.2.1 Connection to Ethernet	
			4.10.2.2 Leading out the Ethernet Cable	
			4.10.2.3 100BASE-TX Connector (CD38A, CD38B) /	
			1000BASE-T Connector (CD38C) Pin Assignments	
			4.10.2.4 Twisted-pair Cable Specification	
			4.10.2.5 Electrical Noise Countermeasures	
			4.10.2.6 Check Items at Installation	
	1.11			050
4		CONN	IECTING THE SENSOR CONNECTION CABLE	
-				
٦	RAN	ISPOR	TATION AND INSTALLATION	259
<b>1</b> 5	<b>FRAN</b> 5.1	<b>ISPOR</b> TRAN	<b>TATION AND INSTALLATION</b>	<b>259</b> 259
<b>1</b> 5	RAN	<b>ISPOR</b> TRAN INSTA	<b>TATION AND INSTALLATION</b> SPORTATION	<b>259</b> 259 260
<b>1</b> 5	<b>FRAN</b> 5.1	ISPOR TRAN INSTA 5.2.1	<b>SPORTATION AND INSTALLATION</b> SPORTATION. ALLATION Installation Method.	<b>259</b> 259 260 260
<b>1</b> 5 5	<b>FRAN</b> 5.1 5.2	ISPOR TRAN INSTA 5.2.1 5.2.2	<b>SPORTATION AND INSTALLATION</b> SPORTATION. LLATION Installation Method. Assemble at Installation	<b>259</b> 259 260 260 266
<b>T</b> 5 5	<b>FRAN</b> 5.1 5.2 5.3	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA	RETATION AND INSTALLATION	<b>259</b> 259 260 260 266 267
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3 5.4	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS	<b>CTATION AND INSTALLATION</b> SPORTATION         ALLATION         Installation Method         Assemble at Installation         ALLATION CONDITION         STMENT AND CHECKS AT INSTALLATION	<b>259</b> 259 260 260 266 267
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS	RETATION AND INSTALLATION	<b>259</b> 259 260 260 266 267
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3 5.4	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS RESE	<b>CTATION AND INSTALLATION</b> SPORTATION         ALLATION         Installation Method         Assemble at Installation         ALLATION CONDITION         STMENT AND CHECKS AT INSTALLATION	<b>259</b> 259 260 260 260 266 267 269
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3 5.4	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS RESE	RTATION AND INSTALLATION	<b>259</b> 259 260 260 260 266 267 269 269
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3 5.4	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS RESE AT INS	<b>CALLATION AND INSTALLATION</b> SPORTATION         ALLATION         Installation Method         Assemble at Installation         ALLATION CONDITION         STMENT AND CHECKS AT INSTALLATION         TTING OVERTRAVEL AND EMERGENCY STOP         STALLATION         Peripheral Device Interface Processing	<b>259</b> 259 260 260 266 267 267 269 269 269 269
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3 5.4	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS RESE AT INS 5.5.1	TATION AND INSTALLATION SPORTATION LLATION Installation Method Assemble at Installation LLATION CONDITION STMENT AND CHECKS AT INSTALLATION TTING OVERTRAVEL AND EMERGENCY STOP STALLATION.	<b>259</b> 259 260 260 260 266 267 269 269 269 269 270 270
<b>T</b> 5 5 5	<b>FRAN</b> 5.1 5.2 5.3 5.4	ISPOR TRAN INSTA 5.2.1 5.2.2 INSTA ADJUS RESE AT INS 5.5.1 5.5.2	<b>RTATION AND INSTALLATION</b> SPORTATION         ALLATION         Installation Method         Assemble at Installation         ALLATION CONDITION         STMENT AND CHECKS AT INSTALLATION         TTING OVERTRAVEL AND EMERGENCY STOP         STALLATION         Peripheral Device Interface Processing         Resetting Overtravel	<b>259</b> 259 260 260 266 267 269 269 269 270 270 270

### **APPENDIX**

5

Α	SPEC	IFICA	TION LIST	275
В	ΤΟΤΑ		NECTION DIAGRAM	280
С	SPEC		TIONS OF PERIPHERAL DEVICE INTERFACE	335
	C.1	SIGNA	۸L	335
	C.2		NG COMMON VOLTAGE	
	C.3	I/O SIC	GNALS	337
		C.3.1	Input Signals	337
		C.3.2	Output Signals	
	C.4	SPECI	FICATIONS OF DIGITAL INPUT/OUTPUT	343
		C.4.1	Overview	
		C.4.2	Input/Output Hardware Usable in the R-30iB/R-30iB Plus Controller	343
		C.4.3	Software Specifications	344
D	OPTIC	CAL FI	BER CABLE	345
Е	BRAK	KE REL	_EASE UNIT	348

	E.1 E.2 E.3	SAFETY PRECAUTIONS CONFIRMATIONS BEFORE OPERATION OPERATION. E.3.1 In Case of Operating to the Robot. E.3.2 Releasing the Brake of an Auxiliary Axis	348 349 349
	E.4	HOW TO CONNECT THE PLUG TO THE POWER CABLE (IN CASE OF NO POWER PLUG)	
	E.5	DIMENSION	
	E.6	FUSE	
	E.7	SPECIFICATIONS	356
F		TO SECURE THE COMPACT FLASH MEMORY CARD	.357
G		CONTROLLER FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	
	G.1	CONFIGURATION	
	G.2	TROUBLESHOOTING USING THE ALARM CODE G.2.1 Troubleshooting Using the Alarm Code	
		G.2.2 Alarms Detected by Servo Amplifier	362
	G.3	G.2.3 Relationship of Axis INSTALLING THE CONNECTION CABLE BETWEEN CABINETS	
	G.4	ROBOT CONNECTION CABLE	
	G.5	CONNECTING THE INPUT POWER CABLE	368
	G.6	CONFIRMATIONS OF ON/OFF BY THE BREAKER FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	260
	G.7	TOTAL CONNECTION DIAGRAM	
Н	INSTR	RUCTION FOR STACKING A-CABINETS	
I		H PENDANT DISCONNECT FUNCTION (OPTION)	
	l.1 l.2	CONFIGURATION PROCEDURE OF TEACH PENDANT DISCONNECT	
	1.2	I.2.1       Teach Pendant Disconnect         I.2.2       Teach Pendant Connect	402
J	INSTR	RUCTION FOR TERMINAL BLOCK	.404
κ	-	ING OF THE CABLE ENTRANCE OF THE CABINET	
	К.1 К.2	CABLE ENTRANCE FOR A-CABINET HOLES OF CABLE SEAL BLOCK FOR CABLE	
	K.2 K.3	SUITABLE CABLE DIAMETER	
	K.4	ADJUST THE CABLE DIAMETER	
L	REPL	ACING THE PROTECTION SHEET	.409

# I. MAINTENANCE

# OVERVIEW

This manual is applied to the R-30*i*B/R-30*i*B Plus controller (called R-30*i*B/R-30*i*B Plus).

R-30iB/R-30iB Plus has different controller depending on the required standards.

NRTL controller:	To meet UL/CSA standard
CE controller:	To meet Machinery Directive, Low voltage Directive, EMC Directive to cover
	the requirement of CE mark
CE/NRTL controller:	To meet both CE standard and UL/CSA standard.

This manual covers these controllers of the R-30*i*B/R-30*i*B Plus.

The difference of NRTL, CE and CE/NRTL controller from the Basic controller is small as shown in Table 1 (ex. EMC parts, Breakers).

And the specific descriptions of the CE and NRTL controllers are noted in this manual.

	Functional safety	EMC Standard	Robot Standard Electrical Standard	Requirement	Difference
Basic controller		-	-	-	-
NRTL controller		-	UL1740 CAN/CSA Z434 NFPA79	UL standard CSA standard •USA and Canada	•UL listed main breaker •E-stop unit with UL listed breaker •600V input circuit for Canada
CE controller	ISO 13849-1 IEC 61508		EN/ISO 10218-1 EN 60204-1	CE Marking •Europe	Noise filter     EMC Cabinet     Shielded cable
CE/NRTL controller		EN 55011 EN 61000-6-2 EN 61000-6-4	UL1740 CAN/CSA Z434 NFPA79 EN/ISO 10218-1 EN 60204-1	CE Marking •Europe UL standard CSA standard •USA and Canada	<ul> <li>Noise filter</li> <li>EMC Cabinet</li> <li>Shielded cable</li> <li>UL listed main breaker</li> <li>E-stop unit with UL listed breaker</li> <li>600V input circuit for Canada can not be supported.</li> </ul>

Table 1. Applied standards

This manual describes the maintenance and connection of R-30iB/R-30iB Plus.

Maintenance Part:

•Connection Part:

Troubleshooting, and the setting, adjustment, and replacement of units Connection of R-30*i*B/R-30*i*B Plus to the robot mechanical unit and peripheral devices, and installation of the controller

### WARNING Before you enter the robot working area, be sure to turn off the power to the controller or press the EMERGENCY STOP button on the operator's panel or teach pendant. Otherwise, you could injure personnel or damage equipment.

# 2 CONFIGURATION


### 2.1 EXTERNAL VIEW OF THE CONTROLLER

The appearance and components might differ slightly depending on the controlled robot, application, and options used.


Fig.2.1 (a) shows an external view of two R-30*i*B/R-30*i*B Plus controller cabinet variations.

Fig.2.1 (b) to (g) show the construction of the R-30iB/R-30iB Plus controller.

Fig.2.1 (h) to (k) show the external view of the operator's panel and teach pendant.







B-83195EN/09

#### MAINTENANCE




Fig.2.1 (b) R-30*i*B/R-30*i*B Plus A-cabinet interior (Front)





Fig.2.1 (c) R-30*i*B/R-30*i*B Plus A-cabinet interior (Front) (CR-35*i*A)








Fig.2.1 (e) R-30*i*B/R-30*i*B Plus B-cabinet interior (Front)




Fig.2.1 (f) R-30*i*B/R-30*i*B Plus B-cabinet interior (Front) (M-900*i*A/400L, M-900*i*A/600, M-900*i*B/700, M-900*i*B/400L)





Fig.2.1 (g) R-30*i*B/R-30*i*B Plus B-cabinet interior (Rear)

### 2. CONFIGURATION






Fig.2.2 Block diagram of the R-30*i*B/R-30*i*B Plus

- Main board The main board contains a microprocessor, its peripheral circuits, memory, and operator's panel control circuit. The main CPU controls servo mechanism positioning.
   I/O printed circuit board, FANUC I/O Unit MODEL-A
- I/O printed circuit board, FANUC I/O Unit MODEL-A
   Various types of printed circuit boards are provided for applications including a process I/O board.
   The FANUC I/O unit MODEL-A can also be installed. When it is used, various I/O types can be selected. These are connected with FANUC I/O Link.
- E-stop unit

This unit controls the emergency stop system of the robot controller. It also has user interface terminals of safety relevant signals, external on/off signals etc.

- Power supply unit
- The power supply unit converts the AC power to various levels of DC power.
- Backplane printed circuit board
- The various control printed circuit boards are mounted on the backplane printed circuit board.
- Teach pendant All operations including robot programming are performed with this unit. The controller status and data are indicated on the liquid-crystal display (LCD) on the pendant.
- 6-Axis Servo amplifier The servo amplifier controls servomotor, Pulsecoder signal, brake control, overtravel and hand broken.
- Operator's panel

Buttons and LEDs on the operator's panel are used to start the robot and to indicate the robot status. The panel has an USB interface for the serial interface to an external device.

- Transformer
- The supply voltage is converted to an AC voltage required for the controller by the transformer.
- Fan unit, heat exchanger
  - These components cool the inside of the controller.
- Circuit breaker

If the electric system in the controller malfunctions, or if abnormal input power causes high current in the system, the input power is connected to the circuit breaker to protect the equipment.

- Regenerative resistor
  - To discharge the counter electromotive force from the servomotor, connect a regenerative resistor to the servo amplifier.

## 2.3 CHECKS AND MAINTENANCE

Daily maintenance and periodic maintenance/inspection ensure reliable robot performance for extended periods of time.

(1) Daily maintenance

Before operating the system each day, clean each part of the system and check the system parts for any damage or cracks. Also, check the following:

(a) Before operation

Check the cable connected to the teach pendant for excessive twisting. Check the controller and peripheral devices for abnormalities.

- (b) After operation At the end of operation, return the robot to the specified position, and then turn off the controller. Clean each part, and check for any damage or cracks. If the ventilation port of the controller is dusty, clean it.
- (2) Check after one month Check that the fan is rotating

Check that the fan is rotating normally. If the fan has dirt and dust built up, clean the fan according to step (d) described below for inspection to be performed every 6 months.

(3) Periodic inspection performed every six months

Please refer to the Section 7.5, and then remove any dirt and dust from the inside of the transformer compartment. Wipe off dirt and dust from the fan and transformer.

### (4) Battery daily check

Replace the battery on the front panel of the main board every 4 years. Please refer to the Section 7.12.

(5) Maintenance tools

The following maintenance tools are recommended:

(a) Measuring instruments

AC/DC voltmeter (A digital voltmeter is sometimes required.) Oscilloscope with a frequency range of 5 MHz or higher, two channels


(b) Tools

Cross-head screwdrivers: Straight-head screwdrivers: Nut driver set (Metric) Pliers Cutting pliers Diagonal cutting pliers Large, medium, and small Large, medium, and small

# **3** TROUBLESHOOTING

This chapter describes the checking method and corrective action for each alarm code indicated if a hardware alarm occurs. Refer to the OPERATOR'S MANUAL (ALARM CODE LIST) (B-83284EN-1) for a list of alarms.

## 3.1 POWER CANNOT BE TURNED ON



### 3. TROUBLESHOOTING

	Check and Corrective action	Figure
(Check 2)	Check whether the LED (ALM: red) on	
	the power supply unit is on.	DB1: Diode stack
(Corrective	If the LED (ALM:red) on the power	F1(8.0A): Fuse for AC input
action 1)	supply unit is off, see Check 3.	CP1: Connector for AC input CP1A: Connector for AC output
	If the LED (ALM:red) on the power	VS1: Surge absorber
	supply unit is on, verify that the +24V	
	external connection cable is not connected to 0V or ground.	H1: Auxiliary power module CP5: Connector for +24V F4(7.5A): Fuse for +24V PIL: LED (green) CP5: Connector for +24V
		CP6: Connector for +24E
	If the problem still exists even though it	ALM: LED (red)
	does not have ground fault, check the power supply unit using the following	CP4: Connector for control
	procedure:	
	a) Check Fuse F4.	
	If the fuse is blown, see	The second se
	Corrective action 4.	
	b) Fuse F4 is not blown.	
	The power supply unit, main board or process I/O printed circuit board	
	may be faulty.	
	c) Replace the power supply unit.	
	d) If a system using the process I/O	
	printed circuit board, replace the	
	process I/O printed circuit board.	
	e) See Corrective action 3.	
(Corrective	If the power supply unit is not faulty,	
action 2)	replace the emergency stop board.	
(Corrective	Before executing this action, perform a	
action 3)	complete controller back up to save all	
	your programs and settings.	
	If the emergency stop board is not	
	faulty, replace the Main board.	
(Corrective	Causes of blown fuse F4 and corrective	
action 4)	action.	
	The device connected to connector CP5 of the power supply unit may be faulty.	
	or the power supply unit may be faulty.	
	Find the cause by referencing the total	
	connection diagram presented in the	
	appendix.	
	If no dovice is connected to ODE or the	
	If no device is connected to CP5 or the connected device is normal, the +24 V	
	power used in a printed circuit board	
	connected to the backplane is faulty.	
	· · · · · · · · · · · · · · · · · · ·	
	See Corrective action 3.	

	Check and Corrective action	Figure
(Check 3)	Check whether the LED (PIL: green) on the power supply unit is on.	
(Corrective action1)	If the LED (PIL: green) is on, - See Corrective action 3. If the LED (PIL: green) is not on, 200 VAC is not supplied to the power supply unit. Check whether 200 VAC is	VS1: Surge absorber DB1: Diode stack F1(8.0A): Fuse for AC input CP1: Connector for AC output CP2, CP3: Connector for AC output F3(7.5A): Fuse for +24E
	supplied to power supply unit. Check the voltage between the 1 pin and 2 pin of the CP1 connector. If 200 VAC is not supplied, Check the	H1: Auxiliary power module F4(7.5A): Fuse for +24V PIL: LED (green) CP5: Connector for +24V CP6: Connector for +24E ALM: LED (red) CP4: Connector for control
	primary input voltage to the controller is within the rated voltage and phase of the primary input voltage is not lack. If there is no problem, the fuse in the transformer may have blown.	CP4: Connector for control
	Before you start to replace the transformer, turn off the circuit breaker. Replace the transformer.	
	If 200 VAC is supplied, It is likely that fuse F1 in the power supply unit has blown. Find the cause of the blown fuse.	
	<ul><li>Before you start troubleshooting, turn off the circuit breaker.</li><li>a) If fuse F1 has blown, see Corrective action 2.</li></ul>	
	<ul> <li>b) If fuse F1 has not blown, Replace the power supply unit.</li> </ul>	
(Corrective action 2)	<ul> <li>Causes of blown fuses F1 and corrective action</li> <li>a) Check the units (fans), printed-circuit board and cables connected to the CP2 and CP3 connectors of the power supply unit to see if there is any short circuit.</li> <li>b) Replace the power supply unit.</li> </ul>	

### 3. TROUBLESHOOTING

(Corrective action 3)       Check whether the connector (RS19 or RS20 on the emergency stop board. If the external ON/OFF and EXOFF11 signals are connected on the emergency stop board. If the external ON/OFF switch is functioning properly.         a)       If the external ON/OFF switch is functioning properly.         b)       If the external ON/OFF switch is not used, connect terminal EXOFF1 and EXOFF11.         b)       If the external ON/OFF switch is not used, connect terminal EXOFF1 and EXOFF1.         b)       If the external ON/OFF function is not used, connect terminal EXOFF1 and exorest         corrective action 5)       Check whether the jumper connector of the emergency stop board.         (Corrective action 5)       Check whether the jumper connector of the CRMA38 is connected to the emergency stop board.         (Corrective action 5)       Check whether the jumper connector of the CRMA38 is connected to the emergency stop board.	(	Check and Corrective action	Figure
action 3)       on the main board or the connector (JRS19 or JRS20) on the emergency. stop board is connected properly.         (Corrective action4)       Check whether the EXOFF1 and EXOFF11 singles are connected on the terminal block on the emergency stop board. If the external ON/OFF switch is functioning properly.         a)       If the external ON/OFF function is not used, connect terminal EXOFF1         b)       If the external ON And OFF lines are already used, check the mating contacts and the cable.         (Corrective action 5)       Check whether the jumper connector of action 5)         Check whether the jumper connector of action 5)       Check whether the jumper connector of action 5)         Max and the cable.       Kablent         (Corrective action 5)       Check whether the jumper connector of action 5)       Kablent			
(URS19 or JRS20) on the emergency top board. If the extend to NVOFF and EXOFF11 signals are connected on the terminal block on the emergency stop board. If the external ON/OFF switch is used, verify that the ON/OFF function is not used, connect terminal EXOFF1         a) If the external ON and OFF lines are already used, check the mating contacts and the cable.         (Corrective action 5)         (Corrective action 5)         Check whether the jumper connector of action 5)         (Corrective emergency stop board.			JRS20
(Corrective action4)       Stop board is connected properly. EXOFF11 signals are connected on the terminal block on the emergency stop board. If the external ON/OFF switch is used, verify that the ON/OFF switch is used, verify that the ON/OFF switch is used, connect terminal EXOFF1         a)       If the external ON/OFF function is not used, connect terminal EXOFF1         b)       If the external ON and OFF lines are already used, check the mating contacts and the cable.         (Corrective action 5)       Check whether the jumper connector of the CRMA93 is connected to the emergency stop board.         (Corrective action 5)       Check whether the jumper connector of the CRMA93 is connected to the emergency stop board.		(JRS19 or JRS20) on the emergency	
<ul> <li>action4) EXOFF11 signals are connected on the terminal block on the emergency stop board. If the external ON/OFF switch is used, verify that the ON/OFF switch is not used, connect terminal EXOFF1</li> <li>a) If the external ON and OFF function is not used, connect terminal EXOFF1</li> <li>b) If the external ON and OFF lines are already used, check the mating contacts and the cable.</li> <li>(Corrective Check whether the jumper connector of the CRMA93 is connected to the emergency stop board.</li> <li>(Corrective action 5)</li> </ul>			
action4) EXOFF11 signals are connected on the terminal block on the emergency stop board. If the external ON/OFF switch is used, verify that the ON/OFF switch is not used, connect terminal EXOFF1 a) If the external ON and OFF lines are already used, check the mating contacts and the cable. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the emergency stop board. (Corrective action 5) (Corrective action 5) Check whether the jumper connector of the emergency stop board. (Corrective action 5) (Corrective action 5) Check whether the jumper connector of the emergency stop board. (Corrective action 5) (Corrective action 5)			
board. If the external ON/OFF switch is used, verify that the ON/OFF switch is not used, connect terminal EXOFF1 a) If the external ON and OFF lines are already used, check the mating contacts and the cable. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Support of the CRMA93 is connected to the emergency stop board. (Corrective action 5)	action4)		
used, verify that the ON/OFF switch is functioning property. a) If the external ON/OFF function is not used, connect terminal EXOFF1 b) If the external ON and OFF lines are already used, check the mating contacts and the cable. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. <b>IDENTIFY IDENTIFY IDENTIFY</b> <			
functioning property. a) If the external ON/OFF function is not used, connect terminal EXOFF1 b) If the external ON and OFF lines are already used, check the mating contacts and the cable. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. <b>Corrective</b> Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. <b>IDENTIFY IDENTIFY IDENTIFY</b> <			
<ul> <li>a) If the external ON/OFF function is not used, connect terminal EXOFF1</li> <li>b) If the external ON and OFF lines are already used, check the mating contacts and the cable.</li> <li>(Corrective action 5)</li> <li>Check whether the jumper connector of the CRMA33 is connected to the emergency stop board.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts and the cable.</li> <li>(Corrective 1000 are already used, check the mating contacts ar</li></ul>			
<ul> <li>(a) If the external ON/OFP function is are already used, check the mating contacts and the cable.</li> <li>(Corrective action 5)</li> <li>(Corrective action 5)</li> <li>(Corrective emergency stop board.</li> </ul>		ranouorinig property.	
<pre>indused, connect terminal EXOFF1 and EXOFF11. b) If the external ON and OFF lines are already used, check the mating contacts and the cable. (Corrective action 5) (Corrective cmA833 is connected to the emergency stop board. (Corrective cmA83 is connected to the emergency stop board. ) (Corrective cmA83 (Corrective (Corrective (Corrective cma8 (Corrective (Correctiv</pre>		a) If the external ON/OFF function is	
and EXOFF11. b) If the external ON and OFF lines are already used, check the mating contacts and the cable. (Corrective action 5) (Corrective emergency stop board. (Corrective (Corrective emergency stop board. (Corrective (Corrective (Corrective (Corrective) (Corrective (Corrective) (C		,	
<ul> <li>b) If the external ON and OFF lines are already used, check the mating contacts and the cable.</li> <li>(Corrective action 5)</li> <li>Check whether the jumper connector of the CRMA93 is connected to the emergency stop board.</li> <li>TBOP14</li> <li>TBOP14</li></ul>			
b) If the external ON and OF Lines are already used, check the mating contacts and the cable.          (Corrective action 5)       Check whether the jumper connector of the CRMA93 is connected to the emergency stop board.       A-cab inet         Image: Stop End of the CRMA93 is connected to the emergency stop board.       Image: Stop End of the CRMA93 is connected to the emergency stop board.       Image: Stop End of the CRMA93 is connected to the emergency stop board.         Image: Stop End of the CRMA93 is connected to the emergency stop board.       Image: Stop End of the CRMA93 is connected to the emergency stop board.       Image: Stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the emergency stop End of the CRMA93 is connected to the CRMA93 is connecte			
(Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. (Corrective action 5) TBOP11 14 EXOFF1 14 EXOFF1 13 EXOFF1 (CRMA93 (CRMA9		b) If the external ON and OFF lines	
contacts and the cable.         (Corrective action 5)         Check whether the jumper connector of the CRMA93 is connected to the emergency stop board.         Image: state of the the cable intervalue in the cable intervalue interv		are already used, check the mating	
(Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hop</b>		contacts and the cable.	
(Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hop</b>			
(Corrective action 5) Check whether the jumper connector of the CRMA93 is connected to the emergency stop board. <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hophing</b> <b>Hop</b>			
Action 5) the CRMA93 is connected to the emergency stop board.	(Corrective	Check whether the jumper connector of	12:EXOFF11
emergency stop board.			A-cabinet
TBOP11 14:EXOFF11 13:EXOFF1 13:EXOFF1 CRMA93 CRMA	,	emergency stop board.	
TBOP11 14:EXOFF11 13:EXOFF1 13:EXOFF1 CRMA93 CRMA			
CRMA93 CRMA93			творіі
CRMA93 CRMA93			
I.3.EXOFF1			
I3:EXOFF1			
13:EXOFF1 14:EXOFF1 14:EXOFF1 14:EXOFF1 14:EXOFF1			JUSA JULA 77 JRS19
13:EXOFF1 13:EXOFF1 CRMA93			
			- 094433 CR127 CR536
IbbP10 give     give </td <td></td> <td></td> <td></td>			
			CP5A
			글 알붊했
B-cabinet			C64498
			B-cabinet

## 3.2 ALARM SCREEN

The alarm screen displays only the alarm conditions that are currently active. If an alarm reset signal is input to reset the alarm conditions, the alarm screen displays the message "PAUSE or more serious alarm has not occurred."

The alarm screen displays only the alarm conditions (if any) that occur after the most recently entered alarm reset signal. To erase all alarm displays from the alarm screen, press the CLEAR key (+ shift) on the alarm history screen.

The alarm screen is intended to display PAUSE or alarms that are more serious. It will not display WARN, NONE, or a reset. It is possible to disable PAUSE and some of the more serious alarms from being displayed by setting the \$ER\_NOHIS system variable appropriately.

If two or more alarms have occurred, the display begins with the most recent alarm.

Up to 100 lines can be displayed.

If an alarm has a cause code, it is displayed below the line indicating the alarm.




Fig.3.2 Alarm screen and alarm history screen display procedure


### Displaying the alarm history/alarm detail information

### Step

- (1) Press [MENU] key to display the screen menu.
- (2) Select [ALARM].

You will see a screen similar to the following.

If an alarm has occurred, however, the alarm screen appears automatically.



(3) To display the alarm history screen, press F3, [HIST]. Press F3 [ACTIVE] again, the alarm screen appears.

Alarm :	Hist
	1/25
1	INTP-224 (TEST1, 6) Jump label faile
2	RESET
3	SRVO-007 External emergency stop
4	SRVO-001 Operator panel E-stop
5	RESET
6	SRVO-001 Operator panel E-stop
7	SRVO-012 Power failure recovery
8	INTP-127 Power fail detected
9	SRVO-047 LVAL alarm (Group:1 Axis:5)
10	SRVO-047 LVAL alarm (Group:1 Axis:4)
11	SRVO-002 Teach pendant E-stop
[ TY	PE ] [ VIEW ] ACTIVE CLEAR DETAIL

### NOTE

The latest alarm is assigned number 1. To view messages that are currently not on the screen, press the F5, DETAIL, and then press the right arrow key.

(4) To display the alarm detail screen, press F5, [DETAIL].

MAINTENANCE


Ala	rm :	His	t					
	DET	AIL	A	larm				
	INT	P-22	24	(TEST1,	6) Jump	label fai	led	
	MEM	<b>D-0</b> 2	27	Specifi	ed line d	loes not e	exist	
	STO	P.L		21-NOV	7-11 12:16	5		
	Ala	rm :	: E	Hist				
	1	INT	P -	224 (TE	ST1, 6) J <sup>.</sup>	ump label	faile	
	2	RE	S	БЕТ		-		
	3	SRV	·o-	007 Ext	ernal eme	rgency st	ор	
	4	SRV	·0-	001 Ope	rator pan	el E-stop	-	
	5	RE	S	БЕТ				
	6	SRV	0-	001 Ope	rator pan	el E-stop		
	7	SRV	0-	012 Pow	er failur	e recover	У	
	[ TY:	ΡΕ ]	[	VIEW ]	ACTIVE	CLEAR	DETAIL	

- (5) To return to the alarm history screen, press the PREV key.
- (6) To delete all the alarm histories, press and hold down the SHIFT key, then press F4, [CLEAR].

#### NOTE

When system variable \$ER\_NOHIS = 1, NONE alarms or WARN alarms are not recorded. When \$ER\_NOHIS=2, resets are not recorded in the alarm history. When \$ER\_NOHIS=3, resets, WARN alarms, and NONE alarms are not recorded.

The following map indicates teach pendant operations used to check an alarm.



# **3.3** STOP SIGNALS

The stop signal screen indicates the state of signals related to stop.

To be specific, the screen indicates whether each stop signal is currently on. This screen is for viewing only and therefore you cannot change the state of any stop signal on this screen.

Table	3.3	Stop	sign	als

Stop signal	Description
Operator's panel	This item indicates the state of the emergency stop button on the operator's panel. If
emergency stop	the EMERGENCY STOP button is pressed, the state is indicated as "TRUE".
Teach pendant	This item indicates the state of the emergency stop button on the teach pendant. If the
emergency stop	EMERGENCY STOP button is pressed, the state is indicated as "TRUE".
External emergency stop	This item indicates the state of the external emergency stop signal. If the
	EMERGENCY STOP signal is asserted, the state is indicated as "TRUE".
Fence open	This item indicates the state of the safety fence. If the safety fence is open, the state is indicated as "TRUE".
DEADMAN switch	This item indicates whether the DEADMAN switch on the teach pendant is grasped
	correctly. If the teach pendant is operable, and the DEADMAN switch is grasped
	correctly, the state is indicated as "TRUE". If the DEADMAN switch is released or is
	grasped tightly when the teach pendant is operable, an alarm occurs, causing the
	servo power to be switched off.
Teach pendant operable	This item indicates whether the teach pendant is operable. If the teach pendant is
	operable, the state is indicated as "TRUE".
Hand broken	This item indicates the state of the hand safety joint. If the hand interferes with a
	workpiece or anything like this, and the safety joint is opened, the state is indicated as
	"TRUE". In this case, an alarm occurs, causing the servo power to be switched off.
Robot overtravel	This item indicates whether the current position of the robot is out of the operation
	range. If any robot axis goes out of the operation range beyond the overtravel switch,
	the state is indicated as "TRUE". In this case, an alarm occurs, causing the servo
	power to be switched off.
Abnormal air pressure	This item indicates the state of the air pressure. The abnormal air pressure signal is
	connected to the air pressure sensor. If the air pressure is not higher than the
	specified value, the state is indicated as "TRUE".

### Step

- (1) Press [MENU] key to display the screen menu.
- (2) Select STATUS on the next page.
- (3) Press F1, [TYPE] to display the screen switching menu.
- (4) Select Stop Signal. You will see a screen similar to the following.

STATUS Stop Signal					
SIGNAL NAME		STATUS	1/12		
1 SOP E-Stop:		FALSE			
2 TP E-STOP:		FALSE			
3 EXT E-STOP:		FALSE			
4 Fence Open:		FALSE			
5 TP Deadman:		TRUE			
6 TP Enable:		TRUE			
7 Hand Broken:	:	FALSE			
8 Overtravel:		FALSE			
9 Low Air Alam	rm:	FALSE			
10 Belt Broken	:	FALSE			
11 SVOFF Input	:	FALSE			
12 Non Teacher	Enb. Dev	.: FALSE			
[ TYPE ]					

### 3.4 MASTERING

Mastering is needed if:

- (1) The SRVO-062 BZAL or SRVO-038 pulse mismatch alarm occurs, or
- (2) The Pulsecoder is replaced.
- Item (1) requires quick mastering, while item (2) requires single axis or fixture position mastering.

The mastering procedure is described below. For details, refer to an applicable maintenance manual of mechanical unit or Mastering chapter of the Appendix B of the OPERATOR'S MANUAL (BASIC OPERATION) (B-83284EN).

### Condition

System variable \$MASTER\_ENB must be set to 1 or 2.

SYSTEM Variables	
272 \$MASTER_ENB	1

### Step

- (1) Press [MENU] key.
- (2) Select SYSTEM.
- (3) Press F1, TYPE.
- (4) Select Master/Cal you will see a screen similar to the following.
- (5) Move the robot by jog feed to the mastering position. Release the brake on the manual brake control screen if necessary.

SYSTEM Master/Cal
TORQUE = [ON]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
Press 'ENTER' or number key to select.
[ TYPE ] LOAD RES_PCA DONE

### NOTE Mastering cannot be performed until the axis is rotated enough to establish a pulse.

(6) Select "1 FIXTURE POSITION MASTER" and press the F4 key (yes). Mastering data is set.

SYST	EM Mast	er/Cal				
				TORQUE =	[ON]	
	1 FIX	TURE POSI	TION MAST	ER		
	2 ZER	O POSITIO	N MASTER			
	3 QUI	CK MASTER				
	4 QUI	CK MASTER	FOR SING	LE AXIS		
	5 SIN	GLE AXIS	MASTER			
	6 SET	QUICK MA	STER REF			
	7 CAL	IBRATE				
	Robot	Mastered	! Masteri	ng Data:		
	<-3	105333> <	-13216881:	> <2299528	30>	
	<-1	354153> <	0> <0>			
[	TYPE ]	LOAD	RES_PCA		DONE	

(7) Select "7 CALIBRATE" and press the F4 key (yes). Calibration is performed. Alternatively, to perform positioning, turn the power off, and then turn it on again. Calibration is performed whenever the power is turned on.

SYSTEM	Master	:/Cal				
				TORQUE =	[ON ]	
1	. FIXTU	RE POSIT	TION MAST	ER		
2	ZERO	POSITION	N MASTER			
3	QUICK	MASTER				
4	QUICK	MASTER	FOR SING	LE AXIS		
5	SINGL	E AXIS N	ASTER			
6	SET Q	UICK MAS	STER REF			
7	CALIB	RATE				
R	lobot C	alibrate	ed! Cur J	nt Ang(de	g):	
	< 0	.0000> <	< 24.6528	3> < -94.2	2241>	
	< 0	.0000> <	< -85.775	9> < 0.0	<0000	
[ TY	YPE ]	LOAD	RES_PCA		DONE	

- (8) Press F5 "DONE", after mastering.
- (9) Restore the brake condition to its original condition.


### **3.5** TROUBLESHOOTING USING THE ERROR CODE


### SRVO-001 Operator panel E-stop


(Explanation)	The emergency stop button on the operator's panel was pressed.
(Action 1)	Release the emergency stop button pressed on the operator's panel.
(Action 2)	Check the wires connecting between the emergency stop button and the emergency stop board (CRT27) for continuity. If an open wire is found, replace the entire
	harness.
(Action 3)	Check the wires connecting the teach pendant to the emergency stop board (CRS36)
	for continuity. If an open wire is found, replace the entire harness.
(Action 4)	With the emergency stop in the released position, check for continuity across the
	terminals of the switch. If continuity is not found, the emergency stop button is
	broken. Replace the emergency stop button or the operator's panel.
(Action 5)	Replace the teach pendant.
(Action 6)	Replace the emergency stop board.
Before execut	ing the (Action 7), perform a complete controller back-up to save all your programs
and settings.	
(Action 7)	Replace the main board.

#### NOTE

If SRVO-001 is issued together with SRVO-213, a fuse may have blown. Take the same actions as for SRVO-213.







(Emergency stop board/A-cabinet) (Emergency stop board/B-cabinet) Fig.3.5 (a) SRVO-001 Operator panel E-stop


MAINTENANCE

### SRVO-002 Teach pendant E-stop

- (Explanation) The emergency stop button on the teach pendant was pressed.
- (Action 1) Release the emergency stop button on the teach pendant.
- (Action 2) Replace the teach pendant.

### SRVO-003 DEADMAN switch released

- (Explanation) The teach pendant is enabled, but the DEADMAN switch is not pressed. Alternatively, the DEADMAN switch is grasped strongly.
- (Action 1) Check the intermediate position of the DEADMAN switch on the teach pendant.
- (Action 2) Check that the mode switch on the operator's panel and the enable/disable switch on the teach pendant are at the correct positions.
- (Action 3) Replace the teach pendant.
- (Action 4) Check the mode switch connection and operation. If trouble is found, replace the mode switch.
- (Action 5) Replace the emergency stop board.



(A-cabinet) (B-cabinet) Fig.3.5 (b) SRVO-002 Teach pendant E-stop / SRVO-003 DEADMAN switch released


### SRVO-004 Fence open

(Explanation)	In the automatic operation mode, the safety fence contact connected to EAS1-EAS11
	or EAS2-EAS21 of TBOP13(A-cabinet) or TBOP11(B-cabinet) is open.
(Action 1)	When a safety fence is connected, close the safety fence.
(Action 2)	Check the cables and switches connected between EAS1 and EAS11 and between
	EAS2 and EAS21 of the terminal block TBOP13(A-cabinet) or TBOP11(B-cabinet)
	on the emergency stop board.


- (Action 3) If the safety fence signal is not used, make a connection between EAS1 and EAS11 and between EAS2 and EAS21 of the terminal block TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board.
- (Action 4) Check the mode switch. If trouble is found, replace the mode switch.
- (Action 5) Replace the emergency stop board.


### NOTE

If SRVO-004 is issued together with SRVO-213, a fuse may have blown. Take the same actions as for SRVO-213.



(Emergency stop board/A-cabinet)





(Mode switch) Fig.3.5 (c) SRV0-004 Fence open

### 🕂 WARNING

(Action 1)

(Action 6)

In a system using the safety fence signal, it is very dangerous to disable the signal when a connection is made between EAS1 and EAS11 and between EAS2 and EAS21. Never make such an attempt. If a temporary connection is needed for operation, separate safety measures must be taken.

### SRVO-005 Robot overtravel

(Explanation) The robot has moved beyond a hardware limit switch on the axes.

- 1) Select [System OT release] on the overtravel release screen to release each robot axis from the overtravel state.
  - 2) Hold down the shift key, and press the alarm release button to reset the alarm condition.
  - 3) Still hold down the shift key, and jog to bring all axes into the movable range.
- (Action 2) Replace the limit switch.
- (Action 3) Check the FS2 fuse on the 6-axis servo amplifier. If the SRVO-214 fuse blown alarm is also generated, the fuse (FS2) has blown.
- (Action 4) Check the EE connector.
- (Action 5) Replace the 6-axis servo amplifier.
  - Verify the following for connector RP1 at the base of the robot:
    - 1) There are no bent or dislocated pins in the male or female connectors.
    - 2) The connector is securely connected.

Then verify that connectors CRF8 and CRM68 on the 6-axis servo amplifier are securely connected. Also, verify that the robot connection cable (RMP1) is in good condition, and there are no cuts or kinks visible. Check the internal cable of the robot for a short circuit or connection to ground.

### NOTE

It is factory-placed in the overtravel state for packing purposes. If the Overtravel signal is not in use, it may have been disabled by short-circuiting in the mechanical unit.

#### SRVO-006 Hand broken


(Explanation) The safety joint (if in use) might have been broken. Alternatively, the HBK signal on the robot connection cable might be a ground fault or a cable disconnection.


- (Action 1) Hold down the shift key, and press the alarm release button to reset the alarm condition. While still holding down the shift key, jog the tool to the work area.
  - 1) Replace the hand broken device.
  - 2) Check the hand broken cable.
- (Action 2) Replace the 6-axis servo amplifier.(Action 3) Verify the following for connector 1
  - Verify the following for connector RP1 at the base of the robot:
    - 1) There are no bent or dislocated pins in the male or female connectors.
    - 2) The connector is securely connected.

Then verify that connectors CRF8 and CRM68 on the 6-axis servo amplifier are securely connected. Also, verify that the robot connection cable (RMP1) is in good condition, and there are no cuts or kinks visible. Check the internal cable of the robot for a short circuit or connection to ground.

#### NOTE


If the Hand broken signal is not in use, it can be disabled by software setting. Refer to Subsection 5.5.3 in CONNECTIONS to disable the Hand broken signal.





(A-cabinet)

(B-cabinet)



(Servo amplifier)

Fig.3.5 (d) SRVO-005 Robot overtravel SRVO-006 Hand broken

#### SRVO-007 External emergency stops

- (Explanation) On the terminal block, TBOP13(A-cabinet) or TBOP11(B-cabinet) of the emergency stop board, no connection of external emergency stop is made between EES1 and EES11, EES2 and EES21.
   (Action 1) If an external emergency stop switch is connected, release the switch.
- (Action 2) Check the switch and cable connected to EES1-EES11 and EES2-EES21 on TBOP13(A-cabinet) or TBOP11(B-cabinet).
- (Action 3) When this signal is not used, make a connection between EES1 and EES11, EES2 and EES21.
- (Action 4) Replace the emergency stop board.

#### NOTE

If SRVO-007 is issued together with SRVO-213, a fuse may have blown. Take the same actions as for SRVO-213.




Fig.3.5 (e) SRVO-007 External-emergency stops

# 

In a system using the external emergency stop signal, it is very dangerous to disable the signal when a connection is made between EES1 and EES11 and between EES2 and EES21. Never make such an attempt. If a temporary connection is needed for operation, separate safety measures must be taken.


#### SRVO-009 Pneumatic pressure alarm


- (Explanation) Abnormal air pressure was detected. The input signal is located on the EE interface of the robot. Refer to the manual specific to your robot model.
- (Action 1) If an abnormal air pressure is detected, check the cause.
- (Action 2) Check the EE connector.
- (Action 3) Check the robot connection cable (RP1) and the mechanical unit cable of the robot for a ground fault or a cable disconnection. If a fault or a disconnection is detected, replace the cable.
- (Action 4) Replace the 6-axis servo amplifier.
- (Action 5) Replace the internal cables of the robot.

#### NOTE

Pneumatic pressure alarm input is on the EE interface of robot. Please refer to the manual of your robot.

Fig.3.5 (f) SRVO-009 Pneumatic pressure alarm








(B-cabinet)

#### SRVO-014 Fan motor abnormal (n), CPU STOP

- (Explanation) When a fan motor stops on the backplane, the TP shows the following message. One minute from the occurrence of the alarm, the robot stops and cannot be operated from the TP. The robot can be recovered by replacing the faulty fan motor. The number in the bracket indicates which fan is abnormal.
  - (1): fan above the slot1
  - (2): fan above slot2
  - (3): both fans
- (Action 1) Check the fan motor and its cables. Replace them if necessary.
- (Action 2) Replace the backplane.

Before executing the (Action 3), perform a complete controller back up to save all your programs and settings.

(Action 3) Replace the main board.






#### SRVO-015 System over heat

- (Explanation) The temperature in the controller exceeds the specified value. In one minutes from occurring of alarm, robot stops and cannot be operated from TP.
- (Action 1) If the ambient temperature is higher than specified (45°C), cool down the ambient temperature.
- (Action 2) If the fan motor is not running, check it and its cables. Replace them if necessary.

Before executing the (Action 3), perform a complete controller backup to save all your programs and settings.

(Action 3) Replace the main board. (The thermostat on the main board may be faulty.)

**NOTE** The controller will stop operation after 1 minutes of this alarm.



(B-cabinet) Fig.3.5 (h) SRVO-015 System over heat

#### SRVO-018 Brake abnormal (Group: i Axis: j)

- (Explanation) An excessive brake current is detected. The ALM LED on the 6-axis servo amplifier is lit.
- (Action 1) Check the robot connection cable (RM1,RMP) and the internal cable of the robot and motor brakes connected to CRR88 connector on the 6-axis servo amplifier. If a short-circuit or grounding fault is found, replace the failed part.
- (Action 2) Check the cables and motor brakes connected to CRR65A, CRR65B connector on the 6-axis servo amplifier. If a short-circuit or grounding fault is found, replace the failed part.
- (Action 3) Replace the 6-axis servo amplifier.

# 

This error can be caused by the optional brake release unit if the on/off switch is left in on position while the operator attempts to jog the robot. To recover, turn the brake release unit off and cycle the controller power.

#### SRVO-021 SRDY off (Group: i Axis: j)

- (Explanation) The HRDY is on and the SRDY is off, although there is no other cause of an alarm. (HRDY is a signal with which the host detects the servo system whether to turn on or off the servo amplifier magnetic contactor. SRDY is a signal with which the servo system informs the host whether the magnetic contactor is turned on.) If the servo amplifier magnetic contactor cannot be turned on when directed so, it is most likely that a servo amplifier alarm has occurred. If a servo amplifier alarm has been detected, the host will not issue this alarm (SRDY off). Therefore, this alarm indicates that the magnetic contactor cannot be turned on for an unknown reason. (Action 1) Make sure that the emergency stop board connectors CRRA8(A-cabinet) or CP2A(B-cabinet), CRMA92, CNMC5(A-cabinet), or CNMC7(B-cabinet), and CRMA91(6-axis amplifier) are securely attached to the servo amplifier. In case of using aux. axis amplifier, make sure that the connectors CXA2A (6-axis amplifier) or CXA2B (aux. axis amplifier) are securely attached to the servo amplifier. (Action 2) It is possible that a momentary power loss occurred due to an intermittent connection.
- (Action 3) Check related cables. Replace the E-stop unit.
- (Action 4) Replace the E-stop unit.

# SRVO-022 SRDY on (Group: i Axis: j)

- (Explanation) When the HRDY is about to go on, the SRDY is already on. (HRDY is a signal with which the host directs the servo system whether to turn on or off the servo amplifier magnetic contactor. SRDY is a signal with which the servo system informs the host whether the magnetic contactor is turned on.)
- (Action 1) Replace the servo amplifier with the alarm message.

#### SRVO-023 Stop error excess (G:i A:j)

(Explanation) When the servo is at stop, the position error is abnormally large.

Check whether the brake is released through the clack sound of the brake or vibration.

In case the brake is not released.

- (Action 1) If the brake is not released, check the continuity of the brake line in the robot connection cable and the mechanical unit cable.
- (Action 2) If a cable disconnection is not found, replace the 6-axis servo amplifier or the servo motor.

In case the brake is released.

- (Action 1) Check whether an obstacle inhibits robot motion.
- (Action 2) Make sure that connectors CNJ1A-CNJ6 are securely attached to the 6-axis servo amplifier.
- (Action 3) Check the continuity of the robot connection cable and the internal robot power cable.
- (Action 4) Check to see if the payload is greater than the rating. If greater, reduce it to within the rating. (If the load is too great, the torque required for acceleration / deceleration becomes higher than the capacity of the motor.

As a result, the motor becomes unable to follow the command signal, and an alarm is issued.)


(Action 5) Check that the input voltage to the controller is within the rated voltage and no phase is missing. And check that the setting of the transformer is correct.


Check each phase of the voltage feeding the CRR38A or CRR38B connector of the three-phase power (200 VAC) input to the 6-axis servo amplifier. If it is 210 VAC or lower, check the line voltage. (If the voltage input to the servo amplifier becomes low, the torque output also becomes low. As a result, the motor may become unable to follow the command, hence possibly causing an alarm.).

- (Action 6) Replace the servo amplifier.
- (Action 7) Replace the motor of the alarm axis.

# NOTE

Incorrect setting of the brake number causes this alarm.





(A-cabinet)

(B-cabinet)

Fig.3.5 (i) SRVO-018 Brake abnormal SRVO-021 SRDY off SRVO-022 SRDY on SRVO-023 Stop error excess

#### SRVO-024 Move error excess (G:i A:j)

- (Explanation) When the robot is running, its position error is greater than a specified value (\$PARAM \_ GROUP. \$MOVER \_ OFFST). It is likely that the robot cannot follow the speed specified by program.
- (Action 1) Take the same actions as SRVO-023.

#### SRVO-027 Robot not mastered (Group: i)

- (Explanation) An attempt was made to calibrate the robot, but the necessary mastering had not been completed.
- (Action) Check whether the mastering is valid. If the mastering is invalid, master the robot.

#### 

If the position data is incorrect, the robot or additional axis can operate abnormally, set the position data correctly. Otherwise, you could injure personnel or damage equipment.

#### SRVO-030 Brake on hold (Group: i)

- (Explanation) If the temporary halt alarm function is enabled (\$SCR.\$BRKHOLD ENB=1), SRVO-030 is issued when a temporary halt occurs. When this function is not used, disable the setting.
- (Action) Disable [Servo-off in temporary halt] on the general item setting screen [6 General Setting Items].

#### SRVO-033 Robot not calibrated (Group: i)

- (Explanation) An attempt was made to set up a reference point for quick mastering, but the robot had not been calibrated.
- (Action) Calibrate the robot.
  - 1. Supply power.
    - 2. Set up a quick mastering reference point using [Positioning] on the SYSTEM Master/Cal menu.

#### SRVO-034 Ref pos not set (Group: i)

(Explanation) An attempt was made to perform quick mastering, but the reference point had not been set up.

(Action) Set up a quick mastering reference point on the SYSTEM Master/Cal menu.

#### SRVO-036 Inpos time over (G:i A:j)

- (Explanation) The robot did not get to the effective area (\$PARAM \_ GROUP.\$ STOPTOL) even after the position check monitoring time (\$PARAM \_ GROUP. \$INPOS \_ TIME) elapsed.
- (Action) Take the same actions as for SRVO-023 (large position error at a stop).

#### SRVO-037 IMSTP input (Group: i)

(Explanation) The \*IMSTP signal for a peripheral device interface was input.

(Action) Turn on the \*IMSTP signal.

#### SRVO-038 Pulse mismatch (Group: i Axis: j)

(Explanation) The pulse count obtained when power is turned off does not match the pulse count obtained when power is applied. This alarm is asserted after replacing the Pulsecoder, or after replacing the battery used to back up Pulsecoder data, or after loading back up data to the Main Board.

Check the alarm history.

- (Action 1) If the brake number is set to non-brake motors, this alarm may occur. Check the software setting of the brake number.
- (Action 2) In case the robot has been moved by using the brake release unit while the power is off or when restoring the back-up data to the main board, this alarm may occur. Remaster the robot.
- (Action 3) If the robot moved because the brake failed, this alarm may occur. Check the cause of the brake trouble. Then remaster the robot.
- (Action 4) Replace the Pulsecoder and master the robot.

#### SRVO-043 DCAL alarm (Group: i Axis: j)

- (Explanation) The regenerative discharge energy was too high to be dissipated as heat. (To run the robot, the servo amplifier supplies energy to the robot. When going down the vertical axis, the robot operates from the potential energy. If a reduction in the potential energy is higher than the energy needed for acceleration, the servo amplifier receives energy from the motor. A similar phenomenon occurs even when no gravity is applied, for example, at deceleration on a horizontal axis. The energy that the servo amplifier receives from the motor is called the regenerative energy. The servo amplifier dissipates this energy as heat. If the regenerative energy is higher than the energy dissipated as heat, the difference is stored in the servo amplifier, causing an alarm.)
- (Action 1) This alarm may occur if the axis is subjected to frequent acceleration/deceleration or if the axis is vertical and generates a large amount of regenerative energy. If this alarm has occurred, relax the service conditions.
- (Action 2) Check fuse FS3 in the 6-axis servo amplifier. If it has blown, remove the cause, and replace the fuse. One of the probable causes of a blown fuse is a ground fault in the servo amplifier for the auxiliary axis.
- (Action 3) The ambient temperature is excessively high. Or the regenerative resistor can't be cooled effectively. Check the external fan unit, and replace it if it stops. Clean up the fun unit, the regenerative resistor and the louver if they are dirty.
- (Action 4) Make sure that the 6-axis servo amplifier CRR63A and CRR63B connectors are connected tightly. Then detach the cable from CRR63A and CRR63B connectors on the Servo amplifier, and check for continuity between pins 1 and 2 of the cable-end connector. If there is no continuity between the pins, replace the regenerative resistor.
- (Action 5) Make sure that the 6-axis servo amplifier CRRA11A and CRRA11B are connected tightly, then detach the cables from CRRA11A and CRRA11B on the servo amplifier and check the resistance between pins 1 and 3 of each cable end connector. If the resistance is not  $6.5\Omega$ , replace the regenerative resistor. CRRA11B may not be used depending on the robot model.
- (Action 6) Replace the 6-axis servo amplifier.

#### SRVO-044 DCHVAL%s alarm (G:i A:j)

- (Explanation) The DC voltage (DC link voltage) of the main circuit power supply is abnormally high.
- (Action 1) Check that the input voltage to the controller is within the rated voltage. And check that the setting of the transformer is correct.
- (Action 2) Check the three-phase input voltage at the 6-Axis servo amplifier. If it is 240 VAC or higher, check the line voltage. (If the three-phase input voltage is higher than 240 VAC, high acceleration/deceleration can cause in this alarm.)
- (Action 3) Check that the load weight is within the rating. If it is higher than the rating, reduce it to within the rating. (If the machine load is higher than the rating, the accumulation of regenerative energy might result in the HVAL alarm even when the three-phase input voltage is within the rating.)
- (Action 4) Make sure that the 6-Axis servo amplifier CRRA11A and CRRA11B are connected tightly, then detach the cables from CRRA11A and CRRA11B on the servo amplifier and check the resistance between pins 1 and 3 of each cable end connector. If the resistance is not  $6.5\Omega$ , replace the regenerative resistor. CRRA11B may not be used depending on the robot model.
- (Action 5) Replace the 6-Axis servo amplifier.
- (Action 6) Replace the Power Supply( $\alpha i PS$ ).

# SRVO-045 HCAL alarm (Group: i Axis: j)


- (Explanation) Abnormally high current was detected in the main circuit of the servo amplifier.
- (Action 1) Turn off the power, and disconnect the power cable from the 6-Axis servo amplifier indicated by the alarm message. (And disconnect the brake cable (CRR88 on the servo amplifier) to avoid the axis falling unexpectedly.) Supply power and see if the alarm occurs again. If the alarm occurs again, replace the servo amplifier.
- (Action 2) Turn off the power and disconnect the power cable from the servo amplifier indicated by the alarm message, and check the insulation by measuring between U, V, or W and the GND line. If there is a short-circuit, replace the power cable.
- (Action 3) Turn off the power and disconnect the power cable from the servo amplifier by the alarm message, and measure the resistance between their U and V, V and W and U with an ohmmeter that has a very low resistance range. If the resistances at the three places are different from each other, either the motor or the power cable is defective. Check each item in detail and replace it if necessary.


# SRVO-046 OVC alarm (Group: i Axis: j)

- (Explanation) This alarm is issued to prevent the motor from sustaining thermal damage that might occur when the root mean square current, calculated within the servo system, is out of the allowable range.
- (Action 1) Check the operating condition for the robot and relax the service condition if possible. If the load or operating condition has exceeded the rating, reduce the load or relax the operating condition to meet the rating.
- (Action 2) Check whether the voltage input to the controller is within the rated voltage and also check whether the voltage set for the transformer of the controller is correct.
- (Action 3) Check whether the brake of the corresponding axis is released.
- (Action 4) Check whether there is a factor that has increased the mechanical load on the corresponding axis.
- (Action 5) Replace the servo amplifier.
- (Action 6) Replace the motor of the corresponding axis.
- (Action 7) Replace the E-stop unit
- (Action 8) Replace the motor power line (robot connection cable) of the corresponding axis.
- (Action 9) Replace the motor power line and brake line (internal cable of the robot) of the corresponding axis.


# 3. TROUBLESHOOTING


MAINTENANCE





Regenerative resistor





# B-83195EN/09

#### Reference

Relationships among the OVC, OHAL, and HC alarms

#### - Overview

This section points out the differences among the OVC, OHAL, and HC alarms and describes the purpose of each alarm.

#### - Alarm detection section

Abbreviation	Designation	Detection section
OVC	Overcurrent alarm	Servo software
OHAL	Overheat alarm	Thermal relay in the motor
		Thermal relay in the servo amplifier
		Thermal relay in the separate regenerative resister
HC	High current alarm	Servo amplifier

# - Purpose of each alarm

- HC alarm (high current alarm)
   If high current flows in a power transistor momentarily due to abnormality or noise in the control circuit, the power transistor and rectifier diodes might be damaged, or the magnet of the motor might be degaussed. The HC alarm is intended to prevent such failures.
- 2) OVC and OHAL alarms (overcurrent and overload alarms)

The OVC and OHAL alarms are intended to prevent overheat that may lead to the burnout of the motor winding, the breakdown of the servo amplifier transistor, and the burnout of the separate regenerative resistor.

The OHAL alarm occurs when each built-in thermal relay detects a temperature higher than the rated value. However, this method does not perfectly prevent these failures. For example, if the motor frequently starts and stops, the thermal time constant of the motor, which has a large mass, becomes higher than the time constant of the thermal relay, because these two components are different in material, structure, and dimension. Therefore, if the motor continues to start and stop within a short time as shown in Fig. 3.5 (k), the temperature rise in the motor is steeper than that in the thermal relay, thus causing the motor to burn before the thermal relay detects an abnormally high temperature.




Fig.3.5 (k) Relationship between the temperatures of the motor and thermal relay on start/stop cycles

To prevent the above defects, software is used to monitor the current in the motor constantly in order to estimate the temperature of the motor. The OVC alarm is issued based on this estimated temperature. This method estimates the motor temperature with substantial accuracy, so it can prevent the failures described above.

# 3. TROUBLESHOOTING

To sum up, a double protection method is used; the OVC alarm is used for protection from a short-time overcurrent, and the OHAL alarm is used for protection from long-term overload. The relationship between the OVC and OHAL alarms is shown in Fig.3.5 (1).




Fig.3.5 (I) Relationship between the OVC and OHAL alarms


#### NOTE


The relationship shown in Fig.3.5 (I) is taken into consideration for the OVC alarm. The motor might not be hot even if the OVC alarm has occurred. In this case, do not change the parameters to relax protection.

# SRVO-047 LVAL alarm (Group: i Axis: j)

(Explanation) The control power supply voltage (+5 V, etc.) supplied from the power supply circuit in the servo amplifier is abnormally low.

- (Action 1) Replace the servo amplifier.
- (Action 2) Replace the power supply unit.





(A-cabinet)

Fig.3.5 (m) SRVO-047 LVAL alarm

(B-cabinet)

#### SRVO-049 OHAL1 alarm (G: i A: j)

(Explanation) The thermostat in the transformer activated.

- (Action 1) Check whether the fan is stopped and also check whether the vent is clogged. If necessary, clean or replace them.
- (Action 2) If SRVO-049 is issued when the robot operating condition is severe, check the robot operating condition then relax the condition when possible.
- (Action 3) Check that a connection is made between the transformer connector CPOH and the servo amplifier CRMA91.
- (Action 4) Check whether no phase occurs.
- (Action 5) Replace the E-stop unit.
- (Action 6) Replace the servo amplifier.
- (Action 7) Replace the transformer.


#### SRVO-050 Collision Detect alarm (Grp:i Ax:j)

(Explanation) The disturbance torque estimated by the servo software is abnormally high. (A collision has been detected.)


- (Action 1) Check whether the robot has collided and also check whether there is a factor that has increased the mechanical load on the corresponding axis.
- (Action 2) Check whether the load settings are valid.
- (Action 3) Check whether the brake of the corresponding axis is released.
- (Action 4) If the load weight exceeds the rated range, decrease it to within the limit.
- (Action 5) Check whether the voltage input to the controller is within the rated voltage and also check whether the voltage set for the transformer of the controller is correct.
- (Action 6) Replace the servo amplifier.
- (Action 7) Replace the motor of the corresponding axis.
- (Action 8) Replace the E-stop unit.
- (Action 9) Replace the motor power line (robot connection cable) of the corresponding axis.
- (Action 10) Replace the motor power line and brake line (internal cable of the robot) of the corresponding axis.

# SRVO-051 CUER alarm (Group: i Axis: j)

(Explanation) The offset of the current feedback value is abnormally high.(Action) Replace the servo amplifier.



(A- cabinet)



(B-cabinet)

Fig.3.5 (n) SRVO-049 OHAL1 alarm SRVO-050 Collision Detect alarm SRVO-051 CUER alarm

# SRVO-055 FSSB com error 1 (G: i A: j)

(Explanation) A communication error has occurred between the main board and servo amplifier.

- (Action 1) Check the optical fiber cable between the axis control card on the main board and servo amplifier. Replace it if it is faulty.
- (Action 2) Replace the axis control card on the main board.
- (Action 3) Replace the servo amplifier.

# SRVO-056 FSSB com error 2 (G: i A: j)

- (Explanation) A communication error has occurred between the main board and servo amplifier. (Action 1) Check the optical fiber cable between the axis control card on the main board and
- servo amplifier. Replace it if it is faulty.
- (Action 2) Replace the axis control card on the main board.
- (Action 3) Replace the servo amplifier.

# SRVO-057 FSSB disconnect (G:i A: j)

(Explanation) Communication was interrupted between the main board and servo amplifier.

- (Action 1) Check whether fuse (F4) in the power supply unit has blown. If the fuse has blown, check and correct the cause then replace the fuse.
- (Action 2) Check whether fuse (FS1) in the 6-Axis servo amplifier has blown. If the fuse has blown, replace the 6-Axis servo amplifier including the fuse.
- (Action 3) Check the optical fiber cable between the axis control card on the main board and servo amplifier. Replace it if it is faulty.
- (Action 4) Replace the axis control card on the main board.
- (Action 5) Replace the servo amplifier.
- (Action 6) Check that the robot connection cable (RP1) is in good condition, and there are no cuts or kinks visible. Check the internal cable of the robot (Pulsecoder cable) for a short circuit or connection to ground.

Before continuing to the next step, perform a complete controller back up to save all your programs and settings.

(Action 7) Replace the main board.

# SRVO-058 FSSB init error (yy)

(Explanation) Communication was interrupted between the main board and servo amplifier.

- (Action 1) Check whether fuse (F4) in the power supply unit has blown. If the fuse has blown, check and correct the cause, then replace the fuse.
- (Action 2) Check whether fuse (FS1) on the 6-Axis servo amplifier has blown. If the fuse has blown, replace the servo amplifier including the fuse.
- (Action 3) Turn off the power and disconnect the CRF8 connector on the 6-Axis servo amplifier. Then check whether this alarm occurs again. (Ignore the alarm SRVO-068 because of disconnecting the CRF8 connector.)


If this alarm does not occur, the robot connection cable (RP1) or the internal cable of the robot (Pulsecoder cable) may be short-circuited to ground. Check the cables and replace it if necessary.

#### 3. TROUBLESHOOTING

- (Action 4) Check whether the LED (P5V and P3.3V) on the 6-Axis servo amplifier is lit. If they are not lit, the DC power is not supplied to the servo amplifier. Make sure the connector CP5 on the power supply unit and the connector CXA2B on the 6-Axis servo amplifier are connected tightly. If they are connected tightly, replace the 6-Axis servo amplifier.
  (Action 5) Check the optical fiber cable between the axis control card on the main board and servo amplifier. Replace it if it is faulty.
- (Action 6) Replace the axis control card on the main board.
- (Action 7) Replace the 6-Axis servo amplifier.
- (Action 8) If the other units (the servo amplifier for the auxiliary axis and the line tracking board) are connected in the FSSB optical communication, disconnect these units and connect only 6-Axis servo amplifier for the robot. Then turn on the power. If this alarm does not occur, search the failed unit and replace it.

Before executing the (Action9), perform a complete controller back up to save all your programs and settings.





SRVO-058 FSSB init error

MAINTENANCE

#### SRVO-059 Servo amp init error

(Explanation) Servo amplifier initialization is failed.

- (Action 1) Check the optical fiber cable between the axis control card on the main board and servo amplifier. Replace it if it is faulty.
- (Action 2) Turn off the power and disconnect the CRF8 connector on the 6-Axis servo amplifier. Then check whether this alarm occurs again. (Ignore the alarm SRVO-068 because of disconnecting the CRF8 connector.)

If this alarm does not occur, the robot connection cable (RP1) or the internal cable of the robot (Pulsecoder cable) may be short-circuited to the ground. Check the cables and replace it if necessary.

(Action 3) Check whether the LED (P5V and P3.3V) on the 6-Axis servo amplifier is lit. If they are not lit, the DC power is not supplied to the servo amplifier.

Make sure the connector CP5 on the power supply unit and the connector CXA2B on the 6-Axis servo amplifier are connected tightly. If they are connected tightly, replace the 6-Axis servo amplifier.

- (Action 4) Replace the servo amplifier.
- (Action 5) Replace the line tracking board (If installed).
- (Action 6) Replace the Pulsecoder.

# SRVO-062 BZAL alarm (Group: i Axis: j)

(Explanation) This alarm occurs if battery voltage for Pulsecoder absolute-position backup cannot be detected.

A probable cause is a broken battery cable or no batteries in the robot.

- (Action 1) Replace the battery in the battery box of the robot base.
- (Action 2) Replace the Pulsecoder with which an alarm has been issued.
- (Action 3) Check whether the mechanical unit cable for feeding power from the battery to the Pulsecoder is disconnected or grounded. If an abnormality is found, replace the cable.

#### 

After correcting the cause of this alarm, set the system variable (\$MCR.\$SPC\_RESET) to TRUE, then turn on the power again. Mastering is needed.

#### SRVO-064 PHAL alarm (Group: i Axis: j)

(Explanation) This alarm occurs if the phase of the pulses generated in the Pulsecoder is abnormal.(Action) Replace the Pulsecoder with which an alarm has been issued.

#### NOTE

This alarm might accompany the DTERR, CRCERR, or STBERR alarm. In this case, however, there may be no actual condition for this alarm.

#### SRVO-065 BLAL alarm (Group: i Axis: j)

(Explanation) The battery voltage for the Pulsecoder is lower than the rating.

(Action) Replace the battery.

(If this alarm occurs, turn on the power and replace the battery as soon as possible. A delay in battery replacement may result in the BZAL alarm being detected. In this case, the position data will be lost. Once the position data is lost, mastering will become necessary.)

# SRVO-067 OHAL2 alarm (Grp:i Ax:j)

(Explanation) The temperature inside the Pulsecoder or motor is abnormally high, and the built-in thermostat has operated.

#### **3. TROUBLESHOOTING**

MAINTENANCE

- (Action 1) Check the robot operating conditions. If a condition such as the duty cycle and load weight has exceeded the rating, relax the robot load condition to meet the allowable range.
- (Action 2) When power is supplied to the motor after it has become sufficiently cool, if the alarm still occurs, replace the motor.

# SRVO-068 DTERR alarm (Grp:i Ax:j)

(Explanation) The serial Pulsecoder does not return serial data in response to a request signal.

- (Action 1) Make sure that the robot connection cable (RP1) connector (CRF8) of 6-Axis servo amplifier and the connector (motor side) are connected tightly.
- (Action 2) Check that the shielding of the robot connection cable (RP1) is grounded securely in the cabinet.
- (Action 3) Replace the Pulsecoder.
- (Action 4) Replace the servo amplifier.
- (Action 5) Replace the robot connection cable (RM1, RP1).
- (Action 6) Replace the internal cable of the robot (for the Pulsecoder, motor cable).


# SRVO-069 CRCERR alarm (Grp:i Ax:j)


(Explanation) The serial data has disturbed during communication.

(Action) See actions on SRVO-068

# SRVO-070 STBERR alarm (Grp:i Ax:j)

(Explanation) The start and stop bits of the serial data are abnormal.(Action) See actions on SRVO-068





(A-cabinet)

(B-cabinet)

Fig.3.5 (p) SRVO-059 Servo amp init error SRVO-070 STBERR alarm

# SRVO-071 SPHAL alarm (Grp:i Ax:j)

(Explanation) The feedback speed is abnormally high. (Action) Action as same as the SRVO-068.

#### NOTE

If this alarm occurs together with the PHAL alarm (SRVO-064), this alarm does not correspond to the major cause of the failure.

#### SRVO-072 PMAL alarm (Group: i Axis: j)

(Explanation) It is likely that the Pulsecoder is abnormal.

(Action) Replace the Pulsecoder and remaster the robot.

#### SRVO-073 CMAL alarm (Group: i Axis: j)

- (Explanation) It is likely that the Pulsecoder is abnormal or the Pulsecoder has malfunctioned due to noise.
- (Action 1) Check whether the connection of the controller earth is good. Check the earth cable connection between controller and robot connection cables are connected securely to the grounding plate.
- (Action 2) Reinforce the earth of the motor flange. (In case of Auxiliary axis)
- (Action 3) Reset the Pulse count.
- (Action 4) Replace the Pulsecoder.
- (Action 5) Replace the robot connection cable (RM1, RP1).
- (Action 6) Replace the internal cable of the robot (for the Pulsecoder, motor cable).

# SRVO-074 LDAL alarm (Group: i Axis: j)

(Explanation) The LED in the Pulsecoder is broken.

(Action) Replace the Pulsecoder, and remaster the robot.

#### SRVO-075 Pulse not established (G: i A: j)


(Explanation) The absolute position of the Pulsecoder cannot be established.(Action) Reset the alarm, and jog the axis on which the alarm has occurred until the same alarm will not occur again.


# SRVO-076 Tip Stick Detection (G: i A: j)

(Explanation) An excessive disturbance was assumed in servo software at the start of operation. (An abnormal load was detected. The cause may be welding.)

- (Action 1) Check whether the robot has collided. Or check whether the machinery load of the corresponding axis is increased.
- (Action 2) Check whether the load settings are valid.
- (Action 3) Check whether the brake of the corresponding axis is released.
- (Action 4) Check whether the load weight is within the rated range. If the weight exceeds the upper limit, decrease it to the limit.
- (Action 5) Check whether the voltage input to the controller is within the rated voltage and also check whether the voltage set for the transformer of the controller is correct.
- (Action 6) Replace the servo amplifier.
- (Action 7) Replace the corresponding servo motor.
- (Action 8) Replace the E-stop unit.
- (Action 9) Replace the power cable of the robot connection cable in which the corresponding axis is connected.
- (Action 10) Replace the internal cable of the robot (power/brake) in which the corresponding axis is connected.

E-Stop unit





(B-cabinet)

#### (A-cabinet)

Fig.3.5 (q) SRVO-076 Tip Stick Detection

# SRVO-081 EROFL alarm (Track enc: i)

(Explanation) The pulse counter for line tracking has overflowed.

- (Action 1) Check whether the condition of the line tracking exceeds the limitation.
- (Action 2) Replace the Pulsecoder.
- (Action 3) Replace the line tracking board.

# SRVO-082 DAL alarm (Track encoder: i)

(Explanation) The line tracking Pulsecoder has not been connected.

- (Action 1) Check the connection cable at each end (the line tracking board and the motor side)
- (Action 2) Check whether the shielding of the connection cable is connected securely to the grounding plate.
- (Action 3) Replace the line tracking cable.
- (Action 4) Replace the Pulsecoder.
- (Action 5) Replace the line tracking board.

# SRVO-084 BZAL alarm (Track enc: i)

(Explanation) This alarm occurs if the backup battery for the absolute position of the Pulsecoder has not been connected. See the description about the BZAL alarm (SRVO-062).

# SRVO-087 BLAL alarm (Track enc: i)

(Explanation) This alarm occurs if the voltage of the backup battery for the absolute position of the Pulsecoder is low. See the description about the BLAL alarm (SRVO-065).

# SRVO-089 OHAL2 alarm (Track enc: i)

(Explanation) The motor has overheated. When power is supplied to the Pulsecoder after it has become sufficiently cool, if the alarm still occurs. See the description about the OHAL2 alarm (SRVO-067).

#### SRVO-090 DTERR alarm (Track enc: i)

- (Explanation) Communication between the Pulsecoder and line tracking board is abnormal. See the SRVO-068 DTERR alarm.
- (Action 1) Check the connection cable at each end (the line tracking board and the Pulsecoder)
- (Action 2) Check whether the shielding of the connection cable is connected securely to the grounding plate.
- (Action 3) Replace the Pulsecoder.
- (Action 4) Replace the line tracking cable.
- (Action 5) Replace the line tracking board.

#### SRVO-091 CRCERR alarm (Track enc: i)

(Explanation) Communication between the Pulsecoder and line tracking board is abnormal. (Action) Action as same as the SRVO-090.

#### SRVO-092 STBERR alarm (Track enc: i)

(Explanation) Communication between the Pulsecoder and line tracking board is abnormal. (Action) Action as same as the SRVO-090.

#### SRVO-093 SPHAL alarm (Track enc: i)

(Explanation) This alarm occurs if the current position data from the Pulsecoder is higher than the previous position data.

(Action) Action as same as the SRVO-090.

#### SRVO-094 PMAL alarm (Track enc: i)

(Explanation) It is likely that the Pulsecoder is abnormal.(Action) Replace the Pulsecoder.

#### SRVO-095 CMAL alarm (Track enc: i)

(Explanation) It is likely that the Pulsecoder is abnormal or the Pulsecoder has malfunctioned due to noise. See the description about the CMAL alarm (SRVO-073).

- (Action 1) Reinforce the earth of the flange of the Pulsecoder.
- (Action 2) Reset the Pulse count.
- (Action 3) Replace the Pulsecoder.

#### SRVO-096 LDAL alarm (Track enc: i)

(Explanation) The LED in the Pulsecoder is broken. See the description about the LDAL alarm (SRVO-074).

#### SRVO-097 Pulse not established (Enc: i)

- (Explanation) The absolute position of the Pulsecoder cannot be established. See the description about (SRVO-075). Pulse not established.
- (Action 1) Reset the alarm, and jog the axis on which the alarm has occurred until the same alarm does not occur again. (Jog one motor revolution)


#### SRVO-105 Door open or E-Stop

(Explanation) The cabinet door is open.

- When the door switch is not mounted skip Action 1 and 2 and start from Action 3

- (Action 1) When the door is open, close it.
- (Action 2) Check the door switch and door switch connection cable. If the switch or cable is faulty, replace it.
- (Action 3) Check that the CRMA92, CRMA94(A-cabinet), CRMA74(B-cabinet) connectors on the E-STOP unit and CRMA91 on the servo amplifier are connected securely.
- (Action 4) Replace the emergency stop board.
- (Action 5) Replace the 6-Axis servo amplifier.

E-Stop unit






Fig.3.5 (r) SRVO-105 Door open or E-stop

# SRVO-123 Fan motor rev slow down (i)

(A-cabinet)


(Explanation) The rotation speed of fan motor is slow down.

(Action 1) Check the fan motor and its cables. Replace them if necessary.

(Action 2) Replace the backplane unit.

Before executing the (Action 3), perform a complete controller back up to save all your programs and settings.

(Action 3) Replace the main board.



# SRVO-130 OHAL1(PS) alarm (G: i A: j)

- (Explanation) Heat sink temperature of the main circuit of the Power Supply( $\alpha i$ PS) is abnormally high.
- (Action 1) Check the rotation of the cooling fan of the Power Supply( $\alpha i PS$ ).
- (Action 2) Decrease the duty cycle of operation. (Decrease override)
- (Action 3) Replace the Power Supply( $\alpha i PS$ ).

# SRVO-131 LVAL%s alarm (G: i A: j)

- (Explanation) Control supply voltage in the Power Supply( $\alpha iPS$ ) is abnormally low.
- (Action 1) Replace the Power Supply( $\alpha i PS$ ).
- (Action 2) Replace the servo amplifier.
- (Action 3) Replace the Power Supply Unit.

#### SRVO-133 FSAL(PS) alarm (G: i A: j)

(Explanation) The cooling fan for the Control circuit of the Power Supply( $\alpha i PS$ ) stopped.

- (Action 1) Check the status of the cooling fan. And replace it if it was abnormal.
- (Action 2) Replace the Power Supply( $\alpha i PS$ ).

[Regenarative resistor]

# SRVO-134 DCLVAL alarm (G: i A: j)

[Power supply regeneration]

#### SRVO-134 DCLVAL(PS) alarm (G: i A: j)

(Explanation) The DC voltage (DC link voltage) of the main circuit power supply for the servo amplifier is abnormally low.

- (Action 1) It is possible that an instant disconnection of power source causes this alarm. Check whether an instant disconnection occurred.
- (Action 2) Check the input voltage to the controller is within the rated voltage. And check the setting of the transformer is correct.
- (Action 3) Modify the program in order that robot and the auxiliary axis do not accelerate simultaneously in the system with the auxiliary axis.
- (Action 4) Replace the E-stop unit.
- (Action 5) Replace the servo amplifier(6-Axis amplifier).
- (Action 6) Replace the Power Supply( $\alpha i PS$ ).

# SRVO-136 DCLVAL alarm (G: i A: j)

(Explanation) The DC voltage (DC link voltage) of the main circuit power supply for the servo amplifier( $\alpha i$ SV) is abnormally low.

- (Action 1) Check the wiring of the servo amplifier ( $\alpha i$ SV).
- (Action 2) Replace the servo amplifier ( $\alpha i$ SV) that is indicated by the alarm message.

#### SRVO-156 IPMAL alarm (G: i A: j)


(Explanation) Abnormally high current flowed through the main circuit of the servo amplifier.


- (Action 1) Turn off the power, and disconnect the power cable from the servo amplifier indicated by the alarm message. (And disconnect the brake cable (CRR88 on the servo amplifier) to avoid the axis falling unexpectedly.) Turn on the power, and if the alarm occurs again, replace the servo amplifier.
- (Action 2) Turn off the power and disconnect the power cable from the servo amplifier indicated by the alarm message, and check the insulation of their U, V, W and the GND lines each other. If there is a short-circuit, replace the power cable.
- (Action 3) Turn off the power and disconnect the power cable from the servo amplifier by the alarm message, and measure the resistance between their U and V, V and W and W and U with an ohmmeter that has a very low resistance range. If the resistances at the three places are different from each other, the motor, the power cable is defective. Check each item in detail and replace it if necessary.

# SRVO-157 CHGAL alarm (G: i A: j)

(Explanation) The capacitor on the servo amplifier was not charged properly within the specified time when the servo power is on.

- (Action 1) Check the input voltage to the controller is within the rated voltage and phase is not lack. And check the setting of the transformer is correct.
- (Action 2) Check that the circuit breaker of the E-Stop unit is on and has not tripped.
- (Action 3) Make sure that the servo amplifier CRRA12 and emergency stop board CRRA12 connector are connected tightly. If  $\alpha i PS$  is used, make sure that the  $\alpha i PS$  CRRA12 connector is connected tightly.
- (Action 4) Replace the E-stop unit.
- (Action 5) Replace the 6-Axis servo amplifier.
- (Action 6) Replace the  $\alpha i$ PS.





(B-cabinet)


(A-cabinet)

Fig.3.5 (t) SRVO-136 DCLVAL alarm SRVO-156 IPMAL alarm SRVO-157 CHGAL alarm

#### SRVO-204 External (SVEMG abnormal) E-stop


- (Explanation) The switch connected across EES1 EES11 and EES2 EES21 on the TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board was pressed, but the EMERGENCY STOP line was not disconnected.
- (Action 1) Check the switch and cable connected to EES1 EES11 and EES2 EES21 on the TBOP13(A-cabinet) or TBOP11(B-cabinet). If the cable is abnormal, replace it.
- (Action 2) Replace the emergency stop board.
- (Action 3) Replace the 6-Axis servo amplifier.

Emergency stop board (E-Stop unit)



(A-cabinet)

Servo amplifier




(B-cabinet)


ž**e**lje

 $\oplus$ 

⊕



(A-cabinet/Emergency stop board)




(B-cabinet/Emergency stop board)

Fig.3.5 (u) SRVO-204 External (SVEMG abnormal) E-stop


#### SRVO-205 Fence open (SVEMG abnormal)

- (Explanation) The switch connected across EAS1 EAS11 and EAS2 EAS21 on the TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board was opened, but the EMERGENCY STOP line was not disconnected.
- (Action 1) Check the switch and cable connected to EAS1 EAS11 and EAS2 EAS21. If the cable is abnormal, replace it.
- (Action 2) Replace the emergency stop board.
- (Action 3) Replace the 6-Axis servo amplifier.

Emergency stop board (E-Stop unit)



(A-cabinet)





Emergency stop board (E-Stop unit)

 $\oplus$ 

(B-cabinet)

⊕





(Emergency stop board/A-cabinet)

(Emergency stop board/B-cabinet)


Fig.3.5 (v) SRVO-205 Fence open (SVEMG abnormal)


#### SRVO-206 Deadman switch (SVEMG abnormal)

(Explanation) When the teach pendant was enabled, the DEADMAN switch was released or pressed strongly, but the emergency stop line was not disconnected.

- (Action 1) Replace the teach pendant.
- (Action 2) Check the teach pendant cable. If it is inferior, replace the cable.
- (Action 3) Replace the emergency stop board.
- (Action 4) When the NTED signal is used, check whether the cabling of the signal connected to the emergency stop board is correct.
- (Action 5) Replace the 6-Axis servo amplifier.

Emergency stop board (E-Stop unit)





#### (A-cabinet)

(B-cabinet)

Fig.3.5 (w) SRVO-206 DEADMAN switch (SVEMG abnormal)

# SRVO-213 E-STOP Board FUSE2 blown

- (Explanation) A fuse (FUSE2) on the emergency stop board has blown, or no voltage is supplied to EXT24V.
- (Action 1) Check whether the fuse (FUSE2) on the emergency stop board has blown. If the fuse has blown, 24EXT may be short-circuited to 0EXT. Take Action 2. If fuse (FUSE2) has not blown, take Action 3 and up.
- (Action 2) Disconnect the connection destinations of 24EXT that can cause grounding then check that the fuse (FUSE2) does not blow. Disconnect the following on the emergency stop board then turn on the power:
  - CRS36
  - CRT27

- TBOP13(A-cabinet) or TBOP11(B-cabinet) : EES1, EES11, EAS1, EAS11, EGS1, EGS11

If the fuse (FUSE2) does not blow in this state, 24EXT and 0EXT may be short-circuited at any of the connection destinations above. Isolate the faulty location then take action.


If the fuse (FUSE2) blows even when the connection destinations above are detached, replace the emergency stop board.

(Action 3) Check whether 24 V is applied to between EXT24V and EXT0V of TBOP14(A-cabinet), TBOP10(B-cabinet). If not, check the external power supply circuit.


If no external power supply is used, check whether the terminals above are connected to the INT24V and INT0V terminals, respectively.

- (Action 4) Replace emergency stop board .
- (Action 5) Replace the teach pendant cable.


- (Action 6) Replace the teach pendant.
- (Action 7) Replace the operator's panel cable(CRT27).



(Emergency stop board/A-cabinet)



#### (Emergency stop board/B-cabinet)



(B-cabinet)



Fig.3.5 (x) SRVO-213 E-STOP Board FUSE2 blown

#### SRVO-214 6ch amplifier fuse blown (R: i)

(Explanation) A fuse (FS2 or FS3) in the 6-Axis servo amplifier has blown.

(Action 1) A fuse is blown, eliminate the cause, and then replace the fuse. (See Section 3.6)

(Action 2) Replace the 6-Axis servo amplifier.

# SRVO-216 OVC (total) (Robot: i)

(Explanation) The current (total current for six axes) flowing through the motor is too large.

- (Action 1) Slow the motion of the robot where possible. Check the robot operation conditions. If the robot is used with a condition exceeding the duty or load weight robot rating, reduce the load condition value to the specification range.
- (Action 2) Check the input voltage to the controller is within the rated voltage and no phase is lack. And check the setting of the transformer is correct.
- (Action 3) Replace the 6-Axis servo amplifier.

# SRVO-217 E-STOP Board not found

(Explanation) The emergency stop board is not found when the controller power is turned on.

- (Action 1) Check whether fuse (FUSE1) on the emergency stop board has blown. If the fuse has blown, check and correct the cause then replace the fuse.
- (Action 2) Check the cable between emergency stop board and main board. Replace them if necessary.

(Action 3) Replace the E-STOP unit.

Before executing the (Action 4), perform a complete controller back-up to save all your programs and settings.

(Action 4) Replace the main board.

# SRVO-221 Lack of DSP (G: i A: j)

(Explanation) A controlled axis card corresponding to the set number of axes is not mounted.

- (Action 1) Check whether the set number of axes is valid. If the number is invalid, set the correct number.
- (Action 2) Replace the axis control card with a card corresponding to the set number of axes.

#### SRVO-223 DSP dry run (a,b)

- (Explanation) A servo DSP initialization failure occurred due to hardware failure or wrong software setting. Then, the software entered DSP dry run mode. The first number indicates the cause of the failure. The second number is extra information.
- (Action) Perform an action according to the first number that is displayed in the alarm message.

1: This is a warning due to \$scr.\$startup\_cnd=12.

2,3,4,7: Replace a servo card.

5: Invalid ATR setting. Software axis config (FSSB line number, hardware start axis number, amplifier number, and amplifier type) might be wrong.

6: SRVO-180 occurs simultaneously. Controllable axis does not exist on any group. Execute aux axis setting to add axis at controlled start.

8,10: SRVO-058 (FSSB init error) occurs simultaneously. Follow the remedy of SRVO-058.

9: There is no amplifier that is connected to the servo card.

- •Check the hardware connection.
- •Check the optical fiber cable.
- •In case of using aux. axis amplifier, make sure that the connectors CXA2A (6-axis


amplifier) or CXA2B (aux. axis amplifier) are securely attached to the servo amplifier.

- •Check whether the servo amplifier power is supplied.
- •Check whether the fuse on the servo amplifier has blown.
- •Replace the optical fiber cable.
- •Replace the servo amplifier

11: Invalid axisorder setting. Non-existing axis number is specified. Software axis config (FSSB line number) might be wrong or auxiliary axis board is necessary.

12: SRVO-059 (Servo amp init error) occurs simultaneously. Follow the remedy of SRVO-059.

13,14,15: Document the events that led to the error, and contact your FANUC technical representative.



# SRVO-230 Chain 1 abnormal a, b

#### SRVO-231 Chain 2 abnormal a, b

(Explanation) A mismatch occurred between duplicate safety signals.

SRVO-230 is issued if such a mismatch that a contact connected on the chain 1 side (between EES1 and EES11, between EAS1 and EAS11, between EGS1 and EGS11, and so forth) is closed, and a contact on the chain 2 side (between EES2 and EES21, between EAS2 and EAS21, between EGS2 and EGS21, and so forth) is open occurs. SRVO-231 is issued if such a mismatch that a contact on the chain 1 side is open, and a contact on the chain 2 side is closed occurs.

If a chain error is detected, correct the cause of the alarm then reset the alarm according to the method described later.

(Action) Check the alarms issued at the same time in order to identify with which signal the mismatch occurred.

SRVO-266 through SRVO-275 and SRVO-370 through SRVO-385 are issued at the same time. Take the action(s) described for each item.


#### 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

#### 

1 The state of this alarm is preserved by software. After correcting the cause of the alarm, reset the chain error alarm according to the chain error reset procedure described later.

2 Until a chain error is reset, no ordinary reset operation must be performed. If an ordinary reset operation is performed before chain error resetting, the message "SRVO-237 Chain error cannot be reset" is displayed on the teach pendant.



# Alarm history display method

- 1. Press the screen selection key on the teach pendant.
- 2. Select [4 ALARM] on the teach pendant.
- 3. Press F3 [HIST] on the teach pendant.

# Chain error reset procedure

# 

Do not perform this operation until the cause of the alarm is corrected.

#### <Method 1>

- 1. Press the emergency stop button.
- 2. Press the screen selection key on the teach pendant.
- 3. Select [0 NEXT PAGE] on the teach pendant.
- 4. Press [6 SYSTEM] on the teach pendant.
- 5. Press [7 SYSTEM SETTING] on the teach pendant.
- 6. Find "28" Chain Error Reset Execution.
- 7. Press F3 on the teach pendant to reset "Chain Error".

#### <Method 2>

- 1. Press the screen selection key on the teach pendant.
- 2. Select [4 ALARM] on the teach pendant.
- 3. Press F4 [CHAIN RESET] on the teach pendant.

#### SRVO-232 NTED input

(Explanation) In the teach mode, the NTED signal connected to the connector (CRMA96) on the emergency stop board was placed in the open state.

- (Action 1) Check the operation of the device connected to NTED.
- (Action 2) Replace the teach pendant.
- (Action 3) Replace the teach pendant cable.
- (Action 4) Replace the emergency stop board
- (Action 5) Check the mode switch and its cable. Replace them if a defect is found.

# SRVO-233 TP OFF in T1, T2

(Explanation) Teach pendant is disabled when the mode switch is T1 or T2. Or controller door is opened.

- (Action 1) Enable the teach pendant in teaching operation. In other case the mode switch should be AUTO mode.
- (Action 2) Close the controller door, if open.
- (Action 3) Replace the teach pendant.
- (Action 4) Replace the teach pendant cable.
- (Action 5) Replace the mode switch.
- (Action 6) Replace the emergency stop board.
- (Action 7) Replace the 6-Axis servo amplifier.

# SRVO-235 Short term Chain abnormal

(Explanation) Short term single chain failure condition is detected.

- Cause of this alarm is;
  - Half release of DEADMAN switch
    - Half operation of emergency stop switch.
- (Action 1) Cause the same error to occur again, and then perform resetting.
- (Action 2) Replace the emergency stop board.
- (Action 3) Replace the 6-Axis servo amplifier.

# SRVO-251 DB relay abnormal (G: i A: j)

(Explanation) An abnormality was detected in the internal relay (DB relay) of the servo amplifier.


- (Action 1) Replace the servo amplifier.
- (Action 2) Replace the E-stop unit.

# SRVO-252 Current detect abnl (G: i A: j)

- (Explanation) An abnormality was detected in the current detection circuit inside the servo amplifier.
- (Action) Replace the servo amplifier.

# SRVO-253 Amp internal over heat (G: i A: j)

(Explanation) An overheat was detected inside the servo amplifier. (Action) Replace the servo amplifier.



(A-cabinet)




Fig.3.5 (aa) SRVO-232 NTED input SRVO-233 TP OFF in T1, T2 SRVO-235 Short term Chain abnormal SRVO-251 DB relay abnormal SRVO-252 Current detect abnl SRVO-253 Amp internal over heat

# SRVO-266FENCE1 status abnormalSRVO-267FENCE2 status abnormal

(Explanation) A chain alarm was detected with the EAS (FENCE) signal.

- (Action 1) Check whether the circuitry connected to the dual input signal (EAS) is faulty.
- (Action 2) Check whether the timing of the dual input signal (EAS) satisfies the timing specification

(See Subsection 3.2.5, Table 3.2.5 in CONNECTIONS).

(Action 3) Replace the emergency stop board.

#### 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

# NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.




Fig.3.5 (ab)

SRVO-266 FENCE1 status abnormal SRVO-267 FENCE2 status abnormal

# SRVO-268SVOFF1 status abnormalSRVO-269SVOFF2 status abnormal

(Explanation) A chain alarm was detected with the EGS (SVOFF) signal.

- (Action 1) Check whether the circuitry connected to the dual input signal (EGS) is faulty.
- (Action 2) Check whether the timing of the dual input signal (EGS) satisfies the timing specification

(See Subsection 3.2.5, Fig 3.2.5(c) in CONNECTIONS).


(Action 3) Replace the emergency stop board.

#### / WARNING

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

# NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.



(Emergency stop board/B-cabinet)

(Emergency stop board/A-cabinet)

Fig.3.5 (ac) SRVO-268 SVOFF1 status abnormal SRVO-269 SVOFF2 status abnormal

### SRVO-270 EXEMG1 status abnormal

#### SRVO-271 EXEMG2 status abnormal

(Explanation) A chain alarm was detected with the EES (EXEMG) signal.

(Action 1) Check whether the circuitry connected to the dual input signal (EES) is faulty.

(Action 2) Check whether the timing of the dual input signal (EES) satisfies the timing specification

(See Subsection 3.2.5, Fig 3.2.5(c) in CONNECTIONS).

- (Action 3) Replace the teach pendant cable.
- (Action 4) Replace the teach pendant.
- (Action 5) Replace the emergency stop board.
- (Action 6) Replace the emergency stop switch on the operator's panel.

Before executing the (Action 7), perform a complete controller back-up to save all your programs and settings.


(Action 7) Replace the main board.

#### 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

#### NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.



(Emergency stop board/A-cabinet)

(Emergency stop board/B-cabinet)

Fig.3.5 (ad) SRVO-270 EXEMG1 status abnormal SRVO-271 EXEMG2 status abnormal

#### SRVO-274 NTED1 status abnormal

#### SRVO-275 NTED2 status abnormal

(Explanation) A chain alarm was detected with the NTED signal.

- (Action 1) This alarm may be issued when the DEADMAN switch is pressed to a proper position or is operated very slowly. In such a case, release the DEADMAN switch once completely then press the DEADMAN switch again.
- When the NTED signal is not used, skip Action 2 and 3 and go to Action 4
- (Action 2) Check whether the circuitry connected to the dual input signal (NTED) is faulty.
- (Action 3) Check whether the timing of the dual input signal (NTED) satisfies the timing specification

(See Subsection 3.2.5, Fig 3.2.5(c) in CONNECTIONS).


- (Action 4) Replace the teach pendant cable.
- (Action 5) Replace the teach pendant.
- (Action 6) Replace the emergency stop board.
- (Action 7) Replace the mode switch on the operator's panel.


#### 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

#### NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.





#### SRVO-277 Panel E-stop (SVEMG abnormal)

- (Explanation) The emergency stop line was not disconnected although the emergency stop button on the operator's panel was pressed.
- (Action 1) Replace the emergency stop board.
- (Action 2) Replace the 6-Axis servo amplifier.

#### SRVO-278 TP E-stop (SVEMG abnormal)

- (Explanation) The emergency stop line was not disconnected although the emergency stop button on the teach pendant was pressed.
- (Action 1) Replace the teach pendant.
- (Action 2) Replace the teach pendant cable.
- (Action 3) Replace the emergency stop board.
- (Action 4) Replace the 6-Axis servo amplifier.

#### NOTE

This alarm may be issued if the emergency stop button is pressed very slowly.

#### SRVO-280 SVOFF input

- (Explanation) The external contact connected to EGS1-EGS11 or EGS2-EGS21 of the terminal block TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board is open.
- (Action 1) If external circuitry is connected to EGS1-EGS11 or EGS2-EGS21 of the terminal block TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board, check the external circuitry.
- (Action 2) If this signal is not used, make a connection between EGS1 and EGS11 and between EGS2 and EGS21 of the terminal block TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board.
- (Action 3) Replace the emergency stop board.

#### 

In a system using the SVOFF signal, it is very dangerous to disable the signal when a connection is made between EGS1 and EGS11 and between EGS2 and EGS21 of TBOP13(A-cabinet) or TBOP11(B-cabinet). Never make such an attempt. If a temporary connection is needed for operation, separate safety measures must be taken.

#### SRVO-281 SVOFF input (SVEMG abnormal)

- (Explanation) The emergency stop line was not disconnected although the contact connected between EGS1 and EGS11 or between EGS2 and EGS21 of the terminal block TBOP13(A-cabinet) or TBOP11(B-cabinet) on the emergency stop board was open. The emergency stop circuit is faulty.
- (Action 1) Check the switch and cable connected to EGS1-EGS11and EGS2-EGS21 on TBOP13(A-cabinet) or TBOP11(B-cabinet). If the cable is abnormal, replace it.
- (Action 2) Replace the emergency stop board.
- (Action 3) Replace the 6-Axis servo amplifier.






Fig.3.5 (af) SRVO-277 Panel E-stop (SVEMG abnormal) SRVO-278 TP E-stop (SVEMG abnormal) SRVO-280 SVOFF input SRVO-281 SVOFF input (SVEMG abnormal)

#### SRVO-291 IPM over heat (G:i A:j)


(Explanation) IPM on the servo amplifier is overheated.

- (Action 1) Check whether the fan for cabinet ventilation is stopped and also check whether the vent hole is clogged. If necessary, clean or replace them.
- (Action 2) If SRVO-291 is issued when the robot operating condition is severe, check the robot operating condition then relax the condition when possible.
- (Action 3) If SRVO-291 is issued frequently, replace the servo amplifier.





(A-cabinet)



(B-cabinet)

Fig.3.5 (ag) SRVO-291 IPM over heat

#### SRVO- 293 HCAL(PS) alarm (G: i A: j)

(Explanation) The Power Supply( $\alpha i PS$ ) or the servo amplifier is faulty.

- (Action 1) Replace the servo amplifier(6-axis amplifier,  $\alpha i$ SV).
- (Action 2) Replace the Poewr Supply( $\alpha i PS$ ).

#### SRVO- 295 AMP com error (G: i A: j)

- (Explanation) A communication error occurred in the 6-axis amplifier or between the Power Supply( $\alpha iPS$ ) and the servo amplifier.
- (Action 1) Replace the 6-axis amplifier.
- (Action 2) Replace the cable for communication the Power Supply( $\alpha i PS$ ) and servo amplifier.
- (Action 3) Replace the Power Supply( $\alpha i PS$ ).
- (Action 4) Replace the servo amplifier( $\alpha i$ SV).

#### SRVO- 297 Improper input power (G: i A: j)

- (Explanation) The 6-axis servo amplifier or the power supply( $\alpha i PS$ ) has detected the input voltage phase lack.
- (Action 1) Check the input voltage of the controller whether phase is not lack.
- (Action 2) Make sure that the 6-axis servo amplifier CRRA12 and emergency stop board CRRA12 connector are connected tightly. If the power supply( $\alpha i$ PS) is installed, make sure that the power supply( $\alpha i$ PS) CRRA12 connector is connected tightly.
- (Action 3) Measure the secondary voltage between each phase at the main breaker, if phase loss is detected, replace the main breaker.
- (Action 4) Measure the secondary voltage between each phase at the transformer, if phase loss is detected, replace the transformer.
- (Action 5) Replace the E-stop unit.
- (Action 6) Replace the 6-axis servo amplifier.
- (Action 7) Replace the power supply( $\alpha i PS$ ).

#### SRVO-300 Hand broken/HBK disabled SRVO-302 Set Hand broken to ENABLE

(Explanation) Although HBK was disabled, the HBK signal was input.

- (Action 1) Press RESET on the teach pendant to release the alarm.
- (Action 2) Check whether the hand broken signal is connected to the robot. When the hand broken signal circuit is connected, enable hand broken.(See Subsection 5.5.3 in CONNECTIONS)

#### SRVO-335 DCS OFFCHK alarm a, b

- (Explanation) A failure was detected in the safety signal input circuit.
- (Action 1) Replace the emergency stop board.
- (Action 2) In case of B-cabinet, replace the optional safety I/O board.

#### SRVO-348 DCS MCC OFF alarm a, b

(Explanation) A command was issued to turn off the magnetic contactor, but the magnetic contactor was not turned off.

- (Action 1) This action is applicable to the B-Cabinet only. If a signal is connected to the E-stop unit CRMA74, check whether there is a problem in the connection destination.
   (Action 2) This action is applicable to the B-Cabinet only.
  - Check whether the FUSE4 on emergency stop board. If the fuse is blown, see Article 3.6.(3).
- (Action 3) This action is applicable to the A-cabinet and B-cabinet.
- Replace the E-stop unit (included the magnetic contactor).
- (Action 4) This action is applicable to the A-cabinet and B-cabinet. Replace the 6-Axis servo amplifier.

#### SRVO-349 DCS MCC ON alarm a, b

(Explanation) A command was issued to turn on the magnetic contactor, but the magnetic contactor was not turned on.

- (Action 1) Replace the E-stop unit (included the magnetic contactor).
- (Action 2) Replace the 6-Axis servo amplifier.

# SRVO-370SVON1 status abnormalSRVO-371SVON2 status abnormal

(Explanation) A chain alarm was detected with the emergency stop board internal signal (SVON).(Action) Replace the emergency stop board.

#### 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

#### NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.




Fig.3.5 (ah) SRVO-335 DCS OFFCHK alarm a, b SRVO-348 DCS MCC OFF alarm a, b SRVO-349 DCS MCC ON alarm a, b SRVO-370 SVON1 status abnormal SRVO-371 SVON2 status abnormal

# SRVO-372OPEMG1 status abnormalSRVO-373OPEMG2 status abnormal

(Explanation) A chain alarm was detected with the emergency stop button on the operator's panel.

- (Action 1) Replace the emergency stop board.
- (Action 2) Replace the teach pendant cable.
- (Action 3) Replace the teach pendant.
- (Action 4) Replace the emergency stop button on the operator's panel.

### 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

### NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.

# SRVO-374 MODE11 status abnormal

#### SRVO-375 MODE12 status abnormal

### SRVO-376 MODE21 status abnormal

### SRVO-377 MODE22 status abnormal

(Explanation) A chain alarm was detected with the mode switch signal.


- (Action 1) Check the mode switch and its cable. Replace them if a defect is found.
- (Action 2) Replace the emergency stop board.

## 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

#### NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.



SILVO-SIT MODEZZ Status abiom

MAINTENANCE

(B-cabinet)

#### SRVO-378 SFDIxx status abnormal

(Explanation) A chain alarm was detected with the SFDI signal. xx shows signal name.


- (Action 1) Check whether the circuitry connected to the dual input signal (SFDI) is faulty.
- (Action 2) Check whether the timing of the dual input signal (SFDI) satisfies the timing specification. (See Subsection 3.2.5, Fig 3.2.5(c) in CONNECTIONS).
- (Action 3) In case of B-cabinet, replace the optional safety I/O board.
- (Action 4) Replace the emergency stop board.

## 

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

#### NOTE

For the procedure of recovery from this alarm, see the descriptions of SRVO-230 and SRVO-231.



(A-cabinet)

Fig.3.5 (aj) SRVO-378 SFDIxx status abnormal

### SRVO-450 Drvoff circuit fail (G: i A: j)

(Explanation) The two drive off inputs are not in the same status.

- (Action 1) Check the line of the two drive off inputs.
- (Action 2) Make sure that the connector CRMB16 (6-axis amplifier) is securely attached to the servo amplifier.
- (Action 3) Replace the servo amplifier(6-axis servo amplifier, $\alpha i$ SV).

#### SRVO-451 Internal S-BUS fail (G: i A: j)

(Explanation) An error is found in the serial bus communication in the servo amplifier.

(Action 1) Replace the servo amplifier(6-axis servo amplifier, $\alpha i$ SV).

#### SRVO-452 ROM data failure (G: i A: j)

(Explanation) An error is found in the ROM data in the servo amplifier. (Action 1) Replace the servo amplifier(6-axis servo amplifier, $\alpha iSV$ ).

#### SRVO-453 Low volt driver (G: i A: j)

(Explanation) Driver supply voltage in the servo amplifier is low. (Action 1) Replace the servo amplifier(6-axis servo amplifier, $\alpha iSV$ ).

#### SRVO-454 CPU BUS failure (G: i A: j)

(Explanation) An error was found in CPU bus data in the amplifier. (Action 1) Replace the servo amplifier(6-axis servo amplifier, $\alpha i$ SV).

#### SRVO-455 CPU watch dog (G: i A: j)

(Explanation) An error occurred in CPU operation in the amplifier.

(Action 1) Replace the servo amplifier(6-axis servo amplifier,  $\alpha i$ SV).

#### SRVO-456 Ground fault (G: i A: j)

(Explanation) An error is found in the motor current detection data in the servo amplifier. (Action 1) Replace the servo amplifier(6-axis servo amplifier, $\alpha i$ SV).

#### SRVO-457 Ground fault(PS) (G: i A: j)

(Explanation) Ground fault occurs in the motor power line.

- (Action 1) Check the ground fault of the motor and the motor power cable.
- (Action 2) Replace the Power Supply( $\alpha i PS$ ).
- (Action 3) Replace the servo amplifier(6-axis servo amplifier,  $\alpha i$ SV).

#### SRVO-458 Soft thermal(PS) (G: i A: j)

(Explanation) The root-mean-square current value which is calculated internally by the Power Supply ( $\alpha i$ PS) exceeds the maximum permissible value.

This alarm is issued to protect the Power Supply ( $\alpha i$ PS) from damage of thermal destruction.

Probable cause:

- 1. Overload
- 2. External force to the robot
- 3. Disconnection of the brake cable
- 4. Insufficient torque by low voltage of power supply
- 5. Brake failure (includes mis-setting of brake number for auxiliary axis)
- 6. Aux. brake unit failure for aux. axis
- 7. Power Supply( $\alpha i$ PS) failure
- 8. Amplifier failure
- (Action 1) Check whether the duty and applied load exceed the rating. If so, reduce the duty or applied load.
- (Action 2) Check whether the robot is pushed or pulled by external force. If so, remove the external force to the robot or modify the taught point.
- (Action 3) Check whether the brake cable/connector are connected correctly.
- (Action 4) Measure the supplied voltage. Then, check whether the voltage is matched to the controller specification.
- (Action 5) Check whether the motor brake is released properly when Reset or the robot moves. First of all, check whether the setting of brake number is correct when this alarm occurs on auxiliary axis.
- (Action 6) When this alarm occurs on the auxiliary axis which brake is controlled by the aux. brake unit, check the fuse on the aux. brake unit.
- (Action 7) Replace the Power Supply( $\alpha i PS$ ).
- (Action 8) Replace the servo amplifier (6-axis servo amplifier,  $\alpha i$ SV).

#### SRVO-459 Excess regeneration2%s (G: i A: j)

(Explanation) An error is found in the discharge circuit in the 6-axis amplifier.

(Action 1) Replace the 6-axis servo amplifier.

#### SRVO-460 Illegal parameter%s (G: i A: j)

- (Explanation) An error is found in the setting of the parameters in the Power Supply( $\alpha i$ PS) or 6-axis amplifier.
- (Action 1) Replace the Power Supply( $\alpha i$ PS).
- (Action 2) Replace the 6-axis servo amplifier.

#### SRVO-461 Hardware error%s (G: i A: j)

(Explanation) An error is found in the circuit in the Power Supply( $\alpha i PS$ ) or 6-axis amplifier.

- (Action 1) Replace the Power Supply( $\alpha i$ PS).
- (Action 2) Replace the 6-axis servo amplifier.

#### SRVO-477 Calibration data error

(Explanation) The force sensor calibration data are wrong.(Action) Please load correct force sensor calibration data and apply them again.

#### SRVO-478 Temperature difference too large

 (Explanation) The force sensor temperature difference is too large.
 (Action) Please make sure that the environment temperature does not change greatly, and then restart the controller. If the error is not cleared, document the events that led to the error and contact your FANUC technical representative.

#### SRVO-479 Temperature changes too fast

 (Explanation) The force sensor temperature changes too fast.
 (Action) Please make sure that the environment temperature does not change greatly, and then restart the controller. If the error is not cleared, document the events that led to the error and contact your FANUC technical representative.

#### SRVO-480 FORCE alarm %x,%x

- (Explanation) Force sensor error.
- (Action1) Restart the controller.
- (Action2) Replace the sensor cable.


If the error is not cleared, document the events that led to the error and contact your FANUC technical representative.

# **3.6** FUSE-BASED TROUBLESHOOTING

This section describes the alarms and symptoms generated and actions required when the fuses installed on the printed circuit boards and units have blown.

- (1) When the fuses of the power supply unit have blown
  - F1: Fuse for AC input(A60L-0001-0450#8R0)F3: Fuse for +24 E(A60L-0001-0046#7.5)
  - F3. Fuse for +24 E (A60L-0001-0046#7.5) F4: Fuse for +24 V (A60L-0001-0046#7.5)

Name	Symptom observed when fuse has blown		Action
F1	The LED (PIL: Green) of the power supply unit does not light, and the power cannot be turned on.	1	Check the units (fans), printed-circuit board and cables connected to the CP2 and CP3 connectors of the power supply unit to see if there is any short circuit. Replace the power supply unit.
F3	The teach pendant displays "SRVO-217 E-STOP Board not found" or "PRIO-091 E-Stop PCB comm. Error "	1	Check the printed circuit boards, units, and cables using +24 E according to the power supply system diagram. Replace a faulty printed circuit board, unit or cable if any. Replace the power supply unit.
F4	The power, when turned on, is immediately turned off. At this time, the LED (ALM: Red) lights.	1	Check the printed circuit boards, units, servo amplifier and cables using +24 V according to the power supply system diagram. Replace a faulty printed circuit board, unit, servo amplifier or cable if any. The LED of ALM is turned off by pressing the OFF button once. Replace the power supply unit.



(A-cabinet)

(B-cabinet)




Fig.3.6(a) Fuse on the Power supply unit

 Main board fuse (R-30*i*B Plus)
 FU1:For protecting the +24E output for vision (This fuse is installed on the R-30*i*B Plus main board.)

Name	Symptom observed when fuse has blown	Action
FU1	+24E used for vision is not output.	1 Check +24E used by the vision for a ground fault.
		2 Check the cables connecting to the vision camera and
		the related parts for an abnormaly.
		3 Replace the main board.




Fig.3.6(b) R-30iB Plus Main board

#### MAINTENANCE

#### (3) Servo amplifier fuse

FS1: For generation of the power to the amplifier control circuit (A60L-0001-0290#LM32C) FS2: For protection of the 24V output to the end effector, XROT, and XHBK

d XHBK (A60L-0001-0290#LM32C)

(A60L-0001-0290#LM32C)

FS3: For protection of the 24V output to the regenerative resister

Name	Symptom observed when fuse has blown	Action
FS1	All LEDs on the servo amplifier go out. The FSSB disconnection or initialization alarm is displayed on the teach pendant.	Replace the servo amplifier.
FS2	The 6ch amplifier fuse blown (SRVO-214), Hand broken (SRVO-006), and Robot overtravel (SRVO-005) are displayed on the teach pendant.	<ol> <li>Check +24VF used by the end effector for a ground fault.</li> <li>Check the robot connection cable and the robot's internal cable.</li> <li>Replace the servo amplifier.</li> <li>In case of M-3<i>i</i>A, check the fan motor inside the robot (option).</li> </ol>
FS3	The 6ch amplifier fuse blown (SRVO-214), DCAL alarm (SRVO-043) are displayed on the teach pendant.	<ol> <li>Check the regenerative resister, and replace it if required.</li> <li>Replace the servo amplifier.</li> </ol>





Fig.3.6(c) Fuse on the Servo amplifier

- (4) Emergency stop board fuses
  - FUSE1: For internal power supply circuit
  - FUSE2: For +24EXT line (emergency stop line) protection
  - FUSE3: For teach pendant power supply circuit
  - FUSE4: For SFDI protection (B-cabinet only)

(A60L-0001-0290#LM10C) (A60L-0001-0290#LM10C) (A60L-0001-0290#LM10C) (A60L-0001-0290#LM10C)

Name	Symptom observed when fuse has blown	Action
FUSE1	The teach pendant displays "SRVO-217 E-STOP Board not found" or "PRIO-091 E-Stop PCB comm. Error ".	<ol> <li>Check the cable between emergency stop board and main board. Replace them if necessary.</li> <li>Replace the E-STOP unit.</li> </ol>
		<ul><li>Before executing the (Action 3), perform a complete controller back-up to save all your programs and settings.</li><li>3 Replace the main board.</li></ul>

Name	Symptom observed when fuse has blown	Action
FUSE2	The teach pendant displays "SRVO-213 E-STOP Board FUSE2 blown"	<ol> <li>If an alarm is issued when the fuse has not blown, check the voltages of EXT24V and EXT0V (TBOP14 for A-cabinet or TBOP10 for B-cabinet). If EXT24V or INT0V is not used, check the jumper pin between EXT24V and INT24V or between EXT0V and INT0V.</li> <li>If the FENCE, SVOFF, and EXEMG are used, these signals may be connected to 0V or ground. Check these cables.</li> <li>Replace the operator's panel cable(CRT27).</li> <li>Replace the teach pendant cable.</li> <li>Replace the teach pendant.</li> </ol>
FUSE3	The display on the teach pendant disappears.	<ol> <li>Check the teach pendant cable for a fault, and replace it if required.</li> <li>Check the teach pendant for a fault, and replace it if required.</li> <li>Replace the emergency stop board.</li> </ol>
FUSE4	(B-cabinet only) The teach pendant displays "SRVO-348 DCS MCC OFF Alarm"	<ol> <li>Check the SFDI cable connections, and replace it if required.</li> <li>Check the operator's panel cable (CRT27), and replace it if required.</li> <li>Replace the E-STOP unit.</li> </ol>



(A-cabinet)

(B-cabinet)

Fig.3.6 (d) Fuse on the Emergency stop board

MAINTENANCE

(5) Fuse on the process I/O board JA,JB

FUSE1: Fuse for +24E		(A60L-0001-0046#2.0)	
Name	Symptom observed when fuse has blown	Action	
FUSE1	The LED (ALM-2 or FALM) on the process I/O board lights, and an alarm such as IMSTP input is output on the teach pendant. (The display data depends on state of peripheral equipment connection.)	<ol> <li>Check if the cables and peripheral equipment connected to the process I/O board are normal.</li> <li>Replace the process I/O board.</li> </ol>	

Fuse location is common to JA and JB. The following is figure of JA.




Fig.3.6 (e) Fuse on the Process I/O board JA,JB

(6) Fuse on the process I/O MA,MB

FUSE1: Fuse for +24E		(A60L-0001-0046#1.0)	
Name	Symptom observed when fuse has blown	Action	
FUSE1	The LED (ALM1 or FALM) the process I/O board lights.	<ol> <li>Check if the cables and peripheral devices connected to the process I/O board are normal.</li> <li>Replace the process I/O board.</li> </ol>	





Fig.3.6 (f) Fuse on the process I/O board MA



#### Fig.3.6 (g) Fuse on the process I/O board MB

(7) Fuse on the sensor I/F unit for CR-35iAFUSE: For internal power supply circuit

#### (A60L-0001-0290#LM20)

Name	Symptom observed when fuse has blown		Action
FUSE	The LED of the sensor I/F unit lights.	1.	Check if the cables and peripheral devices connected to the sensor I/F unit are normal.
		2.	Replace the sensor I/F unit.




Fig.3.6 (h) Fuse on sensor I/F unit for CR-35*i*A

# **3.7** TROUBLESHOOTING BASED ON LED INDICATIONS

The printed circuit boards and servo amplifier are provided with alarm LEDs and status LEDs. The LED status and corresponding troubleshooting procedures are described below.




Fig.3.7 Troubleshooting based on LED indication

# **3.7.1** Troubleshooting Using the LEDS on the Main Board

(1) Troubleshooting using the status display LED

To troubleshoot an alarm that arises before the teach pendant is ready to display, check the status LEDs (green) on the main board at power-on. After power-on, the LEDs light as described in steps 1 to end, in the order described. If an alarm is detected, the step in which the alarm occurred can be determined from which LEDs are lit.

Step	LED	Action to be taken
1: After power-on, all LEDs are lit.	D1 D2 D3 D4	[Action1] Replace the CPU card. * [Action2] Replace the main board.
2: Software operation start-up.	D1 D2 D3 D4	[Action1] Replace the CPU card. * [Action2] Replace the main board.
3: The initialization of dram on the CPU card is completed.	D1 D2 D3 D4	[Action1] Replace the CPU card. * [Action2] Replace the main board.

B-83195EN/09

# 3. TROUBLESHOOTING


Step	LED	Action to be taken
4: The initialization of DPRAM on the communication IC is completed.	D1 D2 D3 D4	<ul> <li>[Action1] Replace the CPU card.</li> <li>* [Action2] Replace the main board.</li> <li>* [Action3] Replace the FROM/SRAM module.</li> </ul>
5: The initialization of the communication IC is completed.	D1 D2 D3 D4	[Action1] Replace the CPU card. * [Action2] Replace the main board. * [Action3] Replace the FROM/SRAM module.
6: The loading of the basic software is completed.	D1 D2 D3 D4	<ul> <li>* [Action1] Replace the main board.</li> <li>* [Action2] Replace the FROM/SRAM module.</li> </ul>
7: Basic software start-up.	D1 D2 D3 D4	<ul> <li>* [Action1] Replace the main board.</li> <li>* [Action2] Replace the FROM/SRAM module.</li> <li>* [Action3] Replace the power supply unit.</li> </ul>
8: Start-up of communication with the teach pendant.	D1 D2 D3 D4	* [Action1] Replace the main board. [Action2] Replace the FROM/SRAM module.
9: The loading of optional software is completed.	D1 D2 D3 D4	* [Action1] Replace the main board. [Action2] Replace the process I/O board.
10: DI/DO initialization	D1 D2 D3 D4	[Action1] Replace the FROM/SRAM module. [Action2] Replace the main board.
11: The preparation of the SRAM module is completed.	D1 D2 D3 D4	[Action1] Replace the axis control card. * [Action2] Replace the main board. [Action3] Replace the servo amplifier.
12: Axis control card initialization	D1 D2 D3 D4	[Action1] Replace the axis control card. * [Action2] Replace the main board. [Action3] Replace the servo amplifier.
13: Calibration is completed.	D1 D2 D3 D4	[Action1] Replace the axis control card. * [Action2] Replace the main board. [Action3] Replace the servo amplifier.

MAINTENANCE

Step	LED	Action to be taken
14: Start-up of power application for the servo system	D1 D2 D3 D4	* [Action1] Replace the main board.
15: Program execution	D1 D2 D3 D4	<ul> <li>* [Action1] Replace the main board.</li> <li>[Action2] Replace the process I/O board.</li> </ul>
16: DI/DO output start-up.	D1 D2 D3 D4	* [Action1] Replace the main board.
17: Initialization is terminated.	D1 D2 D3 D4	Initialization has ended normally.
18: Normal status	☆ D1 ☆ D2 D3 D4	Status LEDs 1 and 2 blink when the system is operating normally.

\* If the main board or FROM/SRAM module is replaced, the contents of memory (parameters, specified data, etc.) will be lost. Before you replace the unit, therefore, make a backup copy of the data.

If an alarm is issued, data backup may be disabled. So, back up the contents of memory routinely.



#### Fig.3.7.1 LED on the main board


#### (2) TROUBLESHOOTING BY 7-SEGMENT LED INDICATOR

7-segment LED indicator	Description		
	[Description] A parity alarm condition has occurred in DRAM on the CPU card installed on the main board.		
<b>U</b> .	[Action1] Replace the CPU card. * [Action2] Replace the main board.		
A	[Description] A parity alarm condition has occurred in SRAM on the FROM/SRAM module installed on the main board.		
	[Action1]       Replace the FROM/SRAM module.         * [Action2]       Replace the main board.		
<b>B</b> .	[Description]A bus error has occurred in the communication controller.*[Action]Replace the main board.		
B.	<ul> <li>[Description] A parity alarm condition has occurred in DRAM controlled by the communication controller.</li> <li>* [Action] Replace the main board.</li> </ul>		
<b>B</b> .	[Description]       A servo alarm condition has occurred on the main board.         [Action1]       Replace the axis control card.         * [Action2]       Replace the main board.         [Action3]       If an option board is installed, replace the option board.		
<b>B</b> .	[Description]       The SYSEMG alarm has occurred.         [Action1]       Replace the axis control card.         [Action2]       Replace the CPU card.         *       [Action3]         Replace the main board.		
8.	[Description]       The SYSFAIL alarm has occurred.         [Action1]       Replace the axis control card.         [Action2]       Replace the CPU card.         *       [Action3]         Replace the main board.         [Action4]       If an option board is installed, replace the option board.		
B.	[Description] 5V is supplied to Main board. Above alarms do not occur.		

\* If the main board or FROM/SRAM module is replaced, the contents of memory (parameters, specified data, etc.) will be lost. Before you replace the unit, therefore, make a backup copy of the data.

If an alarm is issued, data backup may be disabled. So, back up the contents of memory routinely.

# **3.7.2** Troubleshooting by LEDs on Power Supply Unit








Fig.3.7.2 LEDs on the power supply unit

# **3.7.3** Troubleshooting by LED on the Emergency Stop Board

LED indication	Failure description and required measure		
FU4	[Description]	When the LED (red) turned on, the fuse FU4 is blown. 24V for safety DI	
(Red)		signal(SFDI) is not supplied.	
(B-cabinet only)	[Action1]	Check the connection of SFDI on Safety I/O board.	
	[Action2]	Check the operator's panel cable (CRT27), and replace it if required.	
	[Action3]	Replace the E-STOP unit.	
24V	[Description]	When the LED does not light, the +24V power for the teach pendant and	
(Green)		internal circuit is not supplied.	
	[Action1]	Check the CRP33(A-cabinet) or CP5A(B-cabinet) connector and check	
		that 24 V is supplied. When 24 V is not supplied, check CP6 connector	
		and fuse F3 of power supply unit.	
	[Action2]	Replace the emergency stop board.	
EXT24/24EXT	[Description]	When the LED (green) does not light, the EXT24V power for emergency	
(Green)		stop circuit is not supplied.	
	[Action1]	Check the voltages of EXT24V and EXT0V (TBOP14 for A-cabinet or	
		TBOP10 for B-cabinet). If +EXT24V or EXT0V is not used, check the	
		jumper pin between EXT24V and INT24V or between EXT0V and	
		INTOV.	
	[Action2]	If the FENCE, SVOFF, and EXEMG is used, these signals may be	
		connected to 0V or ground. Check these cables.	
	[Action3]	Replace the emergency stop board.	
	[Action4]	Check the teach pendant cable, and replace it if required.	
	[Action5]	Check the teach pendant, and replace it if required.	
	[Action6]	Check the operator's panel cable (CRT27), and replace it if required.	
SVON1/SVON2	[Description]	These LEDs (green) indicate the status of SVON1/SVON2 signals from	
(Green)		the emergency stop board to the servo amplifier. When the SVON1 and	
		SVON2 (green) turned on, the servo amplifier is ready to energize.	

LED indication		Failure description and required measure	
LINK1/LINK2	[Description]	Please see the Section 3.9. The operation mode is "I/O Link <i>i</i> ". If LINK1	
(Green)	[]	or LINK2 state is "Blink (1:1 at high speed)", communication is at halt	
(Croon)		because of an alarm.	
	[Action1]	Identify the cause according to the states of the red LED "ALM" stated	
	[/ totion 1]	below or information displayed on the TP screen.	
ALM1/ALM2 (Red)	[Description]	Please see the Section 3.9. The operation mode is "I/O Link <i>i</i> ".	
	[1] If the ALM	1 or ALM2 state is "Steadily ON", hardware may be defective.	
	[Action1]	Check the cable between the main board and the emergency stop	
		boards, and replace it if necessary.	
	[Action2]	Replace the emergency stop board.	
	[Action3]	Replace the main board.	
	[2] If the ALM1 or ALM2 state is "Blink (1:1)", the communication between the emergency stop board and a unit connected to I/O Link <i>i</i> (E-STOP unit) to the		
	E-STOP u	nit is stopped, or there may be noise around the cable.	
	[Action1]	Check the communication cable between the emergency stop board and the unit connected to I/O Link $i$ (E-STOP unit), and replace it if necessary.	
	[Action2]	Replace the unit connected to I/O Link <i>i</i> (E-STOP unit).	
	[Action3]	Replace the emergency stop board	
		.M1 or ALM2 state is "Blink (3:1)", a unit connected to I/O Link $i$ (E-STOP ne E-STOP unit may have power failure.	
	[Action1]	Check fuse on a unit connected to I/O Link i (E-STOP unit) to the	
		E-STOP unit, and replace it if it has blown.	
	[Action2]	Replace the unit connected to I/O Link <i>i</i> (E-STOP unit).	
	[Action3]	Replace the emergency stop board.	





# **3.7.4** Troubleshooting by Alarm LEDs on the Process I/O Board

Process I/O JA,JB			
LED	Description and action to be taken		
I 2 3 4 STATUS IIIII	<ul> <li>[Description] A communication alarm occurred between the main board and process I/O board.</li> <li>[Action1] Replace the process I/O board.</li> <li>* [Action2] Replace the main board.</li> <li>[Action3] Replace the I/O link connection cable.</li> </ul>		
I 2 3 4 STATUS IIII ALARM	[Description]A fuse on the process I/O board is blown.[Action1]Replace the blown fuse on the process I/O board.[Action2]Examine the cables and peripheral devices connected to the process I/O board.Replace any failed components.Replace the process I/O board.[Action3]Replace the process I/O board.		

\* If the main board or FROM/SRAM module is replaced, the contents of memory (parameters, specified data, etc.) will be lost. Before you replace the unit, therefore, make a backup copy of the data.

If an alarm is issued, data backup may be disabled. Therefore, back up the contents of memory routinely.




Fig.3.7.4 (a) LEDs on the Process I/O board JA/JB

Process I/O MA,MB			
LED	Color	Description	
		[Explanation]	An alarm was issued during communication between the main board and the process I/O board.
ALM1	Red	[Measure 1]	Replace the process I/O board.
		[Measure 2]	Replace the I/O link connection cable.
		[Measure 3]	Replace the main board.
		[Explanation]	The fuse on the process I/O board was blown.
		[Measure 1]	Replace the fuse on the process I/O board.
FALM	Red	[Measure 2]	Check the cables and peripheral units connected to the process I/O
			board and replace the defective units.
		[Measure 3]	Replace the process I/O board.




Fig.3.7.4 (b) LEDs on the process I/O board MA




Fig.3.7.4 (c) LEDs on the process I/O board MB

# **3.7.5** Troubleshooting by LEDs on the 6-Axis Servo Amplifier

The 6-Axis servo amplifier has alarm LEDs. Troubleshoot the alarm indicated by the LEDs, referring also to the alarm indication on the teach pendant.

Check that the voltage is not higher than 50V.




Fig.3.7.5 LEDs on the 6-Axis servo amplifier

### 

Before touching the 6-Axis servo amplifier, check the DC link voltage with the screws located above the LED "V4". By using a DC voltage tester, check that the voltage is 50 V or less.


LED	Color	Description	
V4	Red	Lights when the DCLINK circuit inside the servo amplifier is charged to reach the specified	
		voltage.	
		If the LED does not light after pre-charge is finished:	
		[Action 1] The DC Link may be short-circuited. Check for connection.	
		[Action 2] The charge current control resistor may be defective. Replace the	
		emergency stop unit.	
		[Action 3] Replace the servo amplifier.	
ALM	Red	Lights when the servo amplifier detects an alarm.	
		If the LED lights when there is no alarm condition in the machine:	
		[Action] Replace the servo amplifier.	
		If the LED does not light when there is an alarm condition in the machine:	
		[Action] Replace the servo amplifier.	

B-83195EN/09

LED	Color	Description
SVEMG	Red	Lights when an emergency stop signal is input to the servo amplifier.
		If the LED lights when the machine is not at an emergency stop:
		[Action] Replace the servo amplifier.
		If the LED does light when the machine is at an emergency stop:
		[Action] Replace the servo amplifier.
DRDY	Green	Lights when the servo amplifier is ready to drive the servo motor.
		If the LED does not light when the motor is activated:
		[Action] Replace the servo amplifier.
OPEN	Green	Lights when the communication between the servo amplifier and the main board is normal.
		If the LED does not light:
		[Action 1] Check for the connection of the FSSB optical cable.
		[Action 2] Replace the servo card.
		[Action 3] Replace the servo amplifier.
P5V	Green	Lights when the power supply circuit inside the servo amplifier outputs a voltage of +5 V
		normally.
		If the LED does not light:
		[Action 1] Check the robot connection cable (RMP1) to see if there is a ground fault in
		the +5V wire.
		[Action 2] Replace the servo amplifier.
P3.3V	Green	Lights when the power supply circuit inside the servo amplifier outputs a voltage of +3.3 V $$
		normally.
		If the LED does not light:
		[Action] Replace the servo amplifier.

# **3.7.6** Troubleshooting by LEDs on the $\alpha i PS$

The  $\alpha i$ PS has alarm LEDs. Troubleshoot the alarm indicated by the LEDs, referring also to the alarm indication on the teach pendant.



MAINTENANCE

## Detail of LED Display of α*i*PS

ALARM LED	ERROR LED	STATUS LED	Contents
		LED is off	Control power has not been supplied. Fault of hardware.
		Number / alphabet	The software series/edition is displayed at 4 sessions for about 4 seconds after the power is turned on. First 1 sec: Upper 2 digits of the software series Second 1 sec: Lower 2 digits of the software series Third 1 sec: Upper 2 digits of software version Forth 1 sec : Lower 2 digits of software version Example) In case of Software serie/version 9G00/01.0 9 G $\rightarrow$ 0 0 $\rightarrow$ 0 1 $\rightarrow$ 0 0
		— — <u>Blink</u>	Serial communication with the servo or spindle amplifier is being established
		— — Lighting	Serial communication with the servo or spindle amplifier is established
		00 <u>Blink</u>	Start up main power (Precharging)
		00	Ready main power
Lighting		Number 01 to	Alarm status
		Number 01to	Warning status

LED	Description
01	PS Overcurrent
02	PS internal fan failure
03	PS overload
04	PS low volt. DC link
05	PS pre-charge failure
06	PS low volt. control
07	PS over volt. DC link
10	PS external fan failure
14	PS improper Input power
15	PS soft thermal
24	PS hardware error

# **3.7.7** Troubleshooting by LEDs on the Sensor I/F Unit for CR-35*i*A

The sensor I/F unit for the I/O Link *i* only has the following LEDs to indicate the communication status of the I/O Link *i*.




Fig.3.7.7 LEDs on the sensor I/F unit for CR-35iA

- FUSE LED Lights when the fuse blows.
   Remove the cause of the blown fuse, and the replace the fuse.
- · LINK LED

The LINK LED indicates the group communication status as described below.

Operation mode	LED Indications	Meaning	Remarks
I/O Link i	OFF	Power OFF	
	ON	Power ON	
	Blink (1:1)	Communication in progress Standard	ON = approx. 0.5 sec OFF = approx. 0.5 sec
	Blink (3:1)	Communication in progress (Dual check safety in use)	ON = approx. 1.5 sec OFF = approx. 0.5 sec
	Blink (1:1 at high speed)	Communication not in progress Watch-dog alarm occurrence	ON = approx. 0.25 sec OFF = approx. 0.25 sec

#### · ALM LED

The ALM LED indicates the types of I/O Link *i* alarms as described below.

Operation mode	LED Indications	Meaning	Remarks
I/O Link i	OFF	Normal state or power OFF	
	ON	Occurrence of any of a parity alarm, external input alarm, and dual check safety alarm	
	Blink (1:1)	Broken wire between the group of interest and a group subsequent to it	ON = approx. 0.5 sec OFF = approx. 0.5 sec
	Blink (3:1)	Power failure (including instantaneous power failure) in a group subsequent to the group of interest	ON = approx. 1.5 sec OFF = approx. 0.5 sec
	Blink (1:3)	Status alarm	ON = approx. 0.5 sec OFF = approx. 1.5 sec
	Blink (1:1 at high speed)	Alarm occurred due to a command from the master	ON = approx. 0.25 sec OFF = approx. 0.25 sec

# **3.8** MANUAL OPERATION IMPOSSIBLE

The following explains checking and corrective action required if the robot cannot be operated manually after the controller is turned on:

(1) Check and corrective action to be made if manual operation is impossible

(Check 1)	Check whether the teach pendant is enabled.
	(Corrective action)
	Turn on the teach pendant "enable".
(Check 2)	Check whether the teach pendant is handled correctly.
	(Corrective action)
	To move an axis by manual operation, press the axis selection key and shift key at
	the same time.
	Set the override for manual feed to a position other than the FINE and VFINE positions.
(Check 3)	Check whether the ENBL signal of the peripheral device control interface is set to
	on.
	(Corrective action)
	Place the peripheral device control interface in the ENBL status.
(Check 4)	Check whether the HOLD signal of the peripheral device control interface (hold
	status). (Check whether the hold lamp on the teach pendant is on.)
	(Corrective action)
	Turn off the HOLD signal of the peripheral device control interface.
(Check 5)	Check whether the previous manual operation has been completed.
	(Corrective action)
	If the robot cannot be placed in the effective area because of the offset of the speed
	command voltage preventing the previous operation from being completed, check the
	position deviation on the status screen, and change the setting.
(Check 6)	Check whether the controller is in the alarm status.
	(Corrective action)
	Release the alarm.

- (2) Check and corrective action to be taken if the program cannot be executed
  - (Check 1) Check whether the ENBL signal for the peripheral-device control interface is on.(Corrective action)Put the peripheral-device control interface in the ENBL state.

B-83195EN/09	MAINTENANCE	3. TROUBLESHOOTING	
(Check 2)	Check whether the HOLD signal for the peripheral-device control interface is on.		
	Also check whether the HOLD lamp on the teach	pendant is on.	
	(Corrective action)	alintanfaaaia on turmit off	
(Check 3)	<ul> <li>If the HOLD signal of the peripheral device control interface is on, turn it off.</li> <li>Check whether the previous manual operation has been completed. (Corrective action)</li> </ul>		
(Check 5)			
	If the robot cannot be placed in the effective are	a because of the offset of the speed	
	command voltage, which prevents the previous		
$(C_{1}, \ldots, 1, A)$	check the position deviation on the status screen,	6 6	
(Check 4)	Check whether the controller is in the alarm statu (Corrective action)	S.	
	Release the alarm.		

# **3.9** LEDS ON UNITS SUPPORTING I/O Link *i*

# **3.9.1** Meanings of LEDs on Units Supporting I/O Link *i*

The standard I/O Link i incorporates three LEDs, "LINK" (green), "ALM" (red), and "FUSE" (red) for each unit separately. These LEDs indicate the states of the units.

The following table lists the ON/OFF states of the LEDs and their me	anings.
--	---------

LED ON/OFF state	ON and OFF duration	
Steadily OFF		
Steadily ON		
Blink (1:1)	ON = approx. 0.5 sec, OFF = approx. 0.5 sec	
Blink (3:1)	ON = approx. 1.5 sec, OFF = approx. 0.5 sec	
Blink (1:3)	ON = approx. 0.5 sec, OFF = approx. 1.5 sec	
Blink (1:1 at high speed)	ON = approx. 0.25 sec, OFF = approx. 0.25 sec	

## LED [LINK] (green)

The "LINK" (green) LED indicates the state of communication. The following table lists the meanings of LED states.

Operation mode	LED state	Meaning	Fault location and action
Common	OFF	Power OFF	
	ON	Power ON (before communication start)	
	Blink (1:1 at high speed)	Communication at halt	Communication is at halt because of an alarm. Identify the cause according to the states of the red LED stated below or information displayed on the CNC screen.
I/O Link	Blink (1:3)	Communication in progress	
I/O Link i	Blink (1:1)	Communication in progress	
	Blink (3:1)	Communication in progress (Dual check safety in use)	

# LED 「ALM」 (red)

The "ALM" (red) LED indicates an alarm in the unit of interest or a unit subsequent to it. The following table lists the meanings of LED states.

Operation mode	LED state	Meaning	Fault location and action
Common	OFF	Normal state or power OFF	
I/O Link	ON	Alarm	It is likely that the hardware may be defective. Replace the unit.
I/O Link i	ON	Alarm	It is likely that the hardware may be defective. Replace the unit.
	Blink (1:1)	Broken wire between the unit of interest and a unit subsequent to it	Check for a defective cable or a poor cable connection between JD1A on the unit of interest and JD1B on a unit subsequent to that unit. Alternatively, it is likely that there may be noise. Check to see if there is noise around the cable.
	Blink (3:1)	Power failure (including instantaneous power failure) in a unit subsequent to the unit of interest	Identify and remove the cause of a power failure in a unit subsequent to the unit of interest.
	Blink (1:3)	Status alarm	A status alarm, such as a DO ground fault, has occurred. Identify and remove the cause of the alarm.

# PRINTED CIRCUIT BOARDS

The printed circuit boards are factory-set for operation. Usually, you do not need to set or adjust them. This chapter describes the standard settings and adjustment required if a defective printed circuit board is replaced. It also describes the test pins and the LED indications.

The controller printed circuit board includes the main unit printed circuit board and one or more cards or modules installed horizontally to the main-unit printed-circuit board.

These PC boards have interface connectors, LED indicators, and a plastic panel at the front. At the rear, there is a backplane connector.

## 4.1 MAIN BOARD




Fig.4.1 Main board

Name	Ordering Specification	<b>Board Specification</b>	Note
Main board	A05B-2600-H001	A16B-3200-0730	Standard
		A16B-3200-0780	
	A05B-2600-H002	A16B-3200-0731	Option (Force sensor)
		A16B-3200-0781	
	A05B-2600-H003	A16B-3200-0732	Option (Force sensor)
		A16B-3200-0782	(High speed com. CPU)
	A05B-2600-H004	A16B-3200-0800	Standard For I/O Link <i>i</i> slave
	A05B-2600-H005	A16B-3200-0801	Option (Force sensor) For I/O Link <i>i</i> slave
	A05B-2600-H006	A16B-3200-0802	Option (Force sensor, High speed) For I/O Link <i>i</i> slave

#### 4. PRINTED CIRCUIT BOARDS MAINTENANCE

Name	Ordering Specification	<b>Board Specification</b>	Note
Main board	A05B-2670-H001	A16B-3200-0810	Standard
	(R-30 <i>i</i> B Plus)		For I/O Link <i>i</i> slave
	A05B-2670-H002	A16B-3200-0811	Option (Force sensor)
	(R-30 <i>i</i> B Plus)		For I/O Link <i>i</i> slave
	A05B-2670-H003	A16B-3200-0812	Option (Force sensor, High
	(R-30 <i>i</i> B Plus)		speed)
			For I/O Link <i>i</i> slave
CPU card	A05B-2600-H020	A20B-3300-0686	Standard / SDRAM 32Mbyte
		A17B-3301-0106	
	A05B-2600-H021	A20B-3300-0687	Standard / SDRAM 64Mbyte
		A17B-3301-0107	
	A05B-2600-H022	A20B-3300-0688	Standard / SDRAM 128Mbyte
		A17B-3301-0108	
		A20B-3300-0683	High speed / SDRAM 32Mbyte
	A05B-2600-H023	A17B-3301-0103	
		A20B-3300-0684	High speed / SDRAM 64Mbyte
	A05B-2600-H024	A17B-3301-0104	<u> </u>
		A20B-3300-0685	High speed / SDRAM 128Mbyte
	A05B-2600-H025	A17B-3301-0105	
		A17B-3301-0109	Standard / SDRAM 32Mbyte
	A05B-2600-H026	ATT D-0001-0109	For I/O Link <i>i</i> slave
	A05B-2600-H027	A17B-3301-0110	Standard / SDRAM 64Mbyte
			For I/O Link <i>i</i> slave
	A05B-2600-H028	A17B-3301-0111	Standard / SDRAM 128Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H029	A17B-3301-0112	High speed / SDRAM 32Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H030	A17B-3301-0113	High speed / SDRAM 64Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H031	A17B-3301-0114	High speed / SDRAM 32Mbyte For I/O Link <i>i</i> slave
	A05B-2670-H020 (R-30 <i>i</i> B Plus)	A17B-3301-0250	Standard /DRAM 1GB For I/O Link <i>i</i> slave
Axis control card	A05B-2600-H040	A20B-3300-0664	6-axis
		A20B-3300-0774	
	A05B-2600-H041	A20B-3300-0663	12-axis
		A20B-3300-0773	12 0/10
	A05B-2600-H042	A20B-3300-0662	18-axis
		A20B-3300-0772	
	A05B-2600-H043	A20B-3300-0661	24-axis
	A03D-2000-110+3	A20B-3300-0771	24-0/13
	A05B-2600-H044	A20B-3300-0660	36-axis
	A05B-2000-11044		50-axis
		A20B-3300-0770	6 avic
	A05B-2670-H040 (R-30 <i>i</i> B Plus)	A20B-3300-0819	6-axis
	A05B-2670-H041	A20B-3300-0818	12-axis
	(R-30 <i>i</i> B Plus)	AZUD-3300-0010	12-0113
		ADOR 2200 0817	19 ovio
	A05B-2670-H042 (R-30 <i>i</i> B Plus)	A20B-3300-0817	18-axis
	A05B-2670-H043 (R-30 <i>i</i> B Plus)	A20B-3300-0816	24-axis
	A05B-2670-H044 (R-30 <i>i</i> B Plus)	A20B-3300-0815	36-axis

Name	Ordering Specification	<b>Board Specification</b>	Note
FROM/SRAM module	A05B-2600-H060	A20B-3900-0283	FROM 32M/ SRAM 1M
		A20B-3900-0297	
	A05B-2600-H061	A20B-3900-0284	FROM 32M/ SRAM 2M
		A20B-3900-0298	
	A05B-2600-H062	A20B-3900-0285	FROM 32M/ SRAM 3M
		A20B-3900-0299	
	A05B-2600-H063	A20B-3900-0286	FROM 64M/ SRAM 1M
	A05B-2600-H064	A20B-3900-0287	FROM 64M/ SRAM 2M
	A05B-2600-H065	A20B-3900-0288	FROM 64M/ SRAM 3M
	A05B-2600-H066	A20B-3900-0280	FROM 128M/ SRAM 1M
	A05B-2600-H067	A20B-3900-0281	FROM 128M/ SRAM 2M
	A05B-2600-H068	A20B-3900-0282	FROM 128M/ SRAM 3M
	A05B-2600-H069	A20B-3900-0293	FROM 256M/SRAM 1M
	(R-30 <i>i</i> B Plus)		
	A05B-2600-H070	A20B-3900-0295	FROM 256M/SRAM 2M
	(R-30 <i>i</i> B Plus)		
	A05B-2600-H071 (R-30 <i>i</i> B Plus)	A20B-3900-0296	FROM 256M/SRAM 3M

#### 

If I/O Link *i* slave is being used, the combinations of the mainboard, CPU card, and software is limited as shown below.

[Main board (For I/O Link *i* slave)] + [CPU card (For I/O Link *i* slave)] + [Software (V8.30P14 or later)]

Except for the above condition, the system does not work correctly as follows.

a) [Main board] + [CPU card (For I/O Link *i* slave)]

Neither the function of I/O Link slave nor I/O Link i slave work correctly. And the alarm regarding I/O Link or I/O Link i occur on the master side. And in case the software version is not correct, system does not work correctly.

 b) [Main board (For I/O Link *i* slave)] + [CPU card] Neither the function of I/O Link slave nor I/O Link *i* slave work correctly, and the alarm regarding I/O Link or I/O Link *i* occurs on the master side.

In case of using the R-30*i*B Plus, the combination of the specification of mainboard, CPU card and software is limited as below.

[Main board (R-30*i*B Plus)] + [CPU card (R-30*i*B Plus)] + [Software (V9.00P03 or later)]


Except for the above condition, the system does not work correctly. And CPU card (R-30*i*B Plus) may be broken.

#### 4. PRINTED CIRCUIT BOARDS

#### 4. PRINTED CIRCUIT BOARDS

MAINTENANCE

LEDs




Seven segment LED	Description
<b>B</b> .	When the alarm condition has occurred in the main board, this LED is turned on. Please see the Section 3.7.TROUBLESHOOTING BASED ON LED INDICATIONS.

ETHERNET CONNECTOR LED	Color	Description
RX/TX	Green	Blink during data transmission
LINK	Green	Light when a link is established

STATUS LED	Color	Description
STATUS1	Green	These LEDs show the energy status of the system
STATUS2	Green	These LEDs show the operating status of the system. Please see the Section 3.7.TROUBLESHOOTING BASED
STATUS3	Green	ON LED INDICATIONS.
STATUS4	Green	


ETHERNET LED	Color	Description
TP_RX/TX	Green	Blink during data transmission of Ethernet TP
TP_LINK	Green	Light when a link of Ethernet TP is established
CD38C_RX/TX	Green	Blink during data transmission of CD38C
CD38C_LINK	Green	Light when a link of CD38C is established

### 4.2 EMERGENCY STOP BOARD A-cabinet:A20B-2200-0650/B-cabinet:A20B-2102-0050





## 4.3 BACKPLANE



(2 slot)

Fig.4.3 Backplane

(4 slot)

Name	Ordering Specification	Parts number	Board specification
2 slot backplane	A05B-2600-H080	A05B-2600-C001	A20B-2004-0980

#### 4. PRINTED CIRCUIT BOARDS

MAINTENANCE

B-83195EN/09

Name	Ordering Specification	Parts number	Board specification
4 slot backplane	A05B-2600-H081	A05B-2600-C002	A20B-2004-0990

### 4.4 PROCESS I/O BOARD JA (A16B-2204-0010)





Fig.4.4 (a) Process I/O Board JA (Total edition 04A or earlier)

MAINTENANCE 4. PRINTED CIRCUIT BOARDS



#### Fig.4.4 (b) Process I/O Board JA (Total edition 05B or later)

#### (1) Test pins

Name		Use
P24V	+24V	For measuring the DC supply voltage
P5V	+5V	
GND1	GND	
GND2	GND	
P3V (Total edition 05B or later)	+3.3V	

#### (2) Settings

	Name	Standard setting	Description
ICOM1	UDI1 to 20	Side A	Set the common voltage
	(Connector CRMA5A)		Side A: +24 V common
ICOM2	UDI21 to 40		Side B: 0 V common
	(Connector CRMA5B)		
ICOM3	UDI41 to 60		
	(Connector CRMA5C)		
ICOM4	UDI61 to 80		
	(Connector CRMA5D)		
ICOM5	UDI81 to 88		
	(Connector CRMA6A)		
ICOM6	UDI89 to 96		
	(Connector CRMA6B)		


#### 4. PRINTED CIRCUIT BOARDS

MAINTENANCE


#### (3) Meaning of LEDs

	Color	Description
PROCESS	Red	A communication alarm occurred between the main board and process I/O board.
PROCESS	Red	A fuse (FUSE 1) in the process I/O board blew.
LINK (Total edition 05B or later)	Green	Blink (1:3) Communication in progress ON = approx. 0.5 sec, OFF = approx. 1.5 sec Blink (1:1) Communication not in progress ON = approx. 0.25 sec, OFF = approx. 0.25 sec
ALM (Total edition 05B or later)	Red	Not used

## 4.5 PROCESS I/O BOARD JB (A16B-2204-0011)







#### Fig.4.5 (b) Process I/O Board JB (Total edition 05B or later)

#### (1) Test pins

Name		Use
P24V	+24V	For measuring the DC supply voltage
P5V	+5V	
GND1	GND	
GND2	GND	
P3V (Total edition 05B or later)	+3.3V	

#### (2) Settings

Name		Standard setting	Description
ICOM1	UDI1 to 20 (Connector CRMA5A)	Side A	Set the common voltage Side A: +24 V common
ICOM2	UDI21 to 40 (Connector CRMA5B)		Side B: 0 V common

#### (3) LEDs

	Color	Description
PROCESS //O PCB STATUS 1 2 8 4 ALARM	Red	A communication alarm occurred between the main board and process I/O board.

#### 4. PRINTED CIRCUIT BOARDS MAINTENANCE


	Color	Description
PROCESS	Red	A fuse (FUSE 1) in the process I/O board blew.
LINK (Total edition 05B or later)	Green	Blink (1:3) Communication in progress ON = approx. 0.5 sec, OFF = approx. 1.5 sec Blink (1:1) Communication not in progress ON = approx. 0.25 sec, OFF = approx. 0.25 sec
ALM (Total edition 05B or later)	Red	Not used

#### NOTE

Installation of Process I/O board JA, JB

1st Process I/O board is installed to slot 3, and 2nd Process I/O board is installed to slot 2.

If both Process I/O board JA and JB are installed, Process I/O board JA is installed to slot 2, and Process I/O board JB is installed to slot 3.



# **4.6** PROCESS I/O BOARD MA (A20B-2004-0380, A20B-2004-0381)




Fig.4.6 (a) Process I/O Board MA (Total edition 02A or earlier)




Fig.4.6 (b) Process I/O Board MA (Total edition 04B or later)

#### (1) Test pins

Name		Use
P24V	+24V	
P5V	+5V	For measuring the DC supply voltage
GND	GND	
P33V (Total edition 04B or later)	+3.3V	

### 4. PRINTED CIRCUIT BOARDS MAINTENANCE

#### (2) Settings

Name		Standard setting	Description	
ICOM1		UDI1- 10 (Connector CRMA52A)	Side A	For common voltage setting Side A: +24V common
ICOM2		UDI11- 20 (Connector CRMA52B)		Side B: 0V common

#### (3) LEDs

Name	Color	Description
ALM1	Red	A communication alarm occurred between the main board and process I/O board.
FALM	Red	The fuse (FUSE1) on the process I/O board has blown.
LINK (Total edition 04B or later)	Green	Blink (1:3) Communication in progress ON = approx. 0.5 sec, OFF = approx. 1.5 sec Blink (1:1) Communication not in progress ON = approx. 0.25 sec, OFF = approx. 0.25 sec
ALM (Total edition 04B or later)	Red	Not used

# 4.7 PROCESS I/O BOARD MB (A20B-2101-0730, A20B-2101-0731)






Fig.4.7 (a) Process I/O Board MB (Total edition 02A or earlier)





#### (1) Test pins and pads

Name		Use
24V	+24V	
5V	+5V	For measuring the DC supply voltage
GND	GND	
3R3V (Total edition 04B or later)	+3.3V	
P24VF	+24V	
P5VF	+5V	D/A converter power supply
GNDF	GND	
AOUT1	Channel 1	For analog output signal (D/A) voltage measurement
AOUT2	Channel 2	

#### 4. PRINTED CIRCUIT BOARDS MAINTENANCE

- (2) Adjustment
  - VR1/VR2 Channel 1 gain and offset adjustment

Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT1 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT[1]=3413, using a robot program. While observing the voltage at the AOUT1 check pin with the digital voltmeter, adjust potentiometers VR1 and VR2 for 15.0V.

VR3/VR4 Channel 2 gain and offset adjustment


Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT2 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT[2]=3413, using a robot program. While observing the voltage at the AOUT2 check pin with the digital voltmeter, adjust potentiometers VR3 and VR4 for 15.0V.

(3) LEDs


Name	Color	Description
ALM1	Red	A communication alarm occurred between the main CPU and process I/O board.
FALM	Red	The fuse (FUSE1) on the process I/O board has blown.
LINK (Total edition 04B or later)	Green	Blink (1:3) Communication in progress ON = approx. 0.5 sec, OFF = approx. 1.5 sec Blink (1:1) Communication not in progress ON = approx. 0.25 sec, OFF = approx. 0.25 sec
ALM (Total edition 04B or later)	Red	Not used



### PROCESS I/O BOARD KA (A20B-2101-0560)



#### Fig.4.8 (a) Process I/O Board KA (Total edition 02A or earlier)



MAINTENANCE

Fig.4.8 (b) Process I/O Board KA (Total edition 03B or later)

(1) Meanings of check pins		
Name		Use
P24V	+24V	
P5V	+5V	
P15V	+15V	
N15V	-15V	
GND1	GND	For DC power measurement
GND2	GND	
GND3	GND	
GND4	GND	
P3R3V (Total edition 03B or later)	+3.3V	
P5VF	+5V	
P24VF	+24V	D/A converter power supply
GNDF	GND	
Al1	Channel 1	For onelog input signal (A/D) voltage measurement
AI2	Channel 2	For analog input signal (A/D) voltage measurement
AOUT1	Channel 1	
AOUT2	Channel 2	For analog output signal (D/A) voltage measurement
AOUT3	Channel 3	

#### (2) Setting

	Name	Standard setting	Use
ICOM1	UDI1 to 20 (Connector CRMA5A)	Side A	For common voltage setting Side A: +24 V common
ICOM2	UDI21 to 40 (Connector CRMA5B)		Side B: 0 V common
ICOM3	WI01 to 08 (Connector CRW10)		

- (3) Adjustment
  - VR1/VR2: Channel 1 gain and offset adjustment

Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT1 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT [1]=3413, using a robot program. While observing the voltage at the AOUT1 check pin with the digital voltmeter, adjust potentiometers VR1 and VR2 for 15.0 V.

VR3/VR4: Channel 2 gain and offset adjustment

Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT2 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT [2]=3413, using a robot program. While observing the voltage at the AOUT2 check pin with the digital voltmeter, adjust potentiometers VR3 and VR4 for 15.0 V.

#### VR5/VR6: Channel 3 gain and offset adjustment

Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT3 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT [3]=3413, using a robot program. While observing the voltage at the AOUT3 check pin with the digital voltmeter, adjust potentiometers VR5 and VR6 for 15.0 V.

(4) Meaning of LEDs

	Color	Meaning
	Red	A communication alarm occurred between the main CPU and the process I/O board.
ALMO FALM	Red	The fuse (FUSE1) on the process I/O board has blown.
LINK (Total edition 03B or later)	Green	Blink (1:3) Communication in progress ON = approx. 0.5 sec, OFF = approx. 1.5 sec Blink (1:1) Communication not in progress ON = approx. 0.25 sec, OFF = approx. 0.25 sec
ALM (Total edition 03B or later)	Red	Not used

(5) Correspondence between driver ICs and DO signals
 Driver IC specification: DRV1, DRV2: A76L-1151-0167
 DV1: A76L-1151-0070

Driver IC name	DO signal name
DRV1	CMDENBL, SYSRDY, PROGRUN, PAUSED
	HELD, FAULT, ATPERCH, TPENBL
	BATALM, BUSY, ACK1/SNO1, ACK2/SNO2
	ACK3/SNO3, ACK4/SNO4, ACK5/SNO5, ACK6/SNO6

#### MAINTENANCE 4. PRINTED CIRCUIT BOARDS

Driver IC name	DO signal name
DRV2	ACK7/SNO7, ACK8/SNO8, SNACK, RESERVED
	DO01, DO02, DO03, DO04
	DO05, DO06, DO07, DO08
	DO09, DO10, DO11, DO12
DV1	DO13, DO14, DO15, DO16
	DO17, DO18, DO19, DO20

### 4.9 PROCESS I/O BOARD KB (A20B-2101-0561)




Fig.4.9 (a) Process I/O Board KB (Total edition 02A or earlier)

#### 4. PRINTED CIRCUIT BOARDS

MAINTENANCE




Fig.4.9 (b) Process I/O Board KB (Total edition 03B or later)

(1)	Meanings	of	check	pins
( - /	meanings	<b>U</b> 1	encen	PILLO

Name		Use
P24V	+24V	
P5V	+5V	
GND1	GND	
GND2	GND	For DC power measurement
GND3	GND	
GND4	GND	
P3R3V (Total edition 03B or later)	+3.3V	
P5VF	+5V	
P24VF	+24V	D/A converter power supply
GNDF	GND	
AOUT1	Channel 1	
AOUT2	Channel 2	For analog output signal (D/A) voltage measurement

#### (2) Setting

	Name	Standard setting	Use
ICOM1	UDI1 to 20 (Connector CRMA5A)	Side A	For common voltage setting Side A: +24 V common
ICOM2	UDI21 to 40 (Connector CRMA5B)		Side B: 0 V common
ICOM3	WI01 to 08 (Connector CRW10)		

MAINTENANCE

- (3) Adjustment
  - VR1/VR2: Channel 1 gain and offset adjustment

Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT1 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT [1]=3413, using a robot program. While observing the voltage at the AOUT1 check pin with the digital voltmeter, adjust potentiometers VR1 and VR2 for 15.0 V.

VR3/VR4: Channel 2 gain and offset adjustment

Connect the "+" and "-" terminals of a digital voltmeter, respectively, to the AOUT2 check pin and the GNDF check pin (not a general ground point). From the teach pendant, execute AOUT [2]=3413, using a robot program. While observing the voltage at the AOUT2 check pin with the digital voltmeter, adjust potentiometers VR3 and VR4 for 15.0 V.

(4) Meaning of LEDs

	Color	Meaning
	Red	A communication alarm occurred between the main CPU and the process I/O board.
ALMO FALM	Red	The fuse (FUSE1) on the process I/O board has blown.
(Total edition 03B or later) Green ON = approx. 0.5 sec, 0 Blink (1:1) Communication		Blink (1:3) Communication in progress ON = approx. 0.5 sec, OFF = approx. 1.5 sec Blink (1:1) Communication not in progress ON = approx. 0.25 sec, OFF = approx. 0.25 sec
ALM (Total edition 03B or later) Red Not used		Not used

(5) Correspondence between driver ICs and DO signals
 Driver IC specification: DRV1, DRV2: A76L-1151-0167
 DV1: A76L-1151-0070

Driver IC name	DO signal name
DRV1	CMDENBL, SYSRDY, PROGRUN, PAUSED
	HELD, FAULT, ATPERCH, TPENBL
	BATALM, BUSY, ACK1/SNO1, ACK2/SNO2
	ACK3/SNO3, ACK4/SNO4, ACK5/SNO5, ACK6/SNO6
DRV2	ACK7/SNO7, ACK8/SNO8, SNACK, RESERVED
	DO01, DO02, DO03, DO04
	DO05, DO06, DO07, DO08
	D009, D010, D011, D012
DV1	DO13, DO14, DO15, DO16
	DO17, DO18, DO19, DO20

# <u>5</u>

## 6-AXIS SERVO AMPLIFIERS

The servo amplifiers are factory-set for operation. Usually, you do not need to set or adjust them. This chapter describes the standard settings and adjustment required if a defective servo amplifier is replaced. It also describes the use of test pins and meanings of the LED indications.

Table 5(a) Serve		DISCHARGE REGISTOR		
ROBOT	SERVO AMPLIFIER	A-CABINET	<b>B-CABINET</b>	
M-900 <i>i</i> A/400L,600 M-900 <i>i</i> B/700,360,400L,280L	A06B-6400-H101(AMP1) A06B-6240-H209(AMP2) A06B-6240-H105(AMP3)		A05B-2603-C100	
R-2000 <i>i</i> B/200T,220U,220US M-900 <i>i</i> A/260L,350 M-410 <i>i</i> B, M-410 <i>i</i> C	A06B-6400-H101	A05B-2601-C102	A05B-2603-C100	
M-900 <i>i</i> A/150P	A06B-6400-H101		A05B-2603-C100	
R-2000 <i>i</i> B/100P	A06B-6400-H102		A05B-2603-C100	
R-1000iA(Except /80H,120F-7B) R-2000iB (Except /200T,220U,220US,100P) M-710iC(Except /50H) M-20iA M-20iB ARC Mate 120iC CR-35iA	A06B-6400-H102	A05B-2601-C100	A05B-2603-C100	
R-2000 <i>i</i> C/125L/165F/210F	A06B-6400-H002	A05B-2601-C100	A05B-2603-C100	
R-2000 <i>i</i> C/210L/270F	A06B-6400-H101	A05B-2601-C102	A05B-2603-C100	
R-2000 <i>i</i> C/165R/210R	A06B-6400-H102	A05B-2601-C100	A05B-2603-C100	
M-420 <i>i</i> A, M-421 <i>i</i> A M-710 <i>i</i> C/50H, R-1000 <i>i</i> A/80H	A06B-6400-H102	A05B-2601-C102	A05B-2603-C100	
M-2iA	A06B-6400-H002	A05B-2601-C100		
M-3iA	A06B-6400-H102	A05B-2601-C100		
ARC Mate 100 <i>i</i> C M-10 <i>i</i> A F-200 <i>i</i> B	A06B-6400-H003	A05B-2601-C100	A05B-2603-C100	
M-430 <i>i</i> A/4FH	A06B-6400- H004(AMP1) A06B-6240-H201(AMP2)	A05B-2601-C100	A05B-2603-C100	
M-430 <i>i</i> A/2P,2PH	A06B-6400- H004(AMP1) A06B-6240-H301(AMP2)	A05B-2601-C100	A05B-2603-C100	
M-900 <i>i</i> A/200P	A06B-6400-H101(Main,AMP1) A06B-6400-H101(2nd,AMP1)		A05B-2603-C100	
M-2000 <i>i</i> A	A06B-6400-H101(Main,AMP1) A06B-6240-H106(Main,AMP2) A06B-6400-H101(2nd,AMP1) A06B-6240-H106(2nd,AMP2)		A05B-2603-C100	
R-1000 <i>i</i> A/120F-7B	A06B-6400-H101(AMP1) A06B-6240-H106(AMP2)	A05B-2601-C102	A05B-2603-C100	


#### Table 5(a) Servo amplifier specification (Resistor discharge)

### MAINTENANCE 5. 6-AXIS SERVO AMPLIFIERS

	Servo amplifier specificatio		REGENERATIVE REGISTOR		
ROBOT	SERVO AMPLIFIER	POWER			
		SUPPLY	A-CABINET	B-CABINET	
M-900 <i>i</i> A/400L,600	A06B-6400-H101(AMP1)	A06B-6200-H037		A05B-2603-C101	
M-900iB/700,360,400L	A06B-6240-H209(AMP2)				
	A06B-6240-H105(AMP3)				
R-2000iB/200T,220U,220US	A06B-6400-H101	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
M-900iA/260L,350,150P					
M-410 <i>i</i> B, M-410 <i>i</i> C					
R-1000 <i>i</i> A	A06B-6400-H102	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
(Except 120F-7B)					
R-2000 <i>i</i> B					
(Except /200T,220U,220US)					
M-710 <i>i</i> C					
M-420 <i>i</i> A, M-421 <i>i</i> A					
R-2000 <i>i</i> C/125L/165F/210F	A06B-6400-H002	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
R-2000 <i>i</i> C/210L/270F	A06B-6400-H101	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
R-2000 <i>i</i> C/165R/210R	A06B-6400-H102	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
M-2iA	A06B-6400-H002	A06B-6200-H015	A05B-2601-C101		
M-3iA	A06B-6400-H102	A06B-6200-H015	A05B-2601-C101		
M-900 <i>i</i> A/200P	A06B-6400-H101(Main,AMP1)	A06B-6200-H015		A05B-2603-C101	
	A06B-6400-H101(2nd,AMP1)				
M-2000 <i>i</i> A	A06B-6400-H101(Main,AMP1)	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
	A06B-6240-H106(Main,AMP2)				
	A06B-6400-H101(2nd,AMP1)				
	A06B-6240-H106(2nd,AMP2)				
R-1000 <i>i</i> A/120F-7B	A06B-6400-H101(AMP1)	A06B-6200-H015	A05B-2601-C101	A05B-2603-C101	
	A06B-6240-H106(AMP2)				

Table 5(b	) Servo amplifier	specification	(Power supply	regeneration)
100100		opeenieatien	(i ener euppij	regeneration)

#### Check that the voltage is not higher than 50V.




#### 

Before touching the servo amplifier, for example, for maintenance purposes, check the voltage at the screw above the LED "V4" with a DC voltage tester to see if the remaining voltage is not higher than 50V.

#### 5. 6-AXIS SERVO AMPLIFIERS

# 5.1 LEDS OF 6-AXIS SERVO AMPLIFIER




LED	Color	Description
V4	Red	Lights when the DCLINK circuit inside the servo amplifier is charged to reach a specific
		voltage.
SVALM	Red	Lights when the servo amplifier detects an alarm.
SVEMG	Red	Lights when an emergency stop signal is input to the servo amplifier.
DRDY	Green	Lights when the servo amplifier is ready to drive the servo motor.
OPEN	Green	Lights when the communication between the servo amplifier and the main board is normal.
P5V	Green	Lights when the power supply circuit inside the servo amplifier outputs a voltage of +5 V
		normally.
P3.3V	Green	Lights when the power supply circuit inside the servo amplifier outputs a voltage of +3.3 V
		normally.

## 5.2 SETTING OF 6-AXIS SERVO AMPLIFIER

#### Table 5.2 Settings

Name	Standard setting	Description		
COM1	Side A	Robot Digital Input (RI) device common voltage. Side A: +24V common Side B: 0V common		






Fig.5.2 Circuit based on jumper pin location or setting of switch

## 5.3

### 6-AXIS SERVO AMPLIFIER SPECIFICATIONS

### SPECIFICATIONS TABLE : (A06B-6400-H\*\*\*)

UNIT		A06B-6400-H101	A06B-6400-H102	A06B-6400-H002		
INPUT	VOLTAGE	AC200 to AC240V ( +10% / -15% ), 50/60Hz, 3phase				
RATINGS	POWER CAPACITY	5.6KVA	5.1KVA	5.1KVA		
OUTPUT	MAXIMUM OUTPUT	240V to				
RATINGS	CURRENT : J1	160Ap / 36.5Arms	80Ap / 23.0Arms	80Ap / 23.0Arms		
	CURRENT : J2	160Ap / 36.5Arms	80Ap / 23.0Arms	80Ap / 23.0Arms		
	CURRENT : J3	160Ap / 36.5Arms	80Ap / 23.0Arms	80Ap / 23.0Arms		
	CURRENT : J4	40Ap / 13.4Arms	40Ap / 13.4Arms	40Ap / 13.4Arms		
	CURRENT : J5	40Ap / 13.4Arms	40Ap / 13.4Arms	40Ap / 13.4Arms		
	CURRENT : J6	40Ap / 13.4Arms	40Ap / 13.4Arms	40Ap / 13.4Arms		
	TOTAL CURRENT	125Arms	90Arms	90Arms		


UNIT		A06B-6400-H003	A06B-6400-H004
INPUT	VOLTAGE	AC200 to AC240V ( +10% / -15% ), 50/60Hz, 3phase	
RATINGS	POWER CAPACITY	2.7KVA	2.0KVA
OUTPUT	MAXIMUM OUTPUT	240V to	
RATINGS	CURRENT : J1	40Ap / 13.4Arms	20Ap / 6.5Arms
	CURRENT : J2	40Ap / 13.4Arms	20Ap / 6.5Arms
	CURRENT : J3	20Ap / 6.5Arms	20Ap / 6.5Arms
	CURRENT : J4	20Ap / 6.5Arms	20Ap / 6.5Arms
	CURRENT : J5	20Ap / 6.5Arms	20Ap / 6.5Arms
	CURRENT : J6	20Ap / 6.5Arms	20Ap / 6.5Arms
	TOTAL CURRENT	52.8Arms	39Arms


UNIT		A06B-6400-H005	
INPUT	VOLTAGE	AC200 to AC240V ( +10% / -15% ), 50/60Hz,3/1phase	
RATINGS	POWER CAPACITY	1.3/1.4 ( 3/1phase )	
OUTPUT	MAXIMUM OUTPUT	240V to	
RATINGS	CURRENT : J1	20Ap / 3.6Arms	
	CURRENT : J2	20Ap / 3.6Arms	
	CURRENT : J3	20Ap / 3.6Arms	
	CURRENT : J4 CURRENT : J5 CURRENT : J6	20Ap / 3.6Arms	
		10Ap / 2.0Arms	
		10Ap / 2.0Arms	
	TOTAL CURRENT	18.4Arms	

# 6 POWER SUPPLY

Setting and adjustment of the power supply is factory-set for operation. Usually, you do not need to set or adjust it.

### 6.1 BLOCK DIAGRAM OF THE POWER SUPPLY









Fig.6.1 (b) Block diagram of the power supply (R-30*i*B Plus)


# 6.2 TRANSFORMER

Select a transformer and tap according to the supply voltage. Select a transformer tap based on the rated voltage.

A-cabinet					
	Rated	Transformer specification			
	voltage	13.0KVA	10.5KVA	7.5KVA	3KVA
	500 to 575				
TYPE E	440 to 500		A80L-0028-0024#A	A80L-0026-0040#A	A80L-0024-0028
	380 to 415				
TYPE D	200 to 230		A80L-0028-0027#A	A80L-0026-0041#A	A80L-0024-0029
TIPED	380 to 400		AOUL-UU20-UU21#A	AOUL-UU20-UU4 1#A	A00L-0024-0029


B-cabinet					
	Rated		Transforme	er specification	
	voltage	13.0KVA	10.5KVA	7.5KVA	3KVA
	500 to 575	A80L-0028-0025	A80L-0028-0024	A80L-0026-0040	A80L-0024-0028
TYPE E	440 to 500				
	380 to 415				
TYPE D	200 to 230	A80L-0028-0028	A80L-0028-0027	A80L-0026-0041	A80L-0024-0029
TIPED	380 to 400				





(A-cabinet)


(B-cabinet)






#### Cabinet side connector


#### 1. TYPE E (500V-575V)



#### 2. TYPE E (440V-500V)



#### 3. TYPEE (380V-415V)




#### Fig.6.2(b) Setting the input voltage

1	Type E: 500-575V	Insert the connector connected to the circuit breaker into connector LA and the dummy plug into connectors LB and LC.	
2	Type E: 440-500V	Insert the connector connected to the circuit breaker into connector LE and the dummy plug into connectors LA and LC.	
3	Type E: 380-415V	Insert the connector connected to the circuit breaker into connector LC and the dummy plug into connectors LA and LB.	
4	Type D: 380-400V	Insert the Y connection cable connected to the circuit breaker into connectors LA and LB.	
5	Type D: 200-230V	Insert the $\Delta$ connection cable connected to the circuit breaker into connectors LA and LB.	


#### 

The secondary voltage of the transformer depends on the cable connection between a breaker and a transformer. Be careful to choose the correct connection if maintenance is necessary.

4. TYPE D (380V-400V)



#### 5. TYPE D (200V-230V)



### 6.3

### CHECKING THE POWER SUPPLY UNIT (A16B-2203-0910)

The power supply unit need not be set or adjusted.

Table 6.3 Rating of the Power supply unit				
Output	Rated voltage	Tolerance		
+5V	+5.1V	±3%		
+3.3V	+3.3V	±3%		
+2.5V	+2.5V	±3%		
+24V	+24V	$\pm 5\%$		
+24E	+24V	±5%		
+15V	+15V	±10%		
-15V	-15V	±10%		





Fig.6.3 Interface of the power supply unit

# SENSOR I/F UNIT FOR CR-35*i*A

Specification of sensor I/F unit: A05B-2600-C320





# 8 REPLACING UNITS

This section explains how to replace each unit in the control section.

#### 

Before you start to replace a unit, turn off the controller main power. Also keep all machines in the area of the controller switched to off. Otherwise, you could injure personnel or damage equipment.

#### 

Before replacing components, read and follow procedures in the robot or controller-specific maintenance manual to understand replacement procedures. Performing an incorrect replacement procedure can lead to an unpredictable accident, resulting in breakage in the robot or personal injury.

#### 

When a heavy component or unit is to be handled, provide the workers with a crane or the like so as not to apply excessive loads to the workers. Note that incorrect handling can cause serious injury to the workers.

#### 

Components in the controller heat up, so care should be taken. When you have to touch a heated component, use appropriate protective equipment such as heat-resistant gloves, a face shield, or body suit if necessary.

Before replacing a component, please refer to "SAFETY PRECAUTION" chapter of this manual.

### 8.1 REPLACING THE PRINTED-CIRCUIT BOARDS

#### 

When you replace printed-circuit boards, observe the following cautions: 1 Keep the controller power switched off.

- 2 When you remove a printed-circuit board, do not touch the semiconductor devices on the board with your hand or make them touch other components.
- 3 Make sure that the replacement printed-circuit board has been set up appropriately. (Setting plug etc.)
- 4 After replacing a printed-circuit board, make adjustments correctly if the board needs to be adjusted.
- 5 If the backplane board, power supply unit, or main board (including cards and modules) is replaced, it is likely that robot parameters and taught data are lost. Before you start to replace these components, save a backup copy of the robot parameters and taught data to an external memory device.
- 6 Before you disconnect a cable, note its location. If a cable is detached for replacement, reconnect it exactly as before.

### **8.1.1** Replacing the Backplane Board (Unit)

When replacing the backplane board, do so together with the plastic rack.

(1) Detach the cables from the power unit and boards on the backplane board.

#### 

When you remove the main board, be sure that the battery is good (3.1-3.3VDC) and it is installed correctly. USE STATIC PROTECTION.

- (2) Remove the power supply unit and boards from the backplane (rack).
- (3) Detach the grounding cable from the backplane unit.
- (4) Loosen the retaining screws in the upper section of the rack. Remove the retaining screws from the lower section of the rack.
- (5) Slide the rack up and out.
- (6) To replace the backplane and rack, reverse steps (1) (5).

#### 

There is a possibility of data loss when a backplane- mounted printed circuit board is replaced. Be sure to back up all program and setup data on an external device such as a memory card before proceeding.


# 8.1.2 Replacing the Power Unit and Printed-Circuit Boards on the Backplane


The backplane incorporates the power unit, main board, and option boards. There are two types of option boards: Full-size board and mini-size board. A full-size board occupies one slot. A mini-size board uses part of a full-size board.

#### 

Before starting replacement, turn off the controller main power. The main board is equipped with battery-backed memory devices for holding robot parameters and taught data. When the main board is replaced, the data in the memory devices is lost.

- (1) Detach the cable from the power supply unit or the printed-circuit board, whichever is to be replaced.
- (2) Pinch the barbed handles on the upper and lower sections of the board to unlatch it, then pull it toward you.
- (3) Place the replacement board on the rail in the appropriate slot of the rack, then push it in gently by the handles until it is latched.
- (4) There are two rails in the main board SLOT (slot 1). When inserting the main board, align it to the right-side rail.
- (5) There are two rails in slots 3 (slots for a full-size option board). When you insert a full-size option board, align it to the left-side rail.








Fig.8.1.2 (b) Replacing the power unit and printed-circuit boards on the backplane


# 8.2 REPLACING CARDS AND MODULES ON THE MAIN BOARD

#### 

Before you start to replace a card or module, make a backup copy of robot parameters and programs. If the FROM/SRAM module is replaced, SRAM memory contents are lost.

#### **Demounting a Card**

- 1. Pull up the spacer metal fitting. (Fig. 8.2 (a))
- 2. Insert a finger into the rear of the card and pull up the card slowly in the arrow direction. (Fig. 8.2 (b) (Note: At this time, hold the main board on the opposite side with the other hand whenever possible. A force of 7 to 8 kgf is required for extraction.)
- 3. When one side of the card board is raised slightly by pulling up, do not fully extract the card board, but push back the card softly.
- 4. When the card board is pushed back to be parallel with the main board, pinch two sides of the card board and pull up the card board. This completes the extraction of the card board.



#### Fig.8.2 (a) Demounting a card





Fig.8.2 (b) Demounting a card

#### **Mounting a Card**

- 1. Check that the metal fittings of the spacers are raised. (Fig.8.2 (c))
- 2. To align the board insertion position, touch the spacer end faces of the board with the spacer. (Fig. 8.2 (d)) (At this time, the board is touching the spacers only.)
- 3. While aligning the board with the spacers, lower the connector side slowly until the connectors touch each other. (Fig.8.2 (d)) (do not press until aligned.)
- 4. The mating position can be determined more easily by moving the card back and forth until the alignment "nubs" and "holes" are aligned on the connectors. The board must be turned to view the board connectors on the side. (Fig.8.2 (d))
- 5. At this time, push on the back of the board over the connector. The force required for connector insertion is about 10 kgf. If the connector will not insert easily, re-check the alignment of the connector to prevent damaging the connector(s). If installing a standard CPU CARD, do not press on the heat sink installed on the CPU and LSI chip. Otherwise, the CPU or LSI chip can be damaged. (Fig.8.2 (e))
- 6. Push in the spacer metal fitting to lock the board in place. (Fig.8.2 (f))








Fig.8.2 (d) Mounting a card




Fig.8.2 (f) Mounting a card

#### Demounting a module

#### 

When replacing the module, be careful not to touch the module edge connector. If you touch the edge connector inadvertently, wipe any dirt off of the contact with a clean cloth.

- (1) Move the clip of the socket outward. (a)
- (2) Extract the module by raising it at a 30 degree slant and pulling outward.

#### Mounting a module

(a)

- (1) Insert the module at a 30 degree slant into the module socket, with side B facing upward. (b)
- (2) Push the module inward and downward until it is locked. (c)






Fig.8.2 (g) Demounting/mounting a module

Figure 8.3 (h) shows the locations of the cards and modules.






(R-30*i*B main board) (R-30*i*B Plus main board) Fig.8.2 (h) Locations of cards and modules


## 8.3 REPLACING THE E-STOP UNIT

- (1) Detach the cables from the E-stop unit.
- (2) Loosen 1-retaining screw and 3-M5 screws, and replace the E-stop unit.(A-cabinet) Remove 4-M4 screws, and replace the E-stop unit.(B-cabinet)
- (3) Reconnect the cables.



## 8.4 REPLACING THE EMERGENCY STOP BOARD

- (1) Detach the cables from the emergency stop board unit.
- (2) Unlock the nylon latches (5 places) holding the board, and replace the board.
- (3) Reconnect the cables.



(A-cabinet)

(B-cabinet)


## 8.5 REPLACING THE TRANSFORMER

#### 

The transformer is heavy. When replacing the transformer, be careful not to cause injury. (The transformer weighs 45 to 60 kg.)


#### In case of A-cabinet

(1) Disconnect all cables from the transformer input connector panel.





- (2) Remove the rear fan unit.
- (3) Remove the regenerative resister.

(4) Remove the rear panel. Remove (6)-M4 screws and (4)-M10 bolts.



(5) Remove (4)-screws from the transformer input connector panel, and remove the (2)-M6 screws at the foot of the transformer. Then replace the transformer.






(2)-screws for the transformer


(6) Install a replacement transformer by reversing above steps.

#### In case of B-cabinet


(1) Disconnect all cables from the transformer input connector panel.



(2) Remove the rear panel. Remove (8)-M4 screws.



(3) Remove (4)-screws from the transformer input connector panel, and remove the (2)-M6 screws at the foot of the transformer. Then replace the transformer.



- (4) Install a replacement transformer by reversing above steps.


## 8.6 REPLACING THE REGENERATIVE RESISTOR UNIT

#### 


Before you start, turn off the controller main power. Be careful not to get burned, because the regenerative resistor unit is very hot immediately after operation.

#### In case of A-cabinet


(1) Unplug CRR63A/B and CRR11A/B connectors from the servo amplifier. In case the cables of these connectors were fastened by cable ties, cut the cable ties to free the cables.



(2) Remove the side panel and the louver from the A-cabinet.




(3) Loosen two screws near the rear fan unit and lift up the regenerative resister unit so that it comes off from the rear panel of the cabinet.



#### 8. REPLACING UNITS

(4) Remove four screws at the cord grip panel and pull out the cable together with the panel. Then the regenerative resister unit is separated from A-cabinet.



(5) Install a replacement unit by reversing above procedure.

#### In case of B-cabinet

- (1) Remove the servo amplifier. (See Section 8.7)
- (2) Remove the cord grip panel securing the cable of the regenerative resistor.
- (3) If a cable is fastened with cable ties, cut them with a diagonal cutter to release the cable. Be careful not to damage the cable.
- (4) Of the two nuts fastening the regenerative resistor, remove the upper nut, loosen the lower nut, and then remove the regenerative resistor.




Fig. 8.6 Regenerative resister

(5) Install a replacement unit by reversing above procedure.

## 8.7 REPLACING SERVO AMPLIFIERS

#### 


Before touching the servo amplifier, for example, for maintenance purposes, check the voltage at the screw above the LED "V4" with a DC voltage tester to see if the remaining voltage is not higher than 50V.

#### 

Because the servo amplifier is heated immediately after operation, leave the servo amplifier until it cools down thoroughly, before replacing it.

#### In case of A-cabinet

(1) Check the voltage at the screw above the LED "V4" with a DC voltage tester to see if the remaining voltage is not higher than 50V.



#### Check that the voltage is not higher than 50V.

- (2) Detach the cables from the servo amplifier. Pull out the detached cables away from the amplifier.
- (3) Loosen 2-retaining screws at the upper side of the servo amplifier.
- (4) Hold the handle at the upper side of the amplifier and pull to tilt it.
- (5) Lift up the amplifier and pull out from the cabinet.
- (6) Install a replacement amplifier by reversing above procedure.




Fig.8.7(a) Replacing the servo amplifier (A-cabinet)

In case of an exchange of an amplifier is difficult by a procedure of figure 8.7(a).


(1) Check the voltage at the screw above the LED "V4" with a DC voltage tester to see if the remaining voltage is not higher than 50V.

LED : V4 (red) 0 [ \_ \_ \_ \_ \_ \_ ] 6 6 0 0 P. 0 o Π ô 0 -----.===. ľ 0 .==-. 0 -0 ۰ i i i l'-l-T-'


Check that the voltage is not higher than 50V.


- (2) Detach the cables from the servo amplifier. Pull out the detached cables away from the amplifier.
- (3) Loosen 2-retaining screws at the upper side of the servo amplifier.
- (4) Hold the handle at the upper side of the amplifier and pull to tilt it.
- (5) Lift up the amplifier and pull the side handle.
- (6) Lift up the amplifier and pull out from bottom side.
- (7) Install a replacement amplifier by reversing above procedure.

(2) Pull out the cables from the cabinet.




(3) Loosen (2)-retaining screws.







(4) Pull the handle.



(5) Lift up and Pull the lower handle.



(6) Pull out from bottom side.




#### B-83195EN/09


#### In case of B-cabinet


- (1) Make sure that servo amplifier shipping screws (2cross-head) have been removed. Retain screws for shipping purposes.
- (2) Check the voltage at the screw above the LED "V4" with a DC voltage tester to see if the remaining voltage is not higher than 50V.

Check that the voltage is not higher than 50V.



- (3) Remove the cover from servo amplifier.
- (4) Detach the cables from the servo amplifier. Pull out the detached cables away from the amplifier.
- (5) Loosen 2-retaining screws at the upper side of the servo amplifier.
- (6) Hold the handle at the upper side of the amplifier and pull to tilt it.
- (7) Lift up the amplifier and pull out from the cabinet.
- (8) Install a replacement amplifier by reversing above procedure.








Fig.8.7(c) Replacing the servo amplifier (B-cabinet)

## 8.8 REPLACING I/O UNIT-MODEL A

### 8.8.1 Replacing the Base Unit of I/O Unit-MODEL A

First, remove the modules from the base unit of I/O Unit-MODEL A. The base unit is retained with 4 screws. Of these screws, loosen the upper 2 screws and remove the lower 2 screws, then replace the base unit.




Fig.8.8.1 Replacing the base unit of I/O unit model A

#### 8.8.2 Replacing a Module

An interface module and input/output module can be easily installed in and removed from the base unit, as described below.

#### Installing a module

- (1) Put the upper hook of the module into the upper hole of the base unit.
- (2) Fit the connectors of the module and the base unit to each other.
- (3) Push the module until the lower stopper of the module is caught in the lower hole of the base unit.

#### Removing a module

- (1) Press the lever at the bottom of the module to release the stopper.
- (2) Lift the module up.





Fig.8.8.2 Replacing the module

## 8.9 REPLACING THE TEACH PENDANT

The specifications of the teach pendant vary with its use. When you replace the teach pendant, check its specifications carefully.

- (1) Be sure that the power of the robot controller is off.
- (2) Detach the cable from the teach pendant.
- (3) Replace the teach pendant.



connector retaining ring.

Fig.8.9 Replacing the teach pendant - 150 -

#### B-83195EN/09

## 8.10 REPLACING THE CONTROL SECTION FAN MOTOR

The control section fan motor can be replaced without using a tool. The fan motor is mounted on the fan unit rack.

- (1) Be sure that the power of a robot controller is off.
- (2) Put your finger in the dent in the upper section of the fan unit, and pull the fan unit until it is unlatched.
- (3) Lift the fan unit slightly, and dismount it from the rack.
- (4) Place a replacement fan on the upper section of the rack, and slide it gently until it is latched.




Fig.8.10 Replacing the control section fan motor

## 8.11 REPLACING THE AC FAN MOTOR

#### 

Do not touch the fan motor when it is rotating, or you could be injured.

### **8.11.1** Replacing the Heat Exchanger and Door Fan Unit (A-cabinet)

The heat exchanger of the A-cabinet is inside its door. To replace the heat exchanger, it is necessary to remove the door fan unit in advance.

#### Door fan unit

- (1) Remove retaining screws (M4, 4 places).
- (2) Disconnect the connector at the FAN.
- (3) Mount the replacement fan unit by reversing above procedure. Be careful not to let the cable get caught in the fan.

#### Heat exchanger

- (1) Dismount the door fan unit. (See the above procedure.)
- (2) Open the A-cabinet door, and detach cables.
- (3) Remove retaining nuts (M5, 4 places), and dismount the unit.
- (4) Mount the replacement unit by reversing above procedure.





Fig.8.11.1 Replacing the heat exchanger and door fan unit (A-cabinet)

#### B-83195EN/09

### 8.11.2 Replacing Rear Fan Unit (A-cabinet)

- (1) Loosen the 4-screws(M4) of the louver, then remove it.
- (2) Loosen 4-screws(M4) , and then detach the fan unit.
- (3) Unplug the connector at the cabinet.
- (4) Mount the replacement unit by reversing above procedure.



Pinch and pull the connector hood to unplug the connector.





Fig.8.11.2 Replacing rear fan unit (A-cabinet)

### 8.11.3 Replacing External Fan Unit and Door Fan (B-cabinet)

#### Door fan


- (1) Detach the cable from the fan unit.
- (2) Remove the retaining screws from the fan unit, then dismount it.
- (3) Install a new fan unit by reversing the dismounting procedure.



#### (Replacing the Door Fan Unit)

#### External fan unit

- (1) Detach the cable connecting the fan unit.
- (2) Remove the screws and pull out the fan unit toward you.
- (3) Install a new fan unit by reversing the dismounting procedure.



(Replacing the External Fan Unit)

## 8.12 REPLACING THE BATTERY

#### 8.12.1 Battery for Memory Backup (3 VDC)

The programs and system variables are stored in the SRAM located on the main board. The power to the SRAM memory is backed up by a lithium battery mounted on the front panel of the main board. The above data is not lost even when the main power of the controller is turned off. A new battery can maintain the contents of memory for about 4 years (Note).

When the voltage of the battery becomes low, the low-voltage battery alarm (system-035) is displayed on the teach pendant. When this alarm is displayed, replace the battery as soon as possible. In general, the battery can be replaced within one or two weeks, however, this depends on the system configuration.

If the battery voltage gets lower, it becomes impossible to back up the content of the SRAM. Cycling power to the controller in this state causes the system not to start, and the LED located on the main board displays "1" because the contents of memory have been lost. Clear the entire SRAM memory and reenter data after replacing the battery. Important data should be saved to a memory card or other external device beforehand for just such an emergency.

NOTE

In a newly introduced robot, the battery is factory-installed. Since some time passes between when the robot is built and when it is installed, battery replacement may, therefore, be needed within 4 years after the introduction of the robot.

#### Replacing the lithium battery

- (1) Prepare a new lithium battery (ordering drawing number: A02B-0200-K102, A98L-0031-0012).
- (2) Turn the robot controller on for about 30 seconds.

#### 

Complete the steps (3) to (5) within 30 minutes.

If the battery is left disconnected for a long time, the contents of memory will be lost.

To prevent possible data loss, it is recommended that the robot data such as programs and system variables be backed up before battery replacement.

- (3) Turn the robot controller off.
- (4) Remove the old battery from the top of the main board.First unlatch the battery, remove it from the battery holder, and detach its connector.




Fig.8.12.1 Replacing the lithium battery

(5) Remove the old battery, insert a new one into the battery holder, and attach the connector. Confirm that the battery is latched firmly.

#### 

Using other than the recommended battery may result in a battery explosion. Replace the battery only with the specified battery (A02B-0200-K102, A98L-0031-0012).

Dispose of the replaced battery as an industrial waste, according to the laws and other rules in the country where the controller is installed and those established by the municipality and other organizations that have jurisdiction over the area where the controller is installed.

## **II. CONNECTIONS**


1

# OVERVIEW

This section describes the electrical interface connections in the R-30*i*B/R-30*i*B Plus. It also includes information about installation of the R-30*i*B/R-30*i*B Plus.

# 2 BLOCK DIAGRAM

Fig.2 is a block diagram of electrical interface connections with the R-30*i*B/R-30*i*B Plus.



#### NOTE

------ : Indicates electrical connection.

#### Fig.2 Block diagram of electrical interface connection

## **3** ELECTRICAL CONNECTIONS

## 3.1

#### CONNECTIONS BETWEEN THE CONTROLLER AND THE MECHANICAL UNIT AND OTHER GENERAL CONTROLLER CONNECTIONS






Fig.3.1 (a) Mechanical connection diagram



#### 3. ELECTRICAL CONNECTIONS CONNECTIONS



#### NOTE

- 1 For detail of the peripheral device connection, see the section of Peripheral device interface.
- 2 This cable is not included. It must be supplied by the customer.


Fig.3.1 (b) Unit-to-unit connection diagram


CONNECTIONS 3. ELECTRICAL CONNECTIONS

# **3.2** CONNECTION TO FANUC I/O LINK AND FANUC I/O LINK

## **3.2.1** Connection of I/O Link by Using JD1A Connector

The connection of I/O link by using JD1A connector is shown below.





## **3.2.1.1** Connection of the I/O Link cable by using JD1A connector

- 1. Connect the cable according to the system. Be sure to perform shielding.
- 2. Before connection turn off the power.

#### NOTE

For connection with the CNC with I/O links, turn on or off the power of the CNC and the robot controller at the following timing.

- a) Slave units and the master must be powered on or off at the same time.
- b) If the CNC or robot controller is powered off after startup of the system, an I/O link error occurs. To successfully make connection with I/O links again, power off all of the units and then power them on at the timing indicated in a).

	•= ···						
	interface						
1	RXSLCA	11	0V				
2	*RXSLCA	12	0V				
3	TXSLCA	13	0V				
4	*TXSLCA	14	0V				
5		15	0V				
6		16	0V				
7		17					
8		18	+5V				
9	+5V	19	+24E				
10	+24E	20	+5V				

#### When used as master interface JD1A

- 3. When the R-30iB/R-30iB Plus controller is used as the I/O link master, use a twisted-pair cable in which wires RXSLCA(Pin No.1 of JD1A) and \*RXSLCA(Pin No.2 of JD1A) are paired and wires TXSLCA(Pin No.3 of JD1A) and \*TXSLCA(Pin No.4 of JD1A) are paired.
- 4. Shield the cable collectively and ground the shield on the CNC side.

# 3.2.1.2 Cable connection diagram of the I/O Link cable when using JD1A connector




Fig.3.2.1.2 Cable connection diagram of the I/O Link cable when using JD1A connector

# **3.2.2** Connection of I/O Link and I/O Link *i* when Using JRL8 Connector

The connection of I/O link and I/O link *i* when using JRL8 connector is shown below.




Fig.3.2.2 Connection of I/O link and I/O Link i by using JRL8 connector

# 3.2.2.1 Connection of the I/O Link cable when using JRL8 connector

- 1 Connect the cable according to the system. Be sure to perform shielding. Shield the cable collectively and ground the shield on the CNC side.
- 2. Before connection turn off the power.

#### NOTE


For connection with the CNC with I/O Link and I/O link i, turn on or off the power of the CNC and the robot controller at the following timing.

- a) Slave units and the master must be powered on or off at the same time.
- b) If the CNC or robot controller is powered off after startup of the system, I/O Link and I/O link *i* error occurs. To successfully make connection with I/O Link and I/O link *i* again, power off all of the units and then power them on at the timing indicated in a).

JRL8					
1	RXSLCB	11	*HDI1		
2	0V	12	0V		
3	*RXSLCB	13	*HDI2		
4	0V	14	0V		
5	TXSLCB	15	*HDI3		
6	RXSLCC	16	0V		
7	*TXSLCB	17	*HDI4		
8	*RXSLCC	18	0V		
9	TXSLCC	19	*HDI5		
10	*TXSLCC	20	0V		
	JRL8 Ir	nterface	9		

י יםי

- 3. When the R-30*i*B/R-30*i*B Plus controller is connected to CNC or preceding I/O link *i* slave unit, use a twisted-pair cable in which wires RXSLCB (Pin No.1 of JRL8) and \*RXSLCB (Pin No.3 of JRL8) are paired and wires TXSLCB (Pin No.5 of JRL8) and \*TXSLCB (Pin No.7 of JRL8) are paired.
- When the R-30*i*B/R-30*i*B Plus controller is connected to next I/O link *i* slave unit, use a twisted-pair 4. cable in which wires RXSLCC (Pin No.6 of JRL8) and \*RXSLCC (Pin No.8 of JRL8) are paired and wires TXSLCC (Pin No.9 of JRL8) and \*TXSLCC (Pin No.10 of JRL8) are paired.



# 3.2.2.2 Cable connection diagram of the I/O Link cable by using JRL8 connector

Fig.3.2.2.2 Cable connection diagram of the I/O Link cable by using JRL8 connector

# **3.3** EXTERNAL CABLE WIRING DIAGRAM

## **3.3.1** Robot Connection Cables

#### 

Before operating the robot, uncoil the interconnection cables from their shipping position to prevent excessive heat, which may damage the cables. (Coiled part should be shorter than 10 meter.)

There are two types of the robot connection cable;

Non-flex type: usage is restricted to fixed laying

Flex type: possible to use in the cable track

#### Specification of cable

			Non-flex type			Flex type		
		Robot	Diameter (mm)	Weight (kg/m)	Minimum bending radius (mm)	Diameter (mm)	Weight (kg/m)	Minimum bending radius (mm)
RP1		All models	16.0	0.45	200	20.5	0.71	200
RM1		Group 1 Group 3 Group 4 Group 5 Group 11 Group 12	26.1	1.22	200	25.4	1.2	200
		Group 2 Group 6	20.0	0.7	200	18.4	0.7	200
RM2		Group 3 Group 4 Group 5	26.1	1.22	200	25.4	1.2	200
	RP	Group7	16.0	0.45	200	20.5	0.71	200
RMP	RM	Group8	20.0	0.7	200	18.4	0.7	200
RP7A		Croup 12	8.5	0.09	200	9.1	0.12	200
RM7A		Group 12	20.6	0.71	200	20	0.64	200
EARTI	Н	All models	4.7	0.065	200	4.7	0.065	200


Group1	R-1000 <i>i</i> A(Except /120F-7B), R-2000 <i>i</i> B (Except /200T/220U/220US), R-2000 <i>i</i> C(Except /210L/270F),
	M-420 <i>i</i> A, M-421 <i>i</i> A, M-710 <i>i</i> C
Group2	F-200 <i>i</i> B
Group3	R-2000iB/200T/220U/220US, R-2000iC/210L/270F, M-410iB, M-410iC
Group4	M-900iA/150P/260L/350
Group5	M-900 <i>i</i> A/400L/600,M-900 <i>i</i> B/400L/700
Group6	M-430iA/2PH/4FH
Group7	M-430iA/2P
Group8	ARC Mate 100iC, ARC Mate 120iC, M-10iA, M-20iA, M-20iB, CR-35iA
Group11	M-2iA, M-3iA
Group12	R-1000 <i>i</i> A/120F-7B

Using condition of flex type cable


(1) When routing cables in movable places, use a cable bearer.

- (2) The bending radius (R) of the cable track is more than 200mm.
- (3) The cable should be fixed to the cable track by using the clamp. (e.g. foam rubber)
- (4) The size of the hole to support a cable in the cable track should be more than 110% of the cable size and should have the gap more than 3mm.
- (5) When cables are laid in the cable track, pay attention for the cable not to be twisted.

### Cable Route In case of A-cabinet Signal cable




### Power/Brake cable



## 


Power/Brake cable should be clamped to Earth plate by cable clamp.

# In case of B-cabinet Signal cable



### CAUTION Signal cable should be clamped to Earth plate by cable clamp.

### Power/Brake cable



# CAUTION Power/Brake cable should be clamped to Earth plate by cable clamp.

#### Robot Model

## Group1: R-1000*i*A(except /120F-7B), R-2000*i*B(expect /200T/220U/220US), R-2000*i*C(expect /210L/270F), M-420*i*A,M-421*i*A,M-710*i*C

#### Group2:F-200*i*B

#### Group11:M-2iA, M-3iA

#### Detail of cable connection to servo amplifier




Fig.3.3.1 (a) Robot connection cable (Group1, Group2, Group11)

#### Robot Model

# Group3:R-2000*i*B/200T/220U/220US, R-2000*i*C/210L/270F, M-410*i*B, M-410*i*C Detail of cable connection to servo amplifier




Fig.3.3.1 (b) Robot connection cable (Group3)

#### Robot Model Group4:M-900*i*A/150P/260L/350 Detail of cable connection to servo amplifier




Fig.3.3.1 (c) Robot connection cable (Group4)

#### Robot Model Group5:M-900*i*A/400L/600,M-900*i*B/400L/700 Detail of cable connection to servo amplifier




Fig.3.3.1 (d) Robot connection cable (Group5)

### Robot Model Group6:M-430*i*A/2PH/4FH Detail of cable connection to servo amplifier




Fig.3.3.1 (e) Robot connection cable (Group6)

#### Robot Model Group7:M-430*i*A/2P Detail of cable connection to servo amplifier




Fig.3.3.1 (f) Robot connection cable (Group7)

#### **Robot Model**

Group8:ARC Mate 100*i*C, ARC Mate 120*i*C, M-10*i*A, M-20*i*A, M-20*i*B,CR-35*i*A Detail of cable connection to servo amplifier




Fig.3.3.1 (g) Robot connection cable (Group8)

## Robot Model Group12:R-1000*i*A/120F-7B Detail of cable connection to servo amplifier





Fig.3.3.1 (h) Robot connection cable (Group12)

## **3.3.2** Teach Pendant Cable



(B-cabinet)

#### Fig.3.3.2 Teach pendant cable

## **3.3.3** Connecting the Input Power

## **3.3.3.1** Connecting the input power cable

- (1) Fig3.3.3.1 shows the method of connecting the input power supply cable.
- (2) Use the input power cable according to the following Table 3.3.3.1. However, the input power cable according to the breaker or the fuse of the input power supply (power distribution panel) connected to the robot controller must be used.
- (3) Provide a class-D or better ground. There shall be no switches or disconnects in the grounding conductor. The resistance to the ground must not exceed 100Ω. Use a thick wire to withstand the maximum current used.

In case of NRTL controller


Grounding/Bonding to comply with NEC Article 250 or CEC Section 10 as appropriate. Provide a grounding conductor of equivalent gauge as the supply conductors.

	Table 3.3.3.1 Conductor size and terminal size of AC power supply						
Input Voltage	Input power source capacity (Refer to CONNECTIONS 5.3)	Conductor size of AC Power supply cable	Terminal size of AC power supply cable	Conductor size of earth cable	Terminal size of earth cable		
400V	All robot	AWG10 or more (Note 1)	M5	WARNING 2	M5		
200V	15KVA or more	AWG8 or more (Note 1)	M8	WARNING 2	M5		
200V	12KVA or less	AWG10 or more (Note 1)	M5	WARNING 2	M5		

### able 3.3.3.1 Conductor size and terminal size of AC power supply


#### 

- 1 The input power cable according to the breaker or the fuse of the input power supply (power distribution panel) connected to the robot controller must be used.
- 2 Use conductor of earth cable size is as well as the AC power supply cable size.3 Disconnection of protective earth ground may impair the protection provided by the system.



## 

The cover for primary terminal of main breaker should be replaced after completing.



#### Fig.3.3.3.1 Connecting the input power cable

## **3.3.3.2** Leakage breaker

- (1) The motor is driven by the PWM inverter system using a power transistor bridge. A high-frequency leakage current flows through the stray capacitance between the ground and the motor coils, power cable, and amplifier. This might cause the leakage-current circuit breaker or leakage-protection relay installed in the path of the power supply to cut out.
- Use the following leakage current circuit breaker for inverters to prevent incorrect operation.
- (2) Leakage breaker using robot controller has sensitive electric current of 30mA.

Manufacture	Туре	
Fuji Electric Co., Ltd.	EG A series or later	
	SG A series or later	
Hitachi, Ltd.	ES100C type or later	
	ES225C type or later	
Matsushita Electric Works, Ltd.	Leakage current circuit breaker, C type or later	
	Leakage current circuit breaker, KC type or later	

 Table 3.3.3.2 Example of leakage current circuit breaker for inverters

## 3.3.3.3 Check input voltage

Setting of transformer tap is necessary depending on the input voltage.

The tap is set to the specified voltage before shipment. However, check it referring to section 6.2 in MAINTENANCE before supplying power (before the breaker switch is turned on).

## **3.3.3.4 ON/OFF** timing by the breaker

If the power supply is turned on, turned off, and then turned on again repeatedly in a short time, the controller may not start up. If the power is turned off before the controller is completely started up (it takes about 30 seconds), wait for at least 10 seconds before turning on the power again.






Fig.3.3.3.4 The power is turned off within 30 seconds after it has been turned on


## **3.3.4** Connecting the External Power Supply ON/OFF Switch



(A-cabinet)



(B-cabinet) Fig.3.3.4 (a) Connection of the external power supply ON/OFF switch



controller cannot be turned on and off by using the circuit breaker.


#### Fig.3.3.4 (c) Connection of the external power supply switch ON and OFF

#### B-83195EN/09


## **3.3.5** Connecting the External Emergency Stop

After connecting the safety signals like external emergency stop signal and/or safety fence signal, verify that,

- $\cdot$  All safety signals stop the robot as intended.
- •There is no mistake in connection of safety signals.




(A-cabinet)



(B-cabinet) Fig.3.3.5 (a) Connecting the external emergency stop


#### External emergency stop output




For the circuit, see Fig. A (i) (j) (k) (l) in Appendix A, "TOTAL CONNECTION DIAGRAM".


Signal	Description	Current, voltage	Min. load
ESPB1 — ESPB11	The contact is open when one of the	Rated contact:	(Reference value)
ESPB2 ESPB21	TP emergency stop button or the	30 VDC, 5 A resistor load	DC5V 10mA
	Operator panel emergency stop button		
	is pressed. The contact is also open		
	while the controller is powered off		
	regardless of status of emergency		
	stop buttons. By connecting external		
	power supply to the emergency stop		
	circuit, the contact works even while		
	the robot controller is powered off.		
	(See "External power connection" of		
	this section) The contact is closed		
	during normal operation.		

#### CONNECTIONS 3. ELECTRICAL CONNECTIONS







### **External power connection**




The relays for the emergency stop input and output can be separated from the controller's power. Please connect the external +24V instead of the internal +24V, if the emergency stop output must not affect the controller's power.



## External emergency stop input



Emergency stop board (A-cabinet)



#### Emergency stop board (B-cabinet)


### 3. ELECTRICAL CONNECTIONS C

CONNECTIONS

Signal	Description	Current, voltage
EES1 EES11 EES2 EES21	Connect the contacts of the external emergency stop switch to these terminals. When the contacts are open, the robot stops according to predetermined stop pattern. (Note 2) When using the contacts of a relay or contactor instead of the switch, connect a spark killer to the coil of the relay or contactor, to suppress noise. When these terminals are not used, jumper them.	Open and close of 24VDC 0.1A (Note 1)
EAS1 EAS11 EAS2 EAS21	These signals are used to stop the robot safely when the safety fence gate is opened during operation in the AUTO mode. When the contacts are open in the AUTO mode, the robot stops according to predetermined stop pattern. (Note 2) In the T1 or T2 mode and the DEADMAN switch is held correct position, the robot can be operated even when the safety fence gate is open. When using the contacts of a relay or contactor instead of the switch, connect a spark killer to the coil of the relay or contactor, to suppress noise. When these terminals are not used, jumper them.	Open and close of 24VDC 0.1A (Note 1)
EGS1 EGS11 EGS2 EGS21	Connect the contacts of the servo-off input switch to these terminals When the contacts are open, the robot stops according to predetermined stop pattern. (Note 2) When using the contacts of a relay or contactor instead of the switch, connect a spark killer to the coil of the relay or contactor, to suppress noise. When these terminals are not used, jumper them.	Open and close of 24VDC 0.1A (Note 1)

#### NOTE

- 1. Use a contact which minimum load is 5 mA less.
- 2. See Chapter 7 in SAFETY PRECAUTIONS.



#### Input timing of duplicate safety signals

Duplicate inputs are used for signals such as the external emergency stop signal, safety fence signal, and servo off signal so that a response is made even when a single failure occurs. The statuses of these duplicate input signals must always be changed at the same timing according to the timing specifications provided in this section. The robot controller always checks that the statuses of the duplicate inputs are the same, and if the controller finds a discrepancy, it issues an alarm. If the timing specifications are not satisfied, an alarm may be issued because of a signal discrepancy.




Fig.3.3.5(c) Input timing of duplicate safety signals

# Connecting external on/off and external emergency stop signal input/output wires

	FANUC's specification	Manufacturer's specification (WAGO)	Remark
16-pole terminal block (TBOP14:A-cabinet) (TBOP10:B-cabinet)	A63L-0002-0154#116	734-116	
14-pole terminal block (TBOP11:B-cabinet)	A63L-0002-0154#114	734-114	
12-pole terminal block (TBOP13:A-cabinet)	A63L-0002-0154#112	734-112	
Operation lever	A63L-0002-0154#230-M	734-230	2 pieces of 734-230 and operation manual are included in FANUC's specification


- 1. Detach the plug connector block from the emergency stop board.
- 2. Use the lever or insert the tip of a flat-blade screwdriver into the manipulation slot and push down its handle.

- 3. Insert the end of the signal wire into the wire slot.
- 4. Pull out the lever or screwdriver.
- 5. Attach the plug connector block to the emergency stop board.

#### 


Do not insert a wire into the wire hole of a plug connector or pull it out with the plug connector block mounted on the emergency stop board; otherwise, the emergency stop board may be damaged.

FANUC recommends the lever (A05B-2600-K030) for connecting the signal wire to the plug connector block instead of Flat-blade screwdriver.



CONNECTIONS 3. ELECTRICAL CONNECTIONS

# **3.3.6** Connecting the Non-Teaching Enabling (NTED) Signal (CRMA96)(For B-cabinet)



Emergency stop board (B-cabinet) Fig.3.3.6 Connecting the NTED Signal (B-cabinet)

NTED provides a way to connect an external enabling device to the robot. In the auto mode, robot moves without reference to the state of the switch connected with NTED signal. CRMA96 connector is provided in B-cabinet.


Refer to "APPENDIX A, Total connection Diagram Fig.A (i) (j) (k) (l)" about NTED circuit.

Input timing of NTED signal must comply with rules in the section "Input timing of duplicate safety signals".

### 

After connecting a NTED switch, be sure to check the operation of this switch, the emergency stop button on the operator's panel, and the emergency stop button on the teach pendant.

### 3. ELECTRICAL CONNECTIONS CONNECTIONS



#### **CRMA96** connector

A1	NTED1	B1	NTED11			
A2	NTED2	B2	NTED21			
A3	(DM1)	B3	(DM2)			

#### **CRMA96 connector Specification**

	TE Connectivity Specification	FANUC Specification
Rece-housing	1-1318119-3	A63L-0001-0812#R06DX
Rece-contact(AWG18-22)	1318107-1	A63L-0001-0812#CRM

## **3.3.7** Connecting the Auxiliary Axis Brake (CRR65 A/B)




Fig.3.3.7 6-axis servo amplifier

#### CRR65 A/B

A1	BKA1	B1	BKA2			
A2		B2				
A3	COMMON	B3	COMMON			

Specification						
TE Connectivity Specification FANUC Specification						
Rece-housing	1-178128-3	A63L-0001-0460#032KSX				
Rece-contact	175218-2	A63L-0001-0456#ASL				

# **3.3.8** Connecting the Auxiliary Axis Over Travel (CRM68)




Fig.3.3.8 6-axis servo amplifier

#### CRM68

A1	AUXOT1					
A2	AUXOT2					
A3						

Specification					
TE Connectivity Specification FANUC Specification					
Rece-housing	1-1318120-3	A63L-0001-0812#R03SX			
Rece-contact	1318107-1	A63L-0001-0812#CRM			

4

# PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

R-30*i*B/R-30*i*B Plus I/O peripheral device interfaces include printed circuit boards and a unit selected according to the applications. Table 4 lists details of the printed-circuit boards and units. Figure 4 shows the locations of these boards and units.

	Table 4 Femphicial device interface types							
No.	Name	Drawing number	Number of I/O points				Remarks	
NO.	No. Name Drawing nu		DI	DO	D/A	A/D	Nemarks	
1	Process I/O board JA	A05B-2600-J001	96	96 (Source type)	0	0	Installed in back plane	
2	Process I/O board JB	A05B-2600-J002	40	40 (Source type)	0	0	Installed in back plane	
3	Process I/O board MA	A05B-2600-J020	20	16 (Source type)	0	0	Installed in A-cabinet	
4	Process I/O board KA	A05B-2600-J010	40	40 (Source type)	3	2	Installed in A-cabinet top	
							box	
5	Process I/O board KB	A05B-2600-J011	40	40 (Source type)	2	0	Installed in A-cabinet top	
							box	
6	I/O Unit-MODEL A	A05B-2601-J130	Depending on selected I/O		A-cabinet (five slots)			
		(Base and	module.					
		interface unit)						
		A05B-2603-J130					B-cabinet (five slots)	
		(Base and						
		interface unit)						

Table 4 Peripheral device inter	ace types
---------------------------------	-----------

No.	Name	Namo Drawing number		Number of I/O po	Remarks		
NO.		Drawing number	WI	WO	D/A	A/D	Reillarks
7	Process I/O board MB	A05B-2600-J021	5	4 (Sink type)	2	0	Installed in A-cabinet

#### NOTE


1 General purpose I/O (DI/DO) is a number, which subtract an exclusive signal from the table value.


Example: Process I/O board JB

Table valueExclusive DIGeneral purpose DIDI;40 -18=22 pointsTable valueExclusive DOGeneral purpose DO

DO;40 -20=20 points

- 2 When there are slave units on the I/O Link and the power for control to these slave units is supplied from other than the robot controller, the power to the controller and the power to the slave units must be turned on and off at the following timings:
  - a) The power to the slave units must be turned on before or when the power to the controller, which is the master of the I/O Link, is turned on.
  - b) If the power to a slave unit is turned off after the system has started up, an I/O Link error occurs. To establish the I/O Link again, turn off the power to all units including the controller, then turn on the power to the units in the order described in a).








Fig.4(a) Locations of peripheral device interfaces (A-cabinet)




Fig.4(b) Locations of peripheral device interfaces (B-cabinet)

# 4.1 PERIPHERAL DEVICE INTERFACE BLOCK DIAGRAM

Following are a block diagram of the peripheral device interface and the specifications.

## 4.1.1 When Process I/O Board JA/JB is Used (B-cabinet)




Fig.4.1.1 Block diagram of the process I/O board JA/JB

# **NOTE** The process I/O board JB does not have CRMA5C, CRMA5D, CRMA6A, and CRMA6B.

Number	Name	Drawing number	Remarks
(1)	I/O Link cable	A05B-2603-J170	Between main board and process I/O
(2)	I/O Link cable	A05B-2603-J171	Between process I/O and process I/O
(2) (4)	Peripheral device connection cable (Process I/O JA, JB)	A05B-2603-J200	Connected length: 10m (one)
(3) (4) (5) (6)		A05B-2603-J201	Connected length: 20m (one)
		A05B-2603-J202	Connected length: 30m (one)
(7) (8)	Peripheral device connection cable (Process I/O JA)	A05B-2603-J203	Connected length: 10m (one)
		A05B-2603-J204	Connected length: 20m (one)
		A05B-2603-J205	Connected length: 30m (one)

# 4.1.2 When Process I/O Board MA is Used (A-cabinet)




Fig.4.1.2 Block diagram of the process I/O MA

Number	Name	Drawing number	Remarks
(1)	I/O Link cable	A05B-2601-J172	
(2)		A05B-2601-J240	Connection length 10m (one): CRMA52
	Peripheral device cable	A05B-2601-J241	Connection length 20m (one): CRMA52
		A05B-2601-J242	Connection length 30m (one): CRMA52

## 4.1.3 When Process I/O Board MB is Used (A-cabinet)




Fig.4.1.3 Block diagram of the process I/O MB

Number	Name	Drawing number	Remarks
(1)	I/O Link cable	A05B-2601-J174	
	Wolding machine connection coble	A05B-2601-J246	Connection length 3m (one): CRW11
(2)	Welding machine connection cable (FANUC interface/elbow type)	A05B-2601-J247	Connection length 7m (one): CRW11
		A05B-2601-J248	Connection length 14m (one): CRW11
	Welding machine connection cable	A05B-2601-J250	Connection length 3m (one): CRW11
		A05B-2601-J251	Connection length 7m (one): CRW11
	(FANUC interface/straight type)	A05B-2601-J252	Connection length 14m (one): CRW11

## 4.1.4 When Process I/O Board KA/KB is Used (A-cabinet)




Fig.4.1.4 Block diagram of the process I/O board KA/KB

#### Integrated type

	integrated type					
Number	Name	Drawing number	Remarks			
(1)	I/O Link cable	A05B-2601-H180				
(2)	Process I/O cable					
(3)	Peripheral device connection cable	A05B-2601-J230	Connection length of 10 m (one)			
(4)		A05B-2601-J231	Connection length of 20 m (one)			
		A05B-2601-J232	Connection length of 30 m (one)			
(5)	Welding machine connection cable	A05B-2601-J235	Connection length of 3 m (one), CRW10			
	(For process I/O board KA, KB)	A05B-2601-J236	Connection length of 7 m (one), CRW10			
	(FANUC interface/elbow type)	A05B-2601-J237	Connection length of 14 m (one), CRW10			

## 4.1.5 When I/O Unit-MODEL A is Used

## 4.1.5.1 In case of A-cabinet





Fig.4.1.5.1 Block diagram of I/O Unit-MODEL A (In case of A-cabinet)

Number	Name	Drawing number	Remarks
(1)	I/O Link cable	-	Included in (A05B-2601-J130)
(2)-(6)	Peripheral device cable	-	Must be supplied by the customer.

### 4.1.5.2 In case of B-cabinet



#### Fig.4.1.5.2 Block diagram of I/O Unit-MODEL A (In case of B-cabinet)

Number	Name	Drawing number	Remarks
(1)	I/O Link cable	-	Included in (A05B-2603-J130)
(2)	Power supply cable	-	Included in (A05B-2603-J130)
(3)-(7)	Peripheral device cable	-	Must be supplied by the customer.

# 4.1.6 When Two or More Process I/O Board and I/O Unit-MODEL A are Used

#### 4.1.6.1 In case of B-cabinet

When several units of the process I/O PCB, I/O Unit-A are used, connect them as shown below.




Fig.4.1.6.1 Block diagram of two or more process I/O printed circuit boards and I/O unit-MODEL A (In case of B-cabinet)

Number	Name	Drawing number	Remarks
(1)	I/O Link cable	A05B-2603-J170	Between main board and process I/O
(2)	I/O Link cable	A05B-2603-J171	Between process I/O and process I/O
(3)	I/O Link cable	-	Included in (A05B-2603-J130)
(4)	Power supply cable	-	Included in (A05B-2603-J130)

# 4.2 PROCESS I/O BOARD SIGNALS

There are 18 exclusive data inputs (DI) and 20 exclusive data outputs (DO) for a process I/O board. These signals are allocated to the process I/O board connected first when two or more printed boards are combined. (General signals DI/DO are allocated to the second and the following process I/O boards.) The common voltage of the DI signals input to pins 1 to 4 of connector CRMA5A is clamped +24 V (common) in each process I/O board.

Table 4.2(a)(b) shows signals of a process I/O board.

#### Table 4.2(a) Process I/O board signals(DI signal)


Connector number	Signal name	Description	Remarks
DI signals			
CRMA5A- 1	XIMSTP	Immediate stop	Clamped at +24 V common
CRMA5A- 2	XHOLD	Temporary stop	Clamped at +24 V common
CRMA5A- 3	XSFSD	Safe speed	Clamped at +24 V common
CRMA5A- 4	CSTOPI	Cycle stop	Clamped at +24 V common
CRMA5A- 5	FAULT RESET	External reset	
CRMA5A- 6	START	Start	
CRMA5A- 7	HOME	Return to home position	
CRMA5A- 8	ENBL	Operation enabled	
	RSR1	Robot service request	
CRMA5A- 9	PNS1	Program number selection	Option
	RSR2	Robot service request	
CRMA5A-10	PNS2	Program number selection	Option
	RSR3	Robot service request	
CRMA5A-11	PNS3	Program number selection	Option
	RSR4	Robot service request	
CRMA5A-12	PNS4	Program number selection	Option
	RSR5	Robot service request	
CRMA5A-13	PNS5	Program number selection	Option
	RSR6	Robot service request	
CRMA5A-14	PNS6	Program number selection	Option
	RSR7	Robot service request	
CRMA5A-15	PNS7	Program number selection	Ontion
	RSR8		Option
CRMA5A-16	PNS8	Robot service request	Option
		Program number selection PNS strobe	Option
CRMA5A-29	PNSTROBE		
CRMA5A-30	PROD START	Start of automatic operation	
CRMA5A-31	DI01	Peripheral device status	General signal
CRMA5A-32	DI02	Peripheral device status	General signal
CRMA5B-1	DI03	Peripheral device status	General signal
CRMA5B-2	DI04	Peripheral device status	General signal
CRMA5B- 3	DI05	Peripheral device status	General signal
CRMA5B- 4	DI06	Peripheral device status	General signal
CRMA5B- 5	DI07	Peripheral device status	General signal
CRMA5B- 6	DI08	Peripheral device status	General signal
CRMA5B-7	DI09	Peripheral device status	General signal
CRMA5B-8	DI10	Peripheral device status	General signal
CRMA5B- 9	DI11	Peripheral device status	General signal
CRMA5B-10	DI12	Peripheral device status	General signal
CRMA5B-11	DI13	Peripheral device status	General signal
CRMA5B-12	DI14	Peripheral device status	General signal
CRMA5B-13	DI15	Peripheral device status	General signal
CRMA5B-14	DI16	Peripheral device status	General signal
CRMA5B-15	DI17	Peripheral device status	General signal
CRMA5B-16	DI18	Peripheral device status	General signal
CRMA5B-29	DI19	Peripheral device status	General signal
CRMA5B-30	DI20	Peripheral device status	General signal
CRMA5B-31	DI21	Peripheral device status	General signal
CRMA5B-32	DI22	Peripheral device status	General signal

Table 4.2(b) Process I/O board signals(DO signal)				
Connector number	Signal name	Description	Remarks	
DO signals				
CRMA5A-33	CMDENBL	During automatic operation		
CRMA5A-34	SYSRDY	Preparation completed		
CRMA5A-35	PROGRUN	Program running		
CRMA5A-36	PAUSED	Program being interrupted		
CRMA5A-38	HELD	During temporary stop		
CRMA5A-39	FAULT	Alarm		
CRMA5A-40	ATPERCH	Home position		
CRMA5A-41	TPENBL	Teach pendant enabled		
CRMA5A-43	BATALM	Battery voltage drop		
CRMA5A-44	BUSY	During operation		
	ACK1	Robot service request acceptance		
CRMA5A-45	SNO1	Selected program number	Option	
	ACK2	Robot service request acceptance		
CRMA5A-46	SNO2	Selected program number	Option	
	ACK3	Robot service request acceptance		
CRMA5A-19	SNO3	Selected program number	Option	
	ACK4	Robot service request acceptance		
CRMA5A-20	SNO4	Selected program number	Option	
	ACK5	Robot service request acceptance		
CRMA5A-21	SNO5	Selected program number	Option	
	ACK6	Robot service request acceptance		
CRMA5A-22	SNO6	Selected program number	Option	
	ACK7	Robot service request acceptance		
CRMA5A-24	SNO7	Selected program number	Option	
	ACK8	Robot service request acceptance		
CRMA5A-25	SNO8	Selected program number	Option	
CRMA5A-26	SNACK	Response signal to PNS		
CRMA5A-20	RESERVED			
CRMA5B-33	DO01	Peripheral device control signal	General signal	
CRMA5B-34	DO02	Peripheral device control signal	General signal	
CRMA5B-35	DO02	Peripheral device control signal	General signal	
CRMA5B-36	D003	Peripheral device control signal	General signal	
CRMA5B-38	DO05	Peripheral device control signal	General signal	
CRMA5B-39	DO06	Peripheral device control signal	General signal	
CRMA5B-39 CRMA5B-40	DO07	Peripheral device control signal	General signal	
CRMA5B-40 CRMA5B-41	DO08	Peripheral device control signal	General signal	
	DO09			
CRMA5B-43 CRMA5B-44	DO10	Peripheral device control signal Peripheral device control signal	General signal General signal	
CRMA5B-45	DO11	Peripheral device control signal	General signal	
CRMA5B-46	DO12	Peripheral device control signal	General signal	
CRMA5B-19	DO13	Peripheral device control signal	General signal	
CRMA5B-20	DO14	Peripheral device control signal	General signal	
CRMA5B-21	DO15	Peripheral device control signal	General signal	
CRMA5B-22	DO16	Peripheral device control signal	General signal	
CRMA5B-24	DO17	Peripheral device control signal	General signal	
CRMA5B-25	DO18	Peripheral device control signal	General signal	
CRMA5B-26	DO19	Peripheral device control signal	General signal	
CRMA5B-27	DO20	Peripheral device control signal	General signal	


#### Table 4.2(b) Process I/O board signals(DO signal)

# 4.3 INTERFACE FOR PERIPHERAL DEVICES

# 4.3.1 Peripheral Device and Controller Connection (Source Type DO)



- 1 The peripheral device connection cables are optional.
- 2 The DOSRC1 pins of the CRMA5A and CRMA5B are pins for supplying power to drivers. (None of these pins can be left open.)
- 3 When the level of the voltage applied to the load is insufficient for a cause such as a too long peripheral device connection cable, supply power from the TBSRC1 terminal block.




- 1 The peripheral device connection cables are optional.
- 2 The DOSRC2 pins of the CRMA5C and CRMA5D are pins for supplying power to drivers. (None of these pins can be left open.)
- 3 When the level of the voltage applied to the load is insufficient for a cause such as a too long peripheral device connection cable, supply power from the TBSRC2 terminal block.

Controller						Process I/O board JA
	Periph	eral de	evice contro	l interfa	ace B1	
				(So	urce type DO)	
		С	RMA6A	(00)		
01	DI63	08	DO65	14	DO61	
02	DI64	09	D066	15	DO62	
03		10	DO67	16	DO63	
04	DI66	11	DO68	17	DO64	
05		12	DOSRC3	18	DOSRC3	
06		13	DI70	19	+24E	device B1
07	DI69			20	0V	
	Periph	eral de	evice contro		ace B2 urce type DO)	
		С	RMA6B	(		
01	DI71	08	DO73	14	DO69	
02	DI72	09	D074	15	DO70	
03	DI73	10	DO75	16	DO71	
04		11	DO76	17	DO72	device B2
05		12	DOSRC3	18	DOSRC3	
06		13	DI78	19	+24E	
07	DI77			20	0V	
Termina	I block TBSRC3 1 DOSRC3 2 OV					

- 1 The peripheral device connection cables are optional.
- 2 The DOSRC3 pins of the CRMA6A and CRMA6B are pins for supplying power to drivers. (None of these pins can be left open.)
- 3 When the level of the voltage applied to the load is insufficient for a cause such as a too long peripheral device connection cable, supply power from the TBSRC3 terminal block.

- 206 -



#### NOTE

In this diagram, common voltage of input devices is +24V.

B-83195EN/09

B-83195EN/09

CONNECTIONS

#### 4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

ontroller (peripheral	DOSRO		Peripheral device
		Connector pin No.	
		CR MA5A (23,28,37,42,47)	+24V regulated power supply
Driver circu	it		
	DV		
CMDENBL —		CRMA5A (33)	
SYSRDY	DV	CRMA5A (34)	
PROGRUN —	DV	CRMA5A (35)	
PAUSED —	DV -	CRMA5A (36)	
HELD —		CRMA5A (38)	
		CRMA5A (39)	
FAULT —	- DV -	CRMA5A (40)	LOAD
ATPERCH —	DV	CRMA5A (41)	
TPENBL —		CRMA5A (43)	
BATALM —	- DV -	CRMA5A (44)	LOAD
BUSY —	- DV -	CRMA5A (45)	LOAD
ACK1/SNO1 —	- DV -	CRMA5A (46)	LOAD
ACK2/SNO2 —	- DV -		LOAD
ACK3/SNO3 —	- DV -	CRMA5A (19)	LOAD
ACK4/SNO4 —	- DV -	CRMA5A (20)	LOAD
ACK5/SNO5 —	– DV –	CRMA5A (21)	LOAD
ACK6/SNO6 —	- DV -	CRMA5A (22)	LOAD
ACK7/SNO7 —	- DV -	CRMA5A (24)	
ACK8/SNO8 —	– DV –	CRMA5A (25)	
SNACK —	- DV -	CRMA5A (26)	
RESERVED —	DV	CRMA5A (27)	
		CRMA5A (17,18)	
		TBSRC1(2)	
maximum output			

4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS

B-83195EN/09

Controller (periphera			Peripheral device
	+		
Pagain	er circuit	FUSE1	
DI03	RV	CRMA5B (1)	
DI04	RV 3.3k	CRMA5B (2)	
DI05 —	RV RV	CRMA5B (3)	
L	──┘ ∳─└_♪	CRMA5B (4)	
DI06 ——	RV	CRMA5B (5)	
DI07[	RV		)
DI08	RV	CRMA5B (6)	
DI09	RV	CRMA5B (7)	
DI10	RV RV	CRMA5B (8)	
L	•_L_J	CRMA5B (9)	
DI11	RV		
DI12	RV	CRMA5B (10)	
DI13	RV	CRMA5B (11)	
DI14	RV	CRMA5B (12)	
DI15	RV RV	CRMA5B (13)	
L L	•	CRMA5B (14)	
DI16 —	RV	CRMA5B(15)	
DI17	RV		
DI18	RV	CRMA5B (16)	)
DI19	RV	CRMA5B (29)	
DI20	RV	CRMA5B (30)	
DI20	RV RV	CRMA5B (31)	
L	•_L_J	CRMA5B (32)	
DI22 —	RV		
COM-2	RV +24E B A	CRMA5B (17,18)	
Set this jumper a	ccording to the		
common voltage o (ICOM2)	f input devices.	0V	

### NOTE

In this diagram, common voltage of input devices is +24V.

B-83195EN/09


CONNECTIONS

DOSI	Connector pin No.	Peripheral device
		+24V $^{0V}$
	CRMA5B (23,28,37,42,47)	power supply
Driver circuit		
DO01		LOAD
	CRMA5B (33)	
	CRMA5B (34)	
DO02 DV	CRMA5B (35)	LOAD
DO03 DV	<b></b>	LOAD
DO04 DV	CRMA5B (36)	LOAD
DO05 DV	CRMA5B (38)	
DO06 DV	CRMA5B (39)	LOAD
DO07 DV	CRMA5B (40)	LOAD
DO08 DV	CRMA5B (41)	
DO09 DV	CRMA5B (43)	
DO10 DV	CRMA5B (44)	
DO 11 DV	CRMA5B (45)	
DO12 DV	CRMA5B (46)	
DO13 DV	CRMA5B (19)	
DO14 DV	CRMA5B (20)	
DO15 DV	CRMA5B (21)	
DO16 DV	CRMA5B (22)	
D017 DV	CRMA5B (24)	
	CRMA5B (25)	
DO18 DV DO19 DV	CRMA5B (26)	
	CRMA5B (27)	
DO20 DV	CRMA5B (17,18)	LOAD
	TBSRC1(2)	
	· · · · · · · · · · · · · · · · · · ·	
ximum output current per	0V	

4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS

B-83195EN/09



#### NOTE

In this diagram, common voltage of input devices is +24V.

B-83195EN/09

CONNECTIONS

#### 4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

ntroller (peripheral device cont		Peripheral device
	Connector pin No.	+24V 0V
	CRMA5C (23,28,37,42,47)	+24V regulated power supply
Driver circuit		
DV		
DO21	CRMA5C (33)	
DO22 DV	CRMA5C (34)	
DO23 DV	CRMA5C (35)	
DO24 DV	CRMA5C (36)	
DO25 DV	CRMA5C (38)	
DO26 DV	CRMA5C (39)	
D027 DV	CRMA5C (40)	
DO28 DV	CRMA5C (41)	
DO29 DV	CRMA5C (43)	
DO29 $DVDO30$ $DV$	CRMA5C (44)	
$DO30 \longrightarrow DV$ $DO31 \longrightarrow DV$	CRMA5C (45)	
	CRMA5C (46)	
	CRMA5C (19)	
	CRMA5C (20)	
	CRMA5C (21)	
$DO35 \longrightarrow DV$	CRMA5C (22)	
DO36 DV	CRMA5C (24)	
DO37 DV	CRMA5C (25)	
DO38 DV	CRMA5C (26)	
DO39 DV	CRMA5C (27)	
DO40 DV		LOAD
	CRMA5C (17,18)	•
	TBSRC2(2)	
naximum output current per	OV	

4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS

#### B-83195EN/09

How State in the system of	roller (peripheral device contro	ol interface A4)	Peripheral device
Receiver circuitFUSE1DI43RV $3.3k$ CRMA5D (1)DI44RVCRMA5D (2)DI45RVCRMA5D (3)DI46RVCRMA5D (5)DI47RVCRMA5D (6)DI48RVCRMA5D (6)DI49RVCRMA5D (7)DI50RVCRMA5D (8)DI51RVCRMA5D (9)DI52RVCRMA5D (10)DI53RVCRMA5D (11)DI54RVCRMA5D (12)DI55RVCRMA5D (13)DI56RVCRMA5D (14)DI57RVCRMA5D (15)DI58RVCRMA5D (30)DI60RVCRMA5D (32)DI61RVCRMA5D (32)COM-4RVCRMA5D (17,18)+24EBAOV		+248	
DI43 RV 3.3k CRMA5D (1) DI44 RV CRMA5D (2) DI45 RV CRMA5D (3) DI46 RV CRMA5D (4) DI47 RV CRMA5D (5) DI48 RV CRMA5D (6) DI48 RV CRMA5D (6) DI49 RV CRMA5D (7) DI50 RV CRMA5D (8) DI51 RV CRMA5D (9) DI51 RV CRMA5D (10) DI52 RV CRMA5D (10) DI53 RV CRMA5D (11) DI55 RV CRMA5D (12) DI56 RV CRMA5D (12) DI57 RV CRMA5D (13) DI58 RV CRMA5D (14) DI59 RV CRMA5D (16) DI59 RV CRMA5D (30) DI60 RV CRMA5D (30) DI61 RV CRMA5D (31) DI62 RV CRMA5D (32) COM 4 RV CRMA5D (17, 18) +24E B A OV		$\square$ CRMA5D (49,50)	
DI43 $\mathbb{R}^{V}$ 3.3k $\mathbb{CRMA5D}(2)$ DI44 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(3)$ DI45 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(3)$ DI46 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(4)$ DI47 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(5)$ DI48 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(6)$ DI49 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(7)$ DI49 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(7)$ DI50 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(9)$ DI51 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(9)$ DI52 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(10)$ DI53 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(10)$ DI54 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(12)$ DI55 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(12)$ DI56 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(13)$ DI57 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(14)$ DI58 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(13)$ DI59 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(29)$ DI60 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(30)$ DI61 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(31)$ DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(31)$ DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(12)$ DI64 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(31)$ DI55 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(32)$ $\mathbb{C}^{CM} - 4 \mathbb{R}^{V}$ $\mathbb{CRMA5D}(32)$ $\mathbb{C}^{CM} - 4 \mathbb{R}^{V}$ $\mathbb{CRMA5D}(12)$ DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(12)$ $\mathbb{C}^{CM} - 4 \mathbb{R}^{V}$ $\mathbb{CRMA5D}(17)$ $\mathbb{C}^{CM} - 4 \mathbb{R}^{V}$ $\mathbb{CR}^{CM} - 4 \mathbb{CR}^{V}$ $\mathbb{CR}^{CM} - 4 \mathbb{CR}^{V}$ $\mathbb{CR}^{CM} - 4 \mathbb{CR}^{V}$ $\mathbb{CR}^{M} $	Receiver circuit		Ĭ
DI44 RV CRMA5D (2) DI45 RV CRMA5D (3) DI46 RV CRMA5D (5) DI47 RV CRMA5D (6) DI48 RV CRMA5D (6) DI49 RV CRMA5D (7) DI49 RV CRMA5D (7) DI50 RV CRMA5D (8) DI51 RV CRMA5D (9) DI52 RV CRMA5D (9) DI52 RV CRMA5D (10) DI53 RV CRMA5D (11) DI54 RV CRMA5D (12) DI55 RV CRMA5D (12) DI55 RV CRMA5D (13) DI56 RV CRMA5D (14) DI57 RV CRMA5D (15) DI58 RV CRMA5D (16) DI59 RV CRMA5D (30) DI60 RV CRMA5D (30) DI61 RV CRMA5D (31) DI62 RV CRMA5D (31) DI62 RV CRMA5D (32) COM 4 RV CRMA5D (17, 18) +24E B A $0V$	DI43 RV	CRMA5D (1)	
DI 45 RV CRMA5D (3) DI 46 RV CRMA5D (5) DI 47 RV CRMA5D (5) DI 48 RV CRMA5D (7) DI 49 RV CRMA5D (7) DI 49 RV CRMA5D (8) DI 50 RV CRMA5D (9) DI 51 RV CRMA5D (9) DI 52 RV CRMA5D (10) DI 52 RV CRMA5D (11) DI 53 RV CRMA5D (12) DI 54 RV CRMA5D (12) DI 55 RV CRMA5D (13) DI 56 RV CRMA5D (14) DI 57 RV CRMA5D (14) DI 58 RV CRMA5D (15) DI 59 RV CRMA5D (30) DI 60 RV CRMA5D (30) DI 61 RV CRMA5D (31) DI 62 RV CRMA5D (17, 18) +24E B A $_{0V}$		CRMA5D (2)	
DI46 RV CRMA5D (4) DI47 RV CRMA5D (5) DI48 RV CRMA5D (6) DI48 RV CRMA5D (7) DI49 RV CRMA5D (7) DI50 RV CRMA5D (8) DI51 RV CRMA5D (9) DI51 RV CRMA5D (10) DI52 RV CRMA5D (10) DI53 RV CRMA5D (11) DI54 RV CRMA5D (12) DI55 RV CRMA5D (13) DI55 RV CRMA5D (14) DI57 RV CRMA5D (14) DI57 RV CRMA5D (15) DI59 RV CRMA5D (16) DI59 RV CRMA5D (29) DI60 RV CRMA5D (30) DI61 RV CRMA5D (31) DI62 RV CRMA5D (32) COM-4 RV CRMA5D (17, 18) +24E B A OV	•	CRMA5D (3)	
DI47 RV CRMA5D (5) DI48 RV CRMA5D (6) DI49 RV CRMA5D (7) DI50 RV CRMA5D (8) DI51 RV CRMA5D (9) DI51 RV CRMA5D (9) DI52 RV CRMA5D (10) DI53 RV CRMA5D (11) DI54 RV CRMA5D (12) DI55 RV CRMA5D (13) DI55 RV CRMA5D (14) DI56 RV CRMA5D (14) DI57 RV CRMA5D (15) DI58 RV CRMA5D (16) DI59 RV CRMA5D (29) DI60 RV CRMA5D (30) DI61 RV CRMA5D (31) DI62 RV CRMA5D (32) COM-4 RV CRMA5D (17, 18) +24E B A OV	•	CRMA5D (4)	Ĭ < I
DI48 RV CRMA5D (6) DI49 RV CRMA5D (7) DI50 RV CRMA5D (9) DI51 RV CRMA5D (9) DI51 RV CRMA5D (10) DI52 RV CRMA5D (11) DI53 RV CRMA5D (12) DI54 RV CRMA5D (12) DI55 RV CRMA5D (13) DI55 RV CRMA5D (14) DI56 RV CRMA5D (14) DI57 RV CRMA5D (15) DI58 RV CRMA5D (16) DI59 RV CRMA5D (29) DI60 RV CRMA5D (30) DI61 RV CRMA5D (31) DI62 RV CRMA5D (32) COM-4 RV CRMA5D (17,18) +24E B A OV	· · · · · · · · · · · · · · · · · · ·	CRMA5D (5)	
DI48 RV CRMA5D (7) DI49 RV CRMA5D (8) DI50 RV CRMA5D (9) DI51 RV CRMA5D (9) DI52 RV CRMA5D (10) DI52 RV CRMA5D (11) DI53 RV CRMA5D (12) DI54 RV CRMA5D (12) DI55 RV CRMA5D (13) DI56 RV CRMA5D (14) DI57 RV CRMA5D (15) DI57 RV CRMA5D (16) DI58 RV CRMA5D (16) DI59 RV CRMA5D (30) DI60 RV CRMA5D (30) DI61 RV CRMA5D (31) DI62 RV CRMA5D (17,18) +24E B A OV CRMA5D (17,18) +24E B A OV	· · · · · · · · · · · · · · · · · · ·		
DI49 RV CRMA5D (8) DI50 RV CRMA5D (9) DI51 RV CRMA5D (10) DI52 RV CRMA5D (11) DI53 RV CRMA5D (12) DI54 RV CRMA5D (12) DI55 RV CRMA5D (13) DI55 RV CRMA5D (14) DI56 RV CRMA5D (14) DI57 RV CRMA5D (15) DI57 RV CRMA5D (16) DI58 RV CRMA5D (29) DI60 RV CRMA5D (30) DI60 RV CRMA5D (31) DI61 RV CRMA5D (32) COM-4 RV CRMA5D (17,18) +24E B A OV			
DIS0 RV CRMA5D (9) DIS1 RV CRMA5D (10) DIS2 RV CRMA5D (11) DIS3 RV CRMA5D (12) DIS4 RV CRMA5D (12) DIS5 RV CRMA5D (13) DIS5 RV CRMA5D (14) DIS6 RV CRMA5D (15) DIS7 RV CRMA5D (16) DI58 RV CRMA5D (16) DI59 RV CRMA5D (29) DI60 RV CRMA5D (31) DI61 RV CRMA5D (31) DI62 RV CRMA5D (32) COM-4 RV CRMA5D (17,18) +24E B A OV	DI49 RV		-
DI51 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(10)$ DI52 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(11)$ DI53 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(12)$ DI54 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(13)$ DI55 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(13)$ DI56 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(14)$ DI57 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(16)$ DI58 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(16)$ DI59 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(29)$ DI60 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(30)$ DI61 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(31)$ DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(31)$ DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}(17,18)$ +24E B A $\mathbb{O}^{V}$ et this jumper according to the $\mathbb{O}^{V}$	DI50 RV		
DI52 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (11) DI53 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (12) DI54 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (12) DI55 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (13) DI56 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (14) DI57 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (15) DI58 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (16) DI58 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (29) DI60 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (29) DI60 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (30) DI61 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (31) DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (32) $\mathbb{C}^{OM-4}$ $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (17, 18) $+24\mathbb{E}$ B A $\mathbb{O}^{V}$ $\mathbb{C}^{CRMA5D}$ (17, 18) $\mathbb{C}^{CRMA5D}$ (17, 18) $\mathbb{C}$	DI51 RV	CRMA5D (9)	
DI53 $\mathbb{RV}$ CRMA5D (11) DI54 $\mathbb{RV}$ CRMA5D (12) DI55 $\mathbb{RV}$ CRMA5D (13) DI55 $\mathbb{RV}$ CRMA5D (14) DI56 $\mathbb{RV}$ CRMA5D (14) DI57 $\mathbb{RV}$ CRMA5D (16) DI58 $\mathbb{RV}$ CRMA5D (29) DI59 $\mathbb{RV}$ CRMA5D (29) DI60 $\mathbb{RV}$ CRMA5D (30) DI61 $\mathbb{RV}$ CRMA5D (31) DI62 $\mathbb{RV}$ CRMA5D (32) COM-4 $\mathbb{RV}$ CRMA5D (17,18) +24E B A OV	DI52 RV	CRMA5D (10)	
DI54 $\mathbb{RV}$ $\mathbb{CRMA5D}(12)$ DI55 $\mathbb{RV}$ $\mathbb{CRMA5D}(13)$ DI56 $\mathbb{RV}$ $\mathbb{CRMA5D}(14)$ DI57 $\mathbb{RV}$ $\mathbb{CRMA5D}(15)$ DI58 $\mathbb{RV}$ $\mathbb{CRMA5D}(16)$ DI59 $\mathbb{RV}$ $\mathbb{CRMA5D}(29)$ DI60 $\mathbb{RV}$ $\mathbb{CRMA5D}(30)$ DI61 $\mathbb{RV}$ $\mathbb{CRMA5D}(31)$ DI62 $\mathbb{RV}$ $\mathbb{CRMA5D}(31)$ DI62 $\mathbb{RV}$ $\mathbb{CRMA5D}(32)$ $\mathbb{COM} - 4$ $\mathbb{RV}$ $\mathbb{CRMA5D}(17, 18)$ $+24\mathbb{E}$ B A $\mathbb{OV}$ et this jumper according to the $\mathbb{OV}$	• • • • • • • • • • • • • • • • • • •	CRMA5D (11)	
DI55 $\mathbb{RV}$ CRMA5D (13) DI56 $\mathbb{RV}$ CRMA5D (14) DI56 $\mathbb{RV}$ CRMA5D (15) DI57 $\mathbb{RV}$ CRMA5D (16) DI58 $\mathbb{RV}$ CRMA5D (29) DI59 $\mathbb{RV}$ CRMA5D (29) DI60 $\mathbb{RV}$ CRMA5D (30) DI61 $\mathbb{RV}$ CRMA5D (31) DI62 $\mathbb{RV}$ CRMA5D (32) COM-4 $\mathbb{RV}$ CRMA5D (17,18) +24E B A $\mathbb{OV}$ et this jumper according to the $\mathbb{OV}$	• • • • • • • • • • • • • • • • • • •		Ĭ _ Ī
DI55 $\mathbb{R}^{V}$ CRMA5D (14) DI56 $\mathbb{R}^{V}$ CRMA5D (15) DI57 $\mathbb{R}^{V}$ CRMA5D (16) DI58 $\mathbb{R}^{V}$ CRMA5D (29) DI59 $\mathbb{R}^{V}$ CRMA5D (29) DI60 $\mathbb{R}^{V}$ CRMA5D (30) DI61 $\mathbb{R}^{V}$ CRMA5D (31) DI62 $\mathbb{R}^{V}$ CRMA5D (32) COM-4 $\mathbb{R}^{V}$ CRMA5D (17,18) +24E B A $\mathbb{O}^{V}$ CRMA5D (17,18) +24E B A $\mathbb{O}^{V}$			
DI 56 $\mathbb{R}^{V}$ CRMA5D (15) DI 57 $\mathbb{R}^{V}$ CRMA5D (16) DI 58 $\mathbb{R}^{V}$ CRMA5D (29) DI 59 $\mathbb{R}^{V}$ CRMA5D (29) DI 60 $\mathbb{R}^{V}$ CRMA5D (30) DI 61 $\mathbb{R}^{V}$ CRMA5D (31) DI 62 $\mathbb{R}^{V}$ CRMA5D (32) COM-4 $\mathbb{R}^{V}$ CRMA5D (17,18) +24E B A $\mathbb{O}^{V}$ CRMA5D (17,18) +24E B A $\mathbb{O}^{V}$	DI55 RV		
DI57 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (16) DI58 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (29) DI59 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (30) DI60 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (30) DI61 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (31) DI62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (32) $\mathbb{COM}^{-4}$ $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (17, 18) $+24\mathbb{E}$ B A $\mathbb{O}^{V}$ et this jumper according to the $\mathbb{O}^{V}$	DI56 RV		
DI 58 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (29) DI 59 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (30) DI 60 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (31) DI 61 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (31) DI 62 $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (32) $\mathbb{COM}^{-4}$ $\mathbb{R}^{V}$ $\mathbb{CRMA5D}$ (17,18) +24 $\mathbb{E}$ $\mathbb{B}$ $\mathbb{A}$ $\mathbb{OV}$ et this jumper according to the $\mathbb{OV}$	DI57 RV		
DI 59 $\mathbb{R}^{V}$ CRMA5D (30) DI 60 $\mathbb{R}^{V}$ CRMA5D (31) DI 61 $\mathbb{R}^{V}$ CRMA5D (31) DI 62 $\mathbb{R}^{V}$ CRMA5D (32) COM-4 $\mathbb{R}^{V}$ CRMA5D (17,18) +24 $\mathbb{E}$ $\mathbb{B}$ $\mathbb{A}$ $\mathbb{O}^{V}$ et this jumper according to the $\mathbb{O}^{V}$	DI58 RV	CRMA5D (16)	
DIGO RV CRMA5D (30) DIGO RV CRMA5D (31) DIG2 RV CRMA5D (31) DIG2 RV CRMA5D (32) COM-4 RV CRMA5D (17,18) +24E B A OV et this jumper according to the OV	DI59	CRMA5D (29)	
DI61 RV CRMA5D (31) DI62 RV CRMA5D (32) COM-4 RV CRMA5D (17, 18) +24E B A $0V$ et this jumper according to the $0V$		CRMA5D (30)	
DIG2 RV CRMA5D (32) COM-4 RV CRMA5D (17,18) +24E B A OV et this jumper according to the OV		CRMA5D (31)	Ĭ _ Ĭ
$COM-4 \xrightarrow{RV} CRMA5D (17,18)$ $+24E B A \xrightarrow{0} 0V$ et this jumper according to the $0V$	• • • • • • • • • • • • • • • • • • •		
$\begin{array}{c c} +24E & B & A & \\ \hline \\$	• • • • • • • • • • • • • • • • • • •		
et this jumper according to the $\frac{1}{0V}$ mmon voltage of input devices.			
et this jumper according to the 0V or 0V	$+24 \mathbf{E}  \mathbf{B} \mid \mathbf{A}$		
mmon voltage of input devices.			
XOM4)	et this jumper according to the	$\frac{1}{0V}$	
,	COM4)		

## NOTE

In this diagram, common voltage of input devices is +24V.


B-83195EN/09

CONNECTIONS

#### 4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES


troller (peripheral de			Peripheral device
	DOSRC2	2 Connector pin N <u>o.</u>	
		CR MA5D (23,28,37,42,47)	
			power supply
Driver circuit			
DO41			LOAD
		CRMA5D (33)	
DO42	DV	CRMA5D (34)	LOAD
DO43 —	DV	CRMA5D (35)	LOAD
DO44	DV	CRMA5D (36)	
DO45	DV	CRMA5D (38)	
DO46	DV —	CRMA5D (39)	
DO47	DV	CRMA5D (40)	
DO48	DV DV	CRMA5D (41)	
		CRMA5D (43)	
DO49	DV —	CRMA5D (44)	
DO50 —	DV	CRMA5D (45)	LOAD
DO51	DV	CRMA5D (46)	LOAD
DO52	DV	CRMA5D (19)	LOAD
DO53 —	DV	CRMA5D (20)	LOAD
DO54 —	DV	)	LOAD
DO55 —	DV	CRMA5D (21)	LOAD
DO56 —	DV	CRMA5D (22)	LOAD
DO57 —	DV	CRMA5D (24)	LOAD
DO58	DV	CRMA5D (25)	LOAD
DO59	DV	CRMA5D (26)	
DO60	DV —	CRMA5D (27)	
	]	CRMA5D (17,18)	
		TBSRC2(2)	Ţ
A maximum outou	it current pe	r DO point is 0.2 A	

B-83195EN/09



#### NOTE


In this diagram, common voltage of input devices is +24V.




#### NOTE

In this diagram, common voltage of input devices is +24V.

# 4.3.2 Connection between the Process I/O Board MA and Peripheral Devices



- 1 The peripheral device connection cable is optional.
- 2 The DOSRC3 pin of CRMA52A and CRMA52B supply power to the drivers (connect all pins).




**NOTE** In this diagram, common voltage of input device is 24V.

4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS

B-83195EN/09



**NOTE** In this diagram, common voltage of input device is +24V.

The following shows the connector interface of the optional peripheral device cables on the peripheral device side.

		Periph	neral de	evice A3		
	01	DI01	7		33	DO01
	02	DI02	19		34	DO02
	03	DI03	20		35	DO03
	04	DI04	21		36	DO04
O board	05	DI05	22		37	DO05
	06	DI06	23		38	DO06
	07	DI07	24		39	DO07
	08	DI08	25		40	D008
	09	DI09	26		41	
	 10	DI10	27		42	
CRMA52A	11		28		43	
	12		29	0V	44	
	13		30	0V	45	
	14		31	DOSRC3	46	
	15		32	DOSRC3	47	
	16				48	
	17	0V			49	+24F
	18	0V			50	+24F
	01	DI11	٦		33	DO09
	01		- Т	al device A4		DOOO
	02	DI12	19		34	DO10
	03	DI13	20		35	D011
	04	DI14	21		36	DO12
	05	DI15	22		37	DO13
	06	DI16	23		38	DO14
	 07	DI17	24		39	DO15
CRMA52B	08	DI18	25		40	DO16
	09	DI19	26		41	
	10	DI20	27		42	
	11		28		43	
	12		29	0V	44	
	13		30	0V	45	
	14		31	DOSRC3	46	
	15		32	DOSRC3	47	
	16	017			48 49	+24F
	17 18	0V 0V			49 50	
	18	υv			90	+24F

### NOTE

Refer to the previous page about details of connection.

# **4.4** INTERFACE FOR WELDER


# 4.4.1 Connection between the Process I/O Board MB and Welding Machines

Controller	Weldi	ng machine in CRW11	nterface	
		А	В	
	01	WI02	24F	
	02	WI03	24F	
	03	WI04	0V	Welding
	04	WI05	0V	machine
	05	WI06	WDI+	
	06	WO01	WDI-	
	07	WO02	DACH1	
	08	WO04	COMDA	
	09	WO05	DACH2	
	10		COMDA	

#### NOTE

1 The welding machine connection cable is optional.

B-83195EN/09




Pin-to-pin connection between CRW11 connector and welding machine connector (FANUC interface) (Analog output, welding wire deposition detection, WI/WO connection)

# **4.4.2** Connection between the Process I/O Board KA, KB and Welding Machines

			CRW10			
01	DACH1		••••••	33	WO1	
02	COMDA1	19	ADCH1	34	WCOM1	
03	DACH2	20	COMAD1	35	WO2	
04	COMDA2	21	ADCH2	36	WCOM12	
05	DACH3	22	COMAD2	37	WO3	
06	COMDA3	23		38	WCOM3	
07	WI1	24		39	WO4	
08	WI2	25	WDI+	40	WCOM4	
09	WI3	26	WDI-	41	WO5	Welding machir
10	WI4	27		42	WCOM5	
11	WI5	28		43	WO6	
12	WI6	29		44	WCOM6	
13	WI7	30		45	WO7	
14	WI8	31		46	WCOM7	
15	0V	32		47	WO8	
16	0V			48	WCOM8	
17	0V			49	+24E	
18	0V			50	+24E	

The welding machine connection cables are options.


# Pin-to-pin connection between CRW10 connector and welding machine connector (general interface) (Analog output, welding wire deposition detection, WI/WO connection, for connections with +24 V common)



## NOTE


In this diagram, common voltage of input devices is +24V.

# Pin-to-pin connection between CRW10 connector and welding machine connector: FANUC interface (Analog input/output, welding wire deposition detection, WI/WO connection, for connections with +24 V common)



# 4.5 EE INTERFACE

## **4.5.1** Connection between the Mechanical Unit and End Effector




#### Fig.4.5.1 EE interface

# **NOTE** EE interface depends on the option of the robot. Refer to the robot-specific operator's manual.

4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS

B-83195EN/09




- 1 In this diagram, common voltage of input devices is +24V.
- 2 The common-level change-over setting pin or switch (COM1) is in the 6-axis servo amplifier.

# 4.6 DIGITAL I/O SIGNAL SPECIFICATIONS

This section describes the specifications of the digital I/O signals interfaced with the peripheral device, end effector, and arc welder.

## 4.6.1 Peripheral Device Interface A

- (1) Output signals in peripheral device interface A (Source type DO)
  - (a) Example of connection



 (b) Electrical specifications Maximum load current when driver is on: Saturation voltage when driver is on: Dielectric strength: Leakage current when driver is off:

200mA (including momentary level) 1.0V max. 24V ±20% (including momentary level) 100μA

(c) The external power supply to output signals must satisfy the following: Power supply voltage:  $+24V \pm 10\%$ 

Power supply current: For each printed circuit board of this type (Total sum of maximum load currents including momentary levels + 100mA or more)

Power-on timing:

At the same time when the controller is turned on or earlier Power-off timing: At the same time when the controller unit is turned off or later

- (d) Spark killer diode
   Rated peak reverse voltage: 100V or more
   Rated effective forward current: 1A or more
- (e) Driver for output signals

In the driver device, the current of each output signal is monitored, and when an overcurrent is detected, the relevant output is turned off. After an output has been turned off by overcurrent, the overcurrent state is released because the output is off, so the output on state is restored. Therefore, in the ground fault or overcurrent state, the output is turned on and off repeatedly. Such a condition is found also when a load with a high surge current is connected.

The driver device also includes an overheat detection circuit, which turns off all outputs of the device when the internal temperature of the device has increased as a result of a continued overcurrent state due to a ground fault of an output and so on. The outputs are held off, but their normal states can be restored by turning the power to the controller on and off after the internal temperature of the device has lowered.

(f) Note on use

Do not use the +24V power supply of the robot.


When adding a relay, solenoid, or the like directly to the circuit, connect a diode for counter electromotive voltage protection in parallel to the load.

When using a load, such as a lamp, that generates surge current when it is turned on, install a protection resistor.

(g) Applicable signals


Output signals of process I/O board CRMA5 and CRMA6 CMDENBL, SYSRDY, PROGRUN, PAUSED, HELD, FAULT, ATPERCH, TPENBL, BATALM, BUSY, ACK1 to ACK8, SNO1 to SNO8, SNACK, DO1 to DO76

- (2) Input signals in peripheral device interface A
  - (a) Example of connection



- (c) Specifications of the peripheral device contact Voltage and Current: DC24V, 0.1A

Voltage and Current.	DC24V, 0.1A
	(Use a contact which minimum load is 5mA or less.)
Input signal width:	200ms or more (on/off)
Chattering time:	5ms or less
Closed circuit resistance:	$100\Omega$ or less
Opened circuit resistance:	$100 \mathrm{k}\Omega$ or more




- (d) Note on use
   Apply the +24 V power at the robot to the receiver.
   However, the above signal specifications must be satisfied at the robot receiver.
- (e) Applicable signals

Input signals of process I/O board CRMA5 and CRMA6 XIMSTP, XHOLD, XSFSD, CSTOPI, FAULT RESET, START, HOME, ENBL, RSR1 to RSR8, PNSTROBE, PROD START, DI1 to DI78

### 4.6.2 EE Interface

- (1) Output signals in EE interface
  - (a) Example of connection



- (b) Electrical specifications

   Maximum load current when driver is on: Saturation voltage when driver is on: Dielectric strength:
   Leakage current when driver is off:

   200mA (including momentary level)

   1.0V max.
   24V ±20% (including momentary level)
   100µA
- (c) Power supply to output signals

The +24V power supply on the robot side can be used if the total current level, including the current of the welding interface, is 0.7A or less.

(d) Driver for output signals

In the driver device, the current of each output signal is monitored, and when an overcurrent is detected, the relevant output is turned off. After an output has been turned off by overcurrent, the overcurrent state is released because the output is off, so the output on state is restored. Therefore, in the ground fault or overcurrent state, the output is turned on and off repeatedly. Such a condition is found also when a load with a high surge current is connected.

The driver device also includes an overheat detection circuit, which turns off all outputs of the device when the internal temperature of the device has increased as a result of a continued overcurrent state due to a ground fault of an output and so on. The outputs are held off, but their normal states can be restored by turning the power to the controller on and off after the internal temperature of the device has lowered.

(e) Note on use


When adding a relay, solenoid, or the like directly to the circuit, connect a diode for counter electromotive voltage protection in parallel to the load. When using a load, such as a lamp, that generates surge current when it is turned on, install a

When using a load, such as a lamp, that generates surge current when it is turned on, install a protection resistor.

- (f) Applicable signals RO1 to RO8
- (2) Input signal in peripheral device interface The input signals are the same as those of other I/O boards. (Refer to Subsection 4.5.1 in CONNECTIONS.)
  - (a) Applicable signals RI1 to RI8, XHBK, XPPABN

### 4.6.3 I/O Signal Specifications for ARC-Welding Interface (A-cabinet/Process I/O Board MB)

- (1) Specification for arc welding machine interface digital output signals
  - (a) Example of connection



- (b) Electrical specifications

  Rated voltage:
  Maximum applicable voltage:
  Maximum load current:
  Transistor type:
  Saturation voltage when the circuit is on:

  (b) Electrical specifications

  24VDC
  30VDC
  200mA (including momentary level)
  Open-collector NPN
  Approximately 1.0V
- (c) Spark killer diode
   Rated peak-to-peak reverse withstand voltage: 1
   Rated effective forward current: 1

100V or higher 1A or more


(d) Caution for use


The arc welding machine interface can use the +24V power supply of the robot unless the sum of its sink current and that of the EE interface exceeds 0.7A. When using a relay or solenoid directly as a load, connect the load and a back electromotive force voltage prevention diode in parallel.

When using a load, such as a lamp, that generates surge current when it is turned on, install a protection resistor.

(e) Applicable signals Arc welding machine interface output signals [WO1, 2,4,5]

- (2) Specification for arc welding machine interface digital output signals
  - (a) Example of connection






(d) Note on use

Apply the +24 V power at the robot to the receiver. However, the above signal specifications must be satisfied at the robot receiver.

(e) Applicable signals Arc welding machine interface input signals [WI2 to 6]


- (3) Specification for arc welding machine interface analog output signals (welding voltage and wire feed specification signals)
  - (a) Example of connection



(b) Caution for use Input impedance:  $3.3k\Omega$  or higher Install a high-frequency filter.

(Wire deposit detection: WDI+ and WDI-)

(a) Example of connection



Welding electrode

#### (Wire deposition detection: WDI+, WDI-)

(b) Caution for use

The resistance between the + and - terminals of the welding machine must be 100  $\Omega$  or higher.

The TIG welding deposition detection circuit must be isolated from the welding circuit (high frequency).

This circuit can withstand up to 80 V.

B-83195EN/09


# 4.7 SPECIFICATIONS OF THE CABLES USED FOR PERIPHERAL DEVICES AND WELDERS

If the customer manufactures cables, make sure they conform to the FANUC standard cables described in this section.


CONNECTIONS

(See the description in "Peripheral Device Interface" in this manual for the specifications of the FANUC standard cables.)


### 4.7.1 Peripheral Device Interface A Cable (CRMA5\*: Honda Tsushin, 50 pins)




# **4.7.2** Peripheral Device Interface B Cable (CRMA6\*: Honda Tsushin, 20 pins)



## 4.7.3 Peripheral Device Interface B1 and B2 Cables (CRMA52; TE Connectivity 30 pin)




### 4.7.4 ARC Weld Connection Cables (CRW11; TE Connectivity 20 pin)



# **4.8** CABLE CONNECTION FOR THE PERIPHERAL DEVICES, END EFFECTORS, AND ARC WELDERS


### **4.8.1** Peripheral Device Connection Cable

Fig.4.8.1 shows the connection of the peripheral device cable in the cabinet.



(B-cabinet)

CONNECTIONS




### NOTE

For protection against the noise, cut part of the jacket of the connection cable to expose the shield, and fasten this part to the earth plate with the cable clamp.

Fig.4.8.1 Peripheral Device Cable Connection

### 4.8.2 Peripheral Device Cable Connector




(1) Fig.4.8.2 shows the connector for peripheral device cables A and B.

Connector	Applicable	Dimensions			Remark	
specifications	interface	Α	(B)	С	(D)	
MR-50F(Connector) MR-50L+(Case)	CRMA5	67.9	73.5	44.8	18	Honda Tsushin Kogyo, 50 pins Female, Solder type
MR-20F(Connector) MR-20L+(Case)	CRMA6	39.3	44.9	39.8	17	Honda Tsushin Kogyo, 20 pins Female, Solder type

Symbol	Name
<1>	Connector cover
<2>	Cable clamp screw
<3>	Connector clamp spring
<4>	Connector clamp screw
<5>	Connector

Fig.4.8.2 (a) Peripheral device cable connector

#### (1) Fig.4.8.2 shows the connector for peripheral device cables A1 and A2.




Maintenance tool

Hand tool (for crimping contact) Extraction tool 2119141-1:A05B-2550-K064 1891526-1:A05B-2550-K061

Fig.4.8.2 (b) Peripheral device cable connector

### (2) Peripheral device connector




Connector	Applicable	Dimensions		Remark
specifications		Α	В	
MR-50RF+	Peripheral device	61.4	56.4	Honda Tsushin Kogyo, 50 pins
				Female, Solder type
MR-20RF+	Peripheral device	39.3	44.9	Honda Tsushin Kogyo, 20 pins
				Female, Solder type

Symbol	Name
<1>	Connector clamp screw
<2>	Screw M2.6 x 8
<3>	Connector

Fig.4.8.2 (c) Peripheral device connector

### **4.8.3** End Effector Cable Connector (EE interface)


(1) Connector external view (Example: For R-2000*i*B, M-710*i*C)



- A: M30 x 1
- B: 63.0
- C: 54.5
- D: 9.6 to 15.0 (Inside diameter)
- E: \$\$33
- F: 11.2
- G: 24.7


Manufactured by Fujikura JMLP2524M





- A: M30 x 1
- B: 54.1
- C: 37.5
- D: 9.6 to 15.0 (Inside diameter)
- E: \$\$33
- F: 11.2
- G: 24.7

Manufactured by Fujikura JMLP2524M



### NOTE

EE interface depends on the option of the robot. Refer to the robot-specific operator's manual of each robot.

### 4.8.4 Recommended Cables

(1) Peripheral device connection cable

Connect a peripheral device using a completely shielded, heavily protected cable conforming to the specifications in Table 4.8.4 (a).

Allow an extra 50 cm for routing the cable in the controller.

The maximum cable length is 30 m.

	Wire specifications	Conductor		Sheath	Effective	<b>Electrical characteristics</b>	
Number of wires		Diameter (mm)	Configuration		outside diameter (mm)	Conductor resistance (Ω/km)	Allowable current (A)
50	A66L-0001-0042	φ1.05	7/0.18 AWG24	1.5	φ12.5	106	1.6A
20	A66L-0001-0041	φ1.05	7/0.18 AWG24	1.5	φ10.5	106	1.6A

#### Table 4.8.4 (a) Recommended Cable (for Peripheral Device Connection)

(2) End effector connection cable

Connect an end effector using a heavily protected cable with a movable wire conforming to the specifications in Table 4.8.4 (b).

The cable length is determined so that the cable will not interfere with the end effector and the wrist can move through its full stroke.

	Wire specifications	Conductor		Sheath	Effective	Electrical characteristics	
Number of wires		Diameter (mm)	Configuration	thicknes	outside diameter (mm)	Conductor resistance (Ω/km)	Allowable current (A)
6	A66L-0001-0143	φ1.1	40/0.08 AWG24	1.0	φ <b>5</b> .3	91	3.7
20	A66L-0001-0144	φ1.1	40/0.08 AWG24	1.0	φ <b>8.6</b>	91	2.3
24	A66L-0001-0459	ф0.58	40/0.08 AWG24	1.0	<b>φ8.3</b>	93	2.3

#### Table 4.8.4 (b) Recommended Cable (for End Effector Connection)

#### NOTE


For protection against the noise, cut part of the jacket of the connection cable to expose the shield, and fasten this part to the earth plate with the cable clamp.

CONNECTIONS

### 4.9 CONNECTION OF HDI


### 4.9.1 Connecting HDI

The HDI signals are used in combination with special application software. The HDI signals cannot be used as general-purpose DIs.




(R-30*i*B)

(R-30*i*B Plus)



### **Cable connections**




### NOTE

- 1 Pair each signal with 0V.
- 2 For protection against the noise, cut part of the jacket of the connection cable to expose the shield, and fasten this part to the earth plate with the cable clamp.

### 4.9.2 Input Signal Rules for the High-speed Skip (HDI)

### **Circuit configuration**



Absolute maximum rating Input voltage range Vin: -3.6 to +10 V Input characteristics

Unit	Symbol	Specification	Unit	Remark
High level input voltage	VH	3.6 to 11.6	V	
Low level input voltage	VL	0 to 1.0	V	

4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS

Unit	Symbol	Specification	Unit	Remark
High level input current	liH	2 max	mA	Vin=5 V
		11 max	mA	Vin = 10 V
Low level input current	liL	-8.0 max	mA	Vin = 0 V
Input signal pulse duration		20 min	μS	
Input signal delay or variations		20 max	μS	


#### NOTE

- 1 The plus (+) sign of liH/liL represents the direction of flow into the receiver. The minus (-) sign of liH/liL represents the direction of flow out of the receiver.
- 2 The high-speed skip signal is assumed to be 1 when the input voltage is at the low level and 0 when it is at the high level.

### 4.10 CONNECTING THE COMMUNICATION UNIT

### 4.10.1 RS232C Interface

### 4.10.1.1 Interface




NOTE

- 1 +24 V can be used as the power supply for FANUC RS232C equipment.
- 2 Do not connect anything to those pins for which signal names are not indicated.

#### B-83195EN/09

### 4.10.1.2 RS232C interface signals




Generally signals as follows are used in RS232C interface.


#### Fig.4.10.1.2 RS232C interface

### 4.10.1.3 Connection between RS232C interface and I/O device


The figure below shows a connection with the handshaking of the ER/DR, RS/CS signals.



• The figure below shows a connection without the handshaking of the RS/CS, ER/DR signals.



### **Cable connection**



#### NOTE

- 1 Pair each signal with SG.
- 2 For protection against the noise, cut part of the jacket of the connection cableto expose the shield, and fasten this part to the earth plate with the cable clamp.

### 4.10.2 Ethernet Interface

This section describes information relating to the physical Ethernet connection.

### 

- 1 Before connecting or disconnecting the Ethernet cable, make sure that the power to the robot controller is turned off.
- 2 Please inquire of each manufacturer (of hub, transceiver, cable etc.) about the construction of the network or the condition in which the equipment is being used. When configuring your network, you must take other sources of electrical noise into consideration to prevent your network from being influenced by electrical noise. Make sure that network wiring is sufficiently separated from power lines and other sources of electrical noise such as motors, and ground each of the devices as necessary. In addition, high and insufficient ground impedance may cause interference during communications. After installing the robot, conduct a communications test before you actually start operating the robot.

We cannot ensure operation that is influenced by network trouble caused by a device other than the robot controller.

### 4.10.2.1 Connection to Ethernet


The robot controller is provided with a 100BASE-TX and 1000BASE-T (Only R-30*i*B Plus) interface. Prepare a hub for connecting the controller to the Ethernet trunk. The following shows an example of a general connection.

To connect the control unit to the CD38C (for R-30iB Plus) Ethernet interface in a half duplex communication mode, use a hub which satisfies the following conditions:

- Supports 100BASE-TX/1000BASE-T.
- Has an auto-negotiation function.
- Supports store-and-forward switching.
- Supports flow controll.


Some devices (hub, transceiver, etc.) that are needed for building a network do not come in dust-proof construction. Using such devices in an atmosphere where they are subjected to dust or oil mist will interfere with communications or damage the robot controller. Be sure to install such devices in a dust-proof cabinet.

CONNECTIONS



### 4.10.2.2 Leading out the Ethernet Cable

For this type of controller, the cable is drawn out only from the front of the controller. See the outline drawing of each type of board for the location of the connector.



The Ethernet cable must be fastened by a cable clamp to prevent tension being applied to the modular connector (RJ-45) that connects the cable to the controller even if the Ethernet cable is pulled directly. This clamp is also used to ground the cable shield.

### 4.10.2.3 100BASE-TX Connector (CD38A, CD38B) / 1000BASE-T Connector (CD38C) Pin Assignments

#### CD38A,CD38B(R-30iB, R-30iB Plus)

Pin No.	Signal name	Description
1	TX+	Send +
2	TX-	Send -
3	RX+	Receive +
4		Not used
5		Not used
6	RX-	Receive -
7		Not used
8		Not used


#### CD38C(1000BASE-T, R-30*i*B Plus only)

Pin No.	Signal name	Description	
1	MDI0+	Bi-directional Data 0+	
2	MDI0-	Bi-directional Data 0-	
3	MDI1+	Bi-directional Data 1+	
4	MDI2+	Bi-directional Data 2+	
5	MDI2-	Bi-directional Data 2-	
6	MDI1-	Bi-directional Data 1-	
7	MDI3+	Bi-directional Data 3+	
8	MDI3- Bi-directional Dat		

### 4.10.2.4 Twisted-pair Cable Specification


#### **Cable Connection**

The cable used for connection between the 100BASE-TX/1000BASE-T interface, CD38, of the controller and the hub is connected as follows:




#### 4. PERIPHERAL DEVICE, ARC WELDING, AND EE INTERFACES

CONNECTIONS



- Keep the total cable length within 100 m. (The maximum cable length of the movable cable recommended by FANUC is 40m.) Do not extend the cable more than is necessary.
- The figure above shows the cable connection when cables are crossed in the hub. "X" is usually indicated at the port of the hub to signify that cables are crossed in the hub.



### (1) Cable Materials

### 

Unshielded cable (UTP cable) is commercially available as 100BASE-TX/ 1000BASE-T twisted-pair cable: You should, however, use shielded Category 5(100BASE-TX) / 5e(1000BASE-T) twisted-pair cable (STP cable) to improve the resistance to electrical noise in an FA environment.

Recommended Cables (100BASE-TX)				
Manufacturer Specification Remarks				
FURUKAWA ELECTRIC CO., LTD.	DTS5087C-4P	Twisted-pair cable		
NISSEI ELECTRIC CO., LTD. F-4PFWMF Single-conductor cable				

Inquiries

Manufa	acturer	Contact address
FURUKAWA ELECTRIC CO., LTD.		2-6-1 Marunouchi, Chiyoda-ku. Tokyo 100-8322
Sales Headquarters		TEL: 03-3286-3126 FAX: 03-3286-3979
NISSEI ELECTRIC CO., L	TD.	3F MU Bldg., 1-9-1 Minami-narise,
Machida Branch		Machida City, Tokyo 194-0045
		TEL: 0427-29-2531 FAX: 0427-29-3375
	<b>Overseas Sales Office</b>	IWATANI International Corporation
		Tokyo Head Office
		21-8 Nishi-shinbashi 3-chome, Minato-ku, TOKYO,
		105-8458, JAPAN
		TEL: 03-5405-5810 FAX: 03-5405-5666
		Telex: 2524256 IWATYO J
Remarks		A finished cable with connectors at both ends can be
		offered.

### NOTE

The recommended cables cannot be connected to moving parts.

#### Recommended cable (for movable parts, dedicated to FANUC)

Manufacturer	Specification	Remarks
Oki Electric Cable Co., Ltd.	AWG26 4P TPMC-C5E (S-HFR) K	CAT5e (1Gbps capable, For 1000BASE-T)
Oki Electric Cable Co., Ltd.	AWG26 4P TPMC-C5-F (SB)	CAT3, CAT5 (100Mbps capable, For 100BASE-TX)
Shinko Electric Industrial Co., Ltd.	FNC-118	CAT3, CAT5 (100Mbps capable, For 100BASE-TX)

Specification

1. Manufacture: Oki Electric Cable Co., Ltd. Manufacture's model number: AWG26 4P TPMC-C5E(S-HFR) K

- Electrical characteristic: Complying with EIA/TIA 568B.2 Category 5e.
- Structure: Common-shield braided cable with drain wire. The conductors of the cable are AWG26 annealed-copper strand wire, with a sheath 0.6 mm thick and an outer diameter of 6.8 mm.
- Fire resistance: UL1581 VW-1
- Oil resistance: As per Fanuc's internal standard (Equivalent to conventional oil-resistant electrical cable)
- Flexing resistance: Sliding: 3 millions or more sliding cycles with a bending radius of 50 mm. bending: 300 thousands or more bending cycles with a bending radius of 20 mm Twisting: 5 millions or more sliding cycles. (+/- 180degrees)
- UL style No. : AWM20276 (80°C/30V/VW-1)
- Manufacture: Oki Electric Cable Co., Ltd. Manufacture's model number: AWG26 4P TPMC-C5-F (SB) Manufacture: SHINKO ELECTRIC INDUSTRIES CO., LTD. Manufacture's model number: FNC-118
- Electric characteristics:

CONNECTIONS

Conforms to EIA/TIA 568A Category 3 and Category 5.

From the viewpoint of attenuation performance, ensure that the length to the hub is 50 m or less.

• Structure:

Group shielded (braided shield). A drain wire is available.

The conductor is an AWG26 annealed copper twisted wire, with a sheath thickness of 0.8 mm and an outer diameter of 6.7 mm  $\pm$ 0.3 mm.

- Fire retardancy: UL1581 VW-1
- Oil resistance: Conforms to the FANUC internal standards (equivalent to the conventional oil-resistant electric cables).
- Flexing resistance:

1,000,000 times or more with a bending radius of 50 mm (U-shaped flex test)

• UL style No. : AWM 20276 (80°C/30V/VW-1)

#### NOTE

Be sure to use the connector TM21CP-88P (03) manufactured by HIROSE ELECTRIC CO., LTD. for this cable.

Inquiries		
Manufacturer	Contact address	
Oki Electric Cable Co., Ltd.	Nagano Sales Office TEL:0266-27-1597	
Shinko Electric Industrial Co., Ltd.	Tokyo Sales Office TEL:03-3492-0073	

Cable assembly

Oki Electric Cable Co., Ltd. can also supply the cable assembly mentioned above.

Contact Oki Electric directly to determine the specifications (length, factory test, packing, and so forth) for purchase.

#### (2) Connector Specification

Use an 8-pin modular connector (RJ-45) with the twisted-pair cable for the Ethernet connection. The following connectors or equivalents must be used.

Non-Flex	Specification	Manufacturer	Remarks
Solid wire	5-569530-3	TE Connectivity	
Solid wire	MS8-RSZT-EMC	SK KOHKI CO., LTD.	Special tools required
Twisted-pair cable	5-569552-3	TE Connectivity	
Twisted-pair cable	TM11AP-88P	HIROSE ELECTRIC CO., LTD.	Special tools required

Flex	Specification	Manufacturer	Remarks
AWG26 4P TPMC-C5-F (SB)			
AWG26 4P TPMC-C5E (S-HFR) K,	TM21CP-88P (03)	HIROSE ELECTRIC CO., LTD.	Note
or FNC-118			

#### NOTE Information about TM21CP-88P (03): Connector (standard product of the manufacturer) Drawing number: A63L-0001-0823#P Manufacturer: HIROSE ELECTRIC CO., LTD. Manufacturer type number: TM21CP-88P (03) Conforms to EIA/TIA 568B.2 Category 5e. For assembly with a cable, contact HIROSE ELECTRIC CO., LTD. directly. (From HIROSE ELECTRIC CO., LTD., "TM21CP-88P (03) Connection Procedure Manual (Technical Specification No. ATAD-E2367)" is available as a technical document.)


### 4.10.2.5 Electrical Noise Countermeasures

### Clamping and Shielding Cables

Clamp an Ethernet twisted pair cable according to the method described below, as with cables that need to be shielded. Clamping cables provides support and shielding and is extremely important to the safe operation of the system. Never overlook cable clamping.

Peel off part of the jacket as shown in the figure to expose the outer coating of the shield, and press this outer coating against the earth plate with the cable clamp.

The machine manufacturer must prepare the ground plate and install it as follows:




### NOTE

To ensure the safe operation of the system, clamp and shield the cables.

#### NOTE

- 1 To secure fast response, FL-net communication is not provided with a retransmission process at intervals of several seconds, unlike normal Ethernet communication. It is, therefore, necessary to provide more noise resistance than that provided by general Ethernet wiring work.
- 2 After the laying of cables, conduct satisfactory communication tests not only before system operation but after system operation from the viewpoint of noise prevention measures.

### Cable route




#### Grounding the Network

Even if the grounding condition on the machine side is satisfied, the communication line can pick up noise from the machine, depending on the machine installation condition and environment, thus resulting

B-83195EN/09


in a communication error. To protect against such noise, the machine should be separated and insulated from the Ethernet trunk cable and personal computer. Examples of connection are given below.





#### NOTE

- 1 The ground between PC/HUB side and machine system side must be separated. If it is impossible to separate the ground because there is only one grounding point, connect the ground cable for each system to the grounding point independently. (See figure below.) The resistance for grounding must be less than 100-ohm (Class D). The thickness of the ground cable is the same as the thickness of AC power cable or more. At least thickness of 5.5mm<sup>2</sup> is necessary.
- 2 Note that the number of allowable hub-to-hub connections depends on the type of hub.
- 3 There is possibility that noise makes the obstacle of communication even if the ground is separated using the 100BASE-TX/1000BASE-T. In the case of using the FAST Ethernet/FAST Data Server under the worst environment, please separate between the PC/Trunk line side and machine system side completely using the 100BASE-FX/1000BASE-SX/LX (Optical fiber media).



Wiring on a single ground point

### 4.10.2.6 Check Items at Installation

Check item	Description	Check
Ethernet cable		
	Use cables which satisfies all the following conditions:	
Туре	1) With shielding	
	2) Twisted-pair cable	
	3) Category 5	
L au aith	The cable length shall be within 100 m (50 m (100BASE-TX) or 40m	
Length	(1000BASE-T) for a movable cable recommended by FANUC).	
	For a twisted-pair cable of 100BASE-TX, the following pins shall be paired:	
	1) Pin No. 1 (TX+) – pin No. 2 (TX-)	
	2) Pin No. 3 (RX+) – pin No. 6 (RX-)	
Ormertien	For a twisted-pair cable of 1000BASE-T, the following pins shall be paired:	
Connection	1) Pin No. 1 (MDI0+) – pin No. 2 (MDI0+)	
	2) Pin No. 3 (MDI1+) – pin No. 6 (MDI1+)	
	3) Pin No. 4 (MDI2+) – pin No. 5 (MDI2+)	
	4) Pin No. 7 (MDI3+) – pin No. 8 (MDI3+)	
	The Ethernet cables shall be bound separately from the following cables or	
	covered with an electromagnetic shield <sup>(Note)</sup> :	
Separation	1) Group A: AC power lines, power lines for motors, and others	
	2) Group B: Current DC (24 VDC) and others	
Oh is believe	For a shielded cable, the part of which outer coating is peeled off and exposed	
Shielding	shall be fixed to the ground plate with a clamp fixture.	
Clamping	The ground plate shall be located as nearest to the CNC as possible (to make the	
Clamping	cable between the ground plate and CNC hard to be affected by noise).	
Connectors	Any cable connector shall not be pulled (to prevent poor contact of the connector).	
Wiring	No cable shall be laid under a heavy object.	
Danding radius	The bending radius shall be at least four times as long as the diameter of the	
Bending radius	cable.	
For movable	For a movable part, a cable for a movable part shall be used.	
part		
HUB		
Use conditions	The "cautions on use" of the hub shall be observed (A terminating resistor shall be	
Use conditions	mounted properly if required).	
Grounding	The hub shall be grounded.	
Cabinet	The hub shall be installed in an enclosed cabinet.	
Vibration	The hub shall be installed so that it is not affected by vibration.	
Bending radius	The bending radius shall be at least four times as long as the diameter of the	
Denuing radius	cable.	

The following table lists check items at installation.

### NOTE

Covering a group with an electromagnetic shield means that shielding is provided between groups with grounded steel plates.

#### 4.11 CONNECTING THE SENSOR CONNECTION CABLE




Fig. 4.11 Connecting the sensor connection cable

### Sensor connection cable should be clamped to Earth plate by cable clamp.

Table4.11 Specification of cable			
Diameter	Diameter Weight Minimum be		
(mm)	(kg/m)	radius (mm)	
8.5	0.115	200	


## **5** TRANSPORTATION AND INSTALLATION

This chapter describes the transportation and installation for the controller.

## 5.1 TRANSPORTATION

The controller is transported by a crane. Attach a sling to eyebolts at the top of the controller.

Crane capacity: Minimum 300kg Sling capacity: Minimum 300kg



(A-cabinet)

(B-cabinet)



### 5.2 INSTALLATION

### 5.2.1 Installation Method

Following is the installation method for cabinet.

When installing the controller, allow the space for maintenance shown in the following figure.




Fig.5.2.1(a1) External dimensions (A-cabinet)






Fig.5.2.1(a2) External dimensions (A-cabinet with Top box)

CONNECTIONS





(87)



0

50


12


0 •

576


E


12







B-83195EN/09





#### Fig.5.2.1(c) External dimensions (Switch box)





#### Fig.5.2.1 (d) Installation dimensions (A-cabinet)





Fig.5.2.1 (e) Installation dimensions (B-cabinet)



### **5.2.2** Assemble at Installation




Fig.5.2.2 (b) Assemble at installation (B-cabinet)

## 5.3 INSTALLAT

### INSTALLATION CONDITION

ltem	Model	Specification/condition
Rated Voltage	All models	Trans. Type E:380-415, 440-500, 500-575VAC(*1) Trans. Type D:200-230, 380-400VAC 50/60Hz 3phases
		(*1) In case of NRTL controller with UL/CSA breaker (600V Rating), 500-575VAC tap can be used.
Tolerant fluctuation	All models	Tolerant voltage fluctuation: $+10\%$ -15% Tolerant frequency fluctuation: $\pm 1Hz$
Input power source	M-900iA/400L/600,M-900iB/400L/700	18kVA
capacity	M-900iA/200P, M-2000iA	30kVA(One cabinet is15kVA)
	R-1000 <i>i</i> A/120F-7B,	15kVA
	R-2000 <i>i</i> B/200T/220U/220US, R-2000 <i>i</i> C/210L/270F, M-410 <i>i</i> B, M-900 <i>i</i> A/260L/350/150P, M-410 <i>i</i> C,M-900 <i>i</i> B/280L/360	
	R-2000 <i>i</i> B (except /200T/220U/220US), R-2000 <i>i</i> C (except /210L/270F),R-1000 <i>i</i> A (except /120F-7B), M-420 <i>i</i> A,M-421 <i>i</i> A, M-710 <i>i</i> C,M-2 <i>i</i> A,M-3 <i>i</i> A	12kVA
	F-200 <i>i</i> B	5kVA
	M-430 <i>i</i> A/2PH/4FH/2P	3.5kVA
	ARC Mate 120 <i>i</i> C,M-20 <i>i</i> A, M-20 <i>i</i> B, CR-35 <i>i</i> A	3kVA
	ARC Mate 100 <i>i</i> C,M-10 <i>i</i> A	2kVA
Average power consumption	M-900 <i>i</i> A/400L/600/150P, M-900 <i>i</i> B/700/400L	5kW
	M-900iA/200P	10kW
	M-2000 <i>i</i> A	8kW
	R-1000iA/120F-7B, R-2000 <i>i</i> B/200T/220U/220US, R-2000 <i>i</i> C/210L/270F,M-410 <i>i</i> B, M-900 <i>i</i> A/260L/350,M-410 <i>i</i> C, M-900 <i>i</i> B/280/360	3kW
	R-2000 <i>i</i> B (except /200T,220U,220US), R-2000 <i>i</i> C(except /210L/270F),R-1000 <i>i</i> A (except /120F-7B), M-420 <i>i</i> A,M-421 <i>i</i> A, M-710 <i>i</i> C,M-2 <i>i</i> A,M-3 <i>i</i> A	2.5kW
	ARC Mate100 <i>i</i> C,ARC Mate 120 <i>i</i> C M-10 <i>i</i> A,M-20 <i>i</i> A,M-20 <i>i</i> B M-430 <i>i</i> A/2PH/4FH/2P,F-200 <i>i</i> B, CR-35 <i>i</i> A	1kW
Permissible ambient temperature	All models	Operating 0°C to 45°C Storage, Transport -20°C to 60°C Temperature change 0.3°C/minute or less
Permissible ambient humidity	All models	Normal: 75%RH or less, no condensation Short period(less than 1 month): 95%RH or less, no condensation
Atmosphere	All models	An additional protective provision is necessary if the machine is installed in an environment in which there are relatively large amounts of contaminants (dust, dielectric fluid, organic solvent, acid, corrosive gas, and/of salt).

Item		Model	Specification/condition
Installation category	All models		Installation categoryⅢ, Pollution degree 3, IEC60664-1 and IEC61010-1
Vibration acceleration	All models		4.9m/s <sup>2</sup> (0.5G) or less. When using the robot in a location subject to serious vibration, consult with your FANUC sales representative.
Altitude	All models		Operating:Up to 1,000m above sea level Non-operating:Up to 12,000m above sea level
lonized and non-ionized radiation	All models		A shielding provision is necessary if the machine is installed in an environment in which it is exposed to radiation (microwave, ultraviolet rays, laser beams, and/or X-rays).
Mass of controller (In case of 2 cabinet configuration, this means mass of each cabinet)	A-cabinet	All models (Except below models) R-1000 <i>i</i> A/120F-7B, R-2000 <i>i</i> B/200T/ 220U/220US, R-2000 <i>i</i> C/210L/270F, M-900 <i>i</i> A,M-900 <i>i</i> B, M-410 <i>i</i> B,M-410 <i>i</i> C	120kg 140kg
	B-cabinet	All models (Except below models) R-1000 <i>i</i> A/120F-7B, R-2000 <i>i</i> B/200T, 220U,220US, R-2000 <i>i</i> C/210L/270F, M-900 <i>i</i> A,M-900 <i>i</i> B, M-410 <i>i</i> B,M-410 <i>i</i> C	180kg 200kg
Degree of protection	A-cabinet B-cabinet Teach pendan	· · · · ·	IP54

#### NOTE

The power rating indicated above is sufficient as the continuous rating. However, when the robot is rapidly accelerating, the instantaneous requirement may increase to several times the continuous rating.

If the acceleration/deceleration override (ACC) greater than 100% is set in the robot program, the extreme current may flow to the robot controller instantaneously and the input voltage of robot controller will drop.

In this case, if the supply voltage is decreased 10% or more per rated voltage, Power supply alarm, Move error excess alarm, DCLV alarm of servo amplifier may occur.

#### NOTE

#### In case of CE controller

R-30*i*B/R-30*i*B Plus controller is a group 1, class A product according to IEC55011.

This means that this product does not generate and/or use intentionally radio-frequency energy, in the form of electromagnetic radiation, inductive and/or capacitive coupling, for the treatment of material or inspection / analysis purpose and that it is suitable for use in all establishments other than domestic and those directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

There may be potential difficulties in ensuring electromagnetic compatibility in environments other than industrial, due to conducted as well as radiated disturbances.

This product must not be used in residual areas.

This product may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

# **5.4** ADJUSTMENT AND CHECKS AT INSTALLATION

Adjust the robot according to the following procedure at installation.

No.	Description
1	Visually check the inside and outside of the controller.
2	Check the screw terminals for proper connection.
3	Check that the connectors and printed circuit boards are firmly connected.
4	Check transformer tap setting. (See Section 6.2 in MAINTENANCE)
5	The breaker off and connect the input power cable.
6	Check the input power voltage and transformer outputs.
7	Press the EMERGENCY STOP button on the operator panel and turn on the controller.
8	Check the interface signals between controller and robot mechanical unit.
9	Check the parameters. If necessary, set them.
10	Release the EMERGENCY STOP button on the operator panel. Turn on the controller.
11	Check the movement along each axis in manual jog mode.
12	Check the interface signals of end effector.
13	Check the peripheral device control interface signals.

# 5.5 RESETTING OVERTRAVEL AND EMERGENCY STOP AT INSTALLATION

An overtravel and emergency stop occur when the robot is operated for the first time after it is installed and the mechanical and controllers are wired. This section describes how to reset the overtravel and emergency stop.


Remove the red plate fastening the swiveling axis beforehand.

The J2 and J3 axes are pressed against the hard stops at shipment. Therefore, an overtravel alarm occurs when the power is turned on after installation.

The robot can also be in an emergency stop state if the peripheral device control interface is not connected.

# 5.5.1 Peripheral Device Interface Processing

Take the following actions if signals XIMSTP, XHOLD, XSFSD, and ENBL are not used.




# 5.5.2 Resetting Overtravel

- 1) Select [OT release] on the overtravel release screen to release each robot axis from the overtravel state.
- 2) Hold down the shift key, and press the alarm release button to reset the alarm condition.
- 3) Still hold down the shift key, and jog to bring all axes into the movable range.

# 5.5.3 How to Disable/Enable HBK

- 1) Press [MENU] key on the teach pendant.
- 2) Select [NEXT].
- 3) Select [SYSTEM].
- 4) Press "F1" (TYPE) on the teach pendant.
- 5) Select "Config" to disable/enable HBK.

Status	Hand Broken enable/disable setting	HBK (*1)	HBK detection	Robot operation	Message
1	Enable	CLOSE	Yes	Possible	None
2	Enable	OPEN	Yes	Impossible	SRVO-006
3	Disable	CLOSE	No (*2)	Impossible	SRVO-302
4	Disable	OPEN	No	Possible	At cold start, SRVO-300



## 5.5.4 How to Disable/Enable Pneumatic Pressure Alarm (PPABN)

- 1) Press [MENU] key on the teach pendant.
- 2) Select [NEXT].
- 3) Select [SYSTEM].
- 4) Press "F1" (TYPE) on the teach pendant.
- 5) Select "Config" to disable/enable PPABN.

# **APPENDIX**



Name	Ordering Specification	FANUC Specification	Note
Main board	A05B-2600-H001	A16B-3200-0730	Standard
		A16B-3200-0780	
	A05B-2600-H002	A16B-3200-0731	Option (Force sensor)
		A16B-3200-0781	
	A05B-2600-H003	A16B-3200-0732	Option (Force sensor)
		A16B-3200-0782	(High speed com. CPU)
	A05B-2600-H004	A16B-3200-0800	Standard For I/O Link <i>i</i> slave
	A05B-2600-H005	A16B-3200-0801	Option (Force sensor) For I/O Link <i>i</i> slave
	A05B-2600-H006	A16B-3200-0802	Option (Force sensor, High speed) For I/O Link <i>i</i> slave
	A05B-2670-H001	A16B-3200-0810	Standard
	(R-30 <i>i</i> B Plus)		For I/O Link <i>i</i> slave
	A05B-2670-H002 (R-30 <i>i</i> B Plus)	A16B-3200-0811	Option (Force sensor) For I/O Link <i>i</i> slave
	A05B-2670-H003 (R-30 <i>i</i> B Plus)	A16B-3200-0812	Option (Force sensor, High speed) For I/O Link <i>i</i> slave
CPU card	A05B-2600-H020	A20B-3300-0686	Standard / SDRAM 32Mbyte
		A17B-3301-0106	
	A05B-2600-H021	A20B-3300-0687	Standard / SDRAM 64Mbyte
		A17B-3301-0107	
	A05B-2600-H022	A20B-3300-0688	Standard / SDRAM 128Mbyte
		A17B-3301-0108	
		A20B-3300-0683	High speed / SDRAM 32Mbyte
	A05B-2600-H023	A17B-3301-0103	
		A20B-3300-0684	High speed / SDRAM 64Mbyte
	A05B-2600-H024	A17B-3301-0104	
	A05B-2600-H025	A20B-3300-0685	High speed / SDRAM 128Mbyte
	A03D-2000-11023	A17B-3301-0105	
	A05B-2600-H026	A17B-3301-0109	Standard / SDRAM 32Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H027	A17B-3301-0110	Standard / SDRAM 64Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H028	A17B-3301-0111	Standard / SDRAM 128Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H029	A17B-3301-0112	High speed / SDRAM 32Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H030	A17B-3301-0113	High speed / SDRAM 64Mbyte For I/O Link <i>i</i> slave
	A05B-2600-H031	A17B-3301-0114	High speed / SDRAM 32Mbyte For I/O Link <i>i</i> slave
	A05B-2670-H020 (R-30 <i>i</i> B Plus)	A17B-3301-0250	Standard /DRAM 1GB For I/O Link <i>i</i> slave

Name	Ordering Specification	FANUC Specification	Note
Axis control card	A05B-2600-H040	A20B-3300-0664	6-axis
		A20B-3300-0774	
	A05B-2600-H041	A20B-3300-0663	12-axis
		A20B-3300-0773	-
	A05B-2600-H042	A20B-3300-0662	18-axis
		A20B-3300-0772	
	A05B-2600-H043	A20B-3300-0661	24-axis
		A20B-3300-0771	
	A05B-2600-H044	A20B-3300-0660	36-axis
		A20B-3300-0770	
	A05B-2670-H040 (R-30 <i>i</i> B Plus)	A20B-3300-0819	6-axis
	A05B-2670-H041 (R-30 <i>i</i> B Plus)	A20B-3300-0818	12-axis
	A05B-2670-H042 (R-30 <i>i</i> B Plus)	A20B-3300-0817	18-axis
	A05B-2670-H043 (R-30 <i>i</i> B Plus)	A20B-3300-0816	24-axis
	A05B-2670-H044 (R-30 <i>i</i> B Plus)	A20B-3300-0815	36-axis
FROM/SRAM module	A05B-2600-H060	A20B-3900-0283 A20B-3900-0297	FROM 32M/ SRAM 1M
	A05B-2600-H061	A20B-3900-0284 A20B-3900-0298	FROM 32M/ SRAM 2M
	A05B-2600-H062	A20B-3900-0285 A20B-3900-0299	FROM 32M/ SRAM 3M
	A05B-2600-H063	A20B-3900-0286	FROM 64M/ SRAM 1M
	A05B-2600-H064	A20B-3900-0287	FROM 64M/ SRAM 2M
	A05B-2600-H065	A20B-3900-0288	FROM 64M/ SRAM 3M
	A05B-2600-H066	A20B-3900-0280	FROM 128M/ SRAM 1M
	A05B-2600-H067	A20B-3900-0281	FROM 128M/ SRAM 2M
	A05B-2600-H068	A20B-3900-0282	FROM 128M/ SRAM 3M
	A05B-2600-H069	A20B-3900-0293	FROM 256M/SRAM 1M
	(R-30 <i>i</i> B Plus)		
	A05B-2600-H070 (R-30 <i>i</i> B Plus)	A20B-3900-0295	FROM 256M/SRAM 2M
	A05B-2600-H071 (R-30 <i>i</i> B Plus)	A20B-3900-0296	FROM 256M/SRAM 3M
Battery	A02B-0200-K102	A98L-0031-0012	For memory backup
Backplane	A05B-2600-H080	A20B-2004-0980	2 slot
-addpiano	A05B-2600-H081	A20B-2004-0990	4 slot
Power supply unit	A05B-2600-H100	A16B-2203-0910	
Fixing plate for CF card	A05B-2500-J300		With adapter for CF card
Emergency stop board		A20B-2200-0650	For A-cabinet
		A20B-2102-0050	For B-cabinet
16-pole terminal block		A63L-0002-0154#116	(TBOP14:A-cabinet) (TBOP10:B-cabinet) Manufacturer's specification
			(WAGO):734-116
14-pole terminal block		A63L-0002-0154#114	(TBOP11:B-cabinet) Manufacturer's specification
			(WAGO):734-114

Name	Ordering Specification	FANUC Specification	Note
12-pole terminal block		A63L-0002-0154#112	(TBOP13:A-cabinet) Manufacturer's specification (WAGO):734-112
Jumper pin		A63L-0002-0154#402F	Manufacturer's specification (WAGO):734-402F
Operation lever		A63L-0002-0154#230-M	2 pieces of 734-230 and operation manual are included in FANUC's specification Manufacturer's specification (WAGO):734-230
CRMA96 connector Rece-housing		A63L-0001-0812#R06DX	NTED, B-cabinet Manufacturer's specification (TE connectivity): 1-1318119-3
CRMA96 connector Rece-contact (AWG18-22)		A63L-0001-0812#CRM	NTED, B-cabinet Manufacturer's specification (TE connectivity): 1318107-1
Process I/O board JA	A05B-2600-J001	A16B-2204-0010	DI/DO=96/96(Source type)
Process I/O board JB	A05B-2600-J002	A16B-2204-0011	DI/DO=40/40(Source type)
I/O Link cable	A05B-2603-J170		Between main board and process I/O
(Process I/O JA, JB)	A05B-2603-J171		Between process I/O and process I/O
Peripheral device	A05B-2603-J200		Connected length: 10m (one)
connection cable	A05B-2603-J201		Connected length: 20m (one)
(Process I/O JA, JB)	A05B-2603-J202		Connected length: 30m (one)
Peripheral device	A05B-2603-J203		Connected length: 10m (one)
connection cable	A05B-2603-J204		Connected length: 20m (one)
(Process I/O JA)	A05B-2603-J205		Connected length: 30m (one)
Process I/O board MA	A05B-2600-J020	A20B-2004-0380	DI/DO=20/16(Source type)
	A05B-2600-J022	A20B-2004-0381	
Process I/O board MB	A05B-2600-J021	A20B-2101-0730	WI/WO=5/4(Sink type), D/A=2
	A05B-2600-J023	A20B-2101-0731	
I/O Link cable (Process I/O MA)	A05B-2601-J172		Between main board and process I/O
	A05B-2601-J240		Connection length 10m (one): CRMA52
Peripheral device cable (Process I/O MA)	A05B-2601-J241		Connection length 20m (one): CRMA52
	A05B-2601-J242		Connection length 30m (one): CRMA52
I/O Link cable (Process I/O MB)	A05B-2601-J174		Between main board and process I/O
Welding machine	A05B-2601-J246		Connection length 3m (one): CRW11
connection cable (FANUC I/F/elbow type)	A05B-2601-J247		Connection length 7m (one): CRW11
(Process I/O MB)	A05B-2601-J248		Connection length 14m (one): CRW11
Welding machine	A05B-2601-J250		Connection length 3m (one): CRW11
connection cable (FANUC I/F/straight	A05B-2601-J251		Connection length 7m (one): CRW11
type)	A05B-2601-J252		Connection length 14m (one): CRW11
Process I/O board KA	A05B-2600-J010	A20B-2101-0560	DI/DO=40/40(Source type), D/A=3, A/D=2

B-83195EN/09

Name	Ordering Specification	FANUC Specification	Note
Process I/O board KB	A05B-2600-J011	A20B-2101-0561	DI/DO=40/40(Source type), D/A=2
I/O Link cable	A05B-2601-J180		Between main board and process I/O
Process I/O power			
supply cable			
Peripheral device cable	A05B-2601-J230		Connected length: 10m (one)
(Process I/O KA,KB)	A05B-2601-J231		Connected length: 20m (one)
	A05B-2601-J232		Connected length: 30m (one)
Welding machine connection cable	A05B-2601-J235		Connection length 3m (one): CRW10
(FANUC I/F/elbow type) (Process I/O KB)	A05B-2601-J236		Connection length 7m (one): CRW10
(FICESS I/O KB)	A05B-2601-J237		Connection length 14m (one):
			CRW10
I/O Unit-MODEL A	A05B-2601-J130		A-cabinet (five slots)
(Base and interface unit)			A03B-0819-C003: Base unit
			A03B-0819-C011: Interface unit
	A05B-2603-J130		B-cabinet (five slots)
			A03B-0819-C002: Base unit
0 :			A03B-0819-C011: Interface unit
6-axis servo amplifier	A05B-2601-H050	A06B-6400-H101	A-cabinet
	A05B-2603-H050		B-cabinet
	A05B-2601-H051	A06B-6400-H102	A-cabinet
	A05B-2603-H051		B-cabinet
	A05B-2601-H052	A06B-6400-H002	A-cabinet
	A05B-2603-H052		B-cabinet
	A05B-2601-H053	A06B-6400-H003	A-cabinet
	A05B-2603-H053		B-cabinet
6-axis servo amplifier	A05B-2601-H054	A06B-6400-H004	A-cabinet
	A05B-2603-H054		B-cabinet
	A05B-2601-H055	A06B-6400-H005	A-cabinet
	A05B-2603-H055		B-cabinet
Servo amplifier	A05B-2605-J040	A06B-6240-H105	
	#H105		
	A05B-2605-J040	A06B-6240-H106	
	#H106		
	A05B-2605-J040	A06B-6240-H201	
	#H201		
	A05B-2605-J040 #H209	A06B-6240-H209	
	A05B-2605-J040 #H301	A06B-6240-H301	
CRR65A/B connector		A63L-0001-0460#032KSX	Auxiliary Axis Brake
Rece-housing			Manufacturer's specification
-			(TE connectivity): 1-178128-3
CRR65A/B connector		A63L-0001-0456#ASL	Auxiliary Axis Brake
Rece-contact			Manufacturer's specification
(AWG16-20)			(TE connectivity): 175218-2
CRM68 connector		A63L-0001-0812#R03SX	Auxiliary Axis Over Travel
Rece-housing			Manufacturer's specification
			(TE connectivity): 1-1318120-3
CRM68 connector		A63L-0001-0812#CRM	Auxiliary Axis Over Travel
Rece-contact			Manufacturer's specification
(AWG18-22)			(TE connectivity): 1318107-1

Name	Ordering Specification	FANUC Specification	Note
Discharge resistor	A05B-2601-C100		A-cabinet
	A05B-2601-C102		A-cabinet
	A05B-2603-C100		B-cabinet
Regenerative resistor	A05B-2601-C101		A-cabinet
	A05B-2603-C101		B-cabinet
αiPS	A06B-6200-H015		Power supply regeneration
	A06B-6200-H037		
Transformer	A05B-2601-H350	A80L-0024-0028	A/B-cabinet, 3kVA, TYPE E
	A05B-2603-H350		
	A05B-2601-H354	A80L-0024-0029	A/B- cabinet, 3kVA, TYPE D
	A05B-2603-H354		
	A05B-2601-H351	A80L-0026-0040#A	A- cabinet, 7.5kVA, TYPE E
	A05B-2601-H355	A80L-0026-0041#A	A- cabinet, 7.5kVA, TYPE D
	A05B-2601-H352	A80L-0028-0024#A	A- cabinet,10.5kVA, TYPE E
	A05B-2601-H356	A80L-0028-0027#A	A- cabinet,10.5kVA,TYPE D
	A05B-2603-H351	A80L-0026-0040	B- cabinet, 7.5kVA, TYPE E
	A05B-2603-H355	A80L-0026-0041	B- cabinet, 7.5kVA, TYPE D
	A05B-2603-H352	A80L-0028-0024	B- cabinet,10.5kVA, TYPE E
	A05B-2603-H356	A80L-0028-0027	B- cabinet,10.5kVA,TYPE D
	A05B-2603-H353	A80L-0028-0025	B- cabinet,13.0kVA, TYPE E
	A05B-2603-H357	A80L-0028-0028	B- cabinet,13.0kVA,TYPE D
Brake release unit connection cable		A660-2005-T559	R-2000 <i>i</i> B,R-2000 <i>i</i> C, R-1000 <i>i</i> A,M-2 <i>i</i> A,M-3 <i>i</i> A M-710 <i>i</i> C,M-410 <i>i</i> B,M-420 <i>i</i> A,M-421 <i>i</i> A, M-410 <i>i</i> C M-900 <i>i</i> A, M-900 <i>i</i> B,M-2000 <i>i</i> A
		A660-2005-T871	F-200 <i>i</i> B
		A660-2006-T881	M-10iA,M-20iA, ARC Mate 100iC,ARC Mate 120iC CR-35iA
		A660-2006-T888	M-430 <i>i</i> A/2PH,4FH
		A660-2006-T887	M-430 <i>i</i> A/2P
		A660-2005-T711	Aux. Axis
		A660-2006-T803	M-410 <i>i</i> B, M-410 <i>i</i> C
Sensor I/F unit	A05B-2600-C320		CR-35iA

#### B. TOTAL CONNECTION DIAGRAM APPENDIX

B

# TOTAL CONNECTION DIAGRAM




Fig.B (a) System block diagram (A-cabinet / Resistor discharge)




Fig.B (b) System block diagram (A-cabinet / Power supply regeneration)

B-83195EN/09






Fig.B (c) System block diagram (B-cabinet / Resistor discharge)





B. TOTAL CONNECTION DIAGRAM APPENDIX

B-83195EN/09

Fig.B (e) AC power line connection diagram (in case of TYPE E transformer)





Fig.B (f) AC power line connection diagram (in case of TYPE D transformer or line filter)

#### APPENDIX B. TOTAL CONNECTION DIAGRAM



124E +24V

٨٥

A2:PSU

A1: BA<u>CKPLANE</u>

R-30iB DC POWER CIRCUIT for A-cabinet

٥

Fig.B (g) DC power line connection diagram (R-30iB A-cabinet)

RS-232-C/RS-485 FORCE SENSOR

CRS35

-INTERNAL -CIRCUIT (ENABLE)

pc/pc

Vision JA/JB Р<

JRL 7

415-1: PROCESS 1/0

AI5:0PTION BOARD FUSE1 2A DC/DC

DC/DC

RS-232-C 1/0 LINK

JRS16

A3:MAIN BOARD

JD1 - 07




Fig.B (h) DC power line connection diagram (R-30iB Plus A-cabinet)




Fig.B (i) DC power line connection diagram (R-30iB B-cabinet)




Fig.B (j) DC power line connection diagram (R-30iB Plus B-cabinet)

E-STOP CIRCUIT FOR A-CABINET RESISTOR DISCHARGE







Fig.B (k) Emergency stop circuit connection diagram (A-cabinet/Resistor discharge)





#### Fig.B (I) Emergency stop circuit connection diagram (A-cabinet/Power supply regeneration)







Fig.B (m) Emergency stop circuit connection diagram (B-cabinet/Resistor discharge)



B-83195EN/09






Fig.B (n) Emergency stop circuit connection diagram (B-cabinet/Power supply regeneration)





	AUX24	AUX23	AUX14	AUX13	MONKM 1	MONKM2	MCCZON	MONKA
<u>u</u> ) –	В1	В2	вз	Β4	B5	BG	В7	B8
CNMC D2100D	AUX24	AUX23	AUX14	AUX13	+24E	0 ۷	MCC1 ON	٥٧
	A 1	A2	AЗ	A4	A5	A6	Α7	A8

۲)	۷۵	ΗM1	AUTO2B	MODE2B	0PESP11	OPESP21	PD11 (FAULT RESET)	PDI2 (CYCLE START)	wS	XBRKON	BRKDLY	MON 1	KMZON		TPESP21	<b>TPESP2</b>	TPESP11	TPESP1	٥٧	٥٧	TXN_TP	TXP_TP	RXN_TP	RXP_TP
T27 0D (\	81	B2	BЗ	B4	B5	B6	в7	B8	0~	81	B2	BЗ	Β4	RS36 00D (	В1	B2	В3	Β4	B5	B6	87	B8	89	B10
CR1 D2100	+24E	+24E	AUT01B	MODE 1 B	OPESP1	OPESP2	PDO1 (BUSY)	PDO2 (FAULT)	CRMA: D2100D	MON2	XSVEMG	XMCCON	XPCON	CF D210	+24T	+24T	TPEN2	TPEN1	TPDSC	0 V	XTXTP	<u> </u>	XRXTP	RXTP
	A 1	A2	¥З	A4	A5	A6	A7	AB		A 1	A2	AЗ	A4		A 1	A2	AЗ	A4	A5	A6	A7	A8	<b>A9</b>	A 1 0

	Г																			
OP 1 3 RM I NAL	EES1	EES11	EES2	EES21	EAS1	EAS11	EAS2	EAS21	EGS1	EGS11	EGS2	EGS21	OP 14 RM INAL	AUX13	AUX14	AUX23	AUX24	DM 1	DM2	
TE TE	١	N	в	4	ß	9	7	8	۶	10	11	12	ЩШ	-	2	e	4	ß	ဖ	

											Г		Γ		Γ	
OP 1 4 RM I NAL	AUX13	AUX14	85XUA	AUX24	1 MQ	ZMD	ESPB1	ESPB11	ESPB2	ESPB21	EXOFF1	EXOFF11	EXT24V	1 N T 2 4 V	INTOV	EXTOV
85	-	2	e	4	5	ω	7	8	ი	10	11	12	13	14	15	16

e (X)	٥٧	OPD01	OPDO2	0PD03	0PD04	OFF11	(X)	SVON11	SVON21	FANOFF	e (X)	٥٧	٥٧	٥٧	.8	٥٧	٥٧
DD DD	18	B2	вз	Β4	B5	B6		8	В2	BЗ	6640 00	81	В2	вз	P34	81	B2
CRM D1201	372+	OPD I 1	21040	0PD13	0PD I 4	OFF 1	CRMAS D2100D	SVON1	SVON2	0PD I 5	CRP33 D2100D ()	+24E	+24E	124V	CRP34 D1200D ()	424E	+24E
	A 1	АZ	AЗ	A4	A5	A6		۲.	Α2	АЗ		A 1	A2	ЪЗ		A 1	A2

Emergency Stop Board Connector Table For A-cabinet

	RXP_TP	RXN_TP	TXP_TP	TXN_TP	сом	٥٧	RXS I LD2	XRXS1LD2	TXSILD2	XTXS1LD2
JRS20 PCR20	11	12	13	14	15	16	17	18	19	20
л РС	RXTP	XRXTP	TXTP	XTXTP	NO	0FF	RXSILD1	XRXSILD1	TXSILD1	XTXSILD1
	1	N	Э	4	S	9	7	8	6	10

3	٥٧	0٧	SFD121	SFD122	SFD021	SFD022	
(U	Ē	Bг	ВЗ	B4	B5	B6	
CRMB D1200D	+24E	+24E	SFD111	SFD112	SFD011	SFD012	
	A 1	A2	AЗ	A4	A5	A6	





Fig.B (o) Emergency stop board connector table (A-cabinet)

CP D3200 200A 200B	A3 200FAN B3 200FAN CNMC6	D3200S (Y)	2 200S 3 200T		5 AC2 6 AC3		CNMC7 D3200S (X)	$\vdash$	2 COLL2 3 COLL2	-	CRRA12	D32005 (Z)	PCM1	+				CRS36	D2100D (	+24T B1	A2 +241 B2 1P5P2 A3 TD5M3 D3 TD5C011	TPEN1 B4	TPDSC B5	٥٧	XTXTP B7	AB TXTP BB TXP_TP					
RT27 00D (Y) B1	A2 24E-2 B2 HMI A3 AUTO1B B3 AUTO2B	3 B4	B5	2 B6 0	A7 PD01 B7 FAULT RESET)	AB PD02 BB CYCLE START)		RMA92	AI MONZ BI XBRKON	а В Э	A4 XPCON B4 KM2ON		CONNECTOR ON THE SAFETY 1/O BOARD	CRMA90 D10000 (X)	A1 +24E B1 0V	SFD111 B2	A3 SFDI12 B3 SFD122 A4 SED113 B4 SED123	SFD114 B5	B6	B7	SFD117 B8	A9 5F0118 B9 5F0128 A10 A10	SFD011	SFD012 B12	B13	SFD014 B14	SFD015 B15	AI6 SFD016 B16 SFD026 A17 SFD017 B17 SFD027	SFD018 B18	0V B19	A20 0V B20 0V
TBOP11 TERMINAL Z EES11	3 EES2 4 EES21 5 EAS1		8 EAS21		11 EGS2 1 12 EGS21	13 EXOFF1		TBOP10 TERMINAL	1 AUX13	2 AUX14 3 AUX23	4 AUX24		6 AUX12 7 AUX21			10 ESPB11	_				_										
с р с	CRMA74 D2100D (Y)	AI MONKAI BI BRKDLY A2 SVONII B2 SVONI	SVON21 B3	24E-2 B4 0V B5	A6 FANOFF B6 MONKA		A1 +24E B1 0V	A2 0PD11 B2 0PD01 A3 0PD12 B3 0PD02	OPD13 B4	A5 0PD14 B5 0PD04 A6 0FF1 B6 0FF11			CRMA83	D1 2 UUU (Y)	0PD15	0PD16 B3	A4 0PUL/ B4 0PUL/2 A5 0PD18 B5 0PD113	OPD19 B6		CNMC3 D2100D (X)	AI KA3I BI KA32	KA41	0 0 83	84	AD AUXII BO AUXIZ	AUX24 B7	AUX23 B8	AUX14 B9	AIO AUXI3 BIO AUXI3		
Emergency Stop Bo Connector Table For B-cabinet	JDIA PCR20	I RXSILD2 II OV 2 XRXSILD2 I2 OV	TXSILD2	15	6 16 0V		9 +5V 19 10 20 +5V	ELSAI.	PCR20	1 RXTP 11 RXP_TP	TXTP 13	XTXTP 14	0N 15	6 0FF 16 0V 7 RXSILD1 17	XRXSILD1	TXSILD1	10 XTXSILD1 20		D3500D	+24E B1 0V	+24E B2	A3 +24E B3 0V	+24E B5 0V	+24V B6			CRMA96		NTEDI	AZ NIEUZ BZ NIEUZI A3 DMI B3 DM2	
			Fig	з.В	(p)	Eme	erge	ency	/ st	ор	bo	ard	l co	onn	ect	or	tab	le	(B-	са	bir	let)	)								

B-83195EN/09

# APPENDIX B. TOTAL CONNECTION DIAGRAM

#### **B. TOTAL CONNECTION DIAGRAM** APPENDIX



3ase-TX Network)								
D38C 100E	TPTXC+	TPTXC-	TPRXC+	NCC 1	NCC 1	TPRXC-	NCCZ	NCC2
CD: net Board	-	S	m	Δ	ß	9	7	8
C Ethernet (Main Boar								

lase-TX Network)									
38B 100E	TPTXB+	TPTXB-	TPRXB+	NCB1	NCB 1	TPRXB-	NCB2	NCB2	
CD rnet Board	-	ŝ	m	4	ß	9	7	8	
Ethernei (Main Boa									

Во	or Table	
ш	c t	
30 i	nne	
ЧЧ Ч	ĉ	

3ase-TX Network)							
100E 100E rd -	TPTXA+	TPTXA-	TPRXA+	NCA1	NCA 1	TPRXA-	NCA2
cD: net Board	-	2	e	4	പ	9	7
Ethernet (Main Boa							

JRS16 RS232-C∕USB (Main Board - Panel)

TXDA

Ξ

RXDA

ŝ ო ഹ ~ æ თ

2

12 13 14 15 16 17 18 19 20

2

DTRA RTSA

DSRA

NCA2 NCA2

ω

USB\_P USB\_M

USB\_5V

USB\_0V

20 ٥٧

CTSA

2 20

4 ശ +24E

+24E


10


RL7 interface nterface)	CAMDO2	٨٥	COMMDO3	٥٧	CAMD 1	CAMDIZ	CAMD 10	CAMDOD	P12V
L7 nte iter	:	12	13	14	15	16	17	18	19
JRL Sensor in (Video Ini	ΔVΧ	0٧	днх	0٧	XTRIG	0٧	VIDEOIN	0٧	
SO	-	S	ю	4	ß	9	7	8	ი


20 CAMDO1

20

10







JRL8 HDI 170 Link (Ma

e .										
/O Device)	0 I GHX	0٧	XHD I 1	0٧	хнр 1 2	0٧	XHD I 3	0 ۷	XHD I 4	٥٧
	:	12	13	14	15	16	17	18	19	20
Board -	RXSLCB	0٧	XRXSLCB	0٧	TXSLCB	RXSLCC	XTXSLCB	XRXSLCC	TXSLCC	XTXSLCC
	-	2	Э	4	5	9	7	8	6	10

Fig.B (q) Main board connector table (R-30iB)

#### APPENDIX B. TOTAL CONNECTION DIAGRAM

2

20

XTXSLCC

0 -




Fig.B (r) Main board connector table (R-30iB Plus)

Emergency Stop Board diagram




Fig.B (s) Operator's panel connection diagram

#### APPENDIX B. TOTAL CONNECTION DIAGRAM




Fig.B (t) Operator's panel/Teach pendant connector table




Fig.B (u) Servo amplifier connector table








Fig.B (v) Motor power connection (Group1, Group11) Group1: R-2000*i*B(except /200T/220U/220US), R-2000*i*C(except /210L/270F), R-1000*i*A(except /120iF-7B), M-710*i*C,M-420*i*A,M-421*i*A Group11: M-2*i*A,M-3*i*A

Motor Brake ا م ۹ م ą ε'n 4 ROBOT 5 BK1 BK4 R N N BK6 ž RM 1 CRR88 ROBOT CONNECTION CABLE Motor Brake Connection Interface (B2) (A2) (¥3) (A1) 6-Axis Servo Amplifier (63) (18) BK4\_5\_6-BK1\_2 BKC BKC BКЗ BKC J2 J3 J4 J5 Motor Brakes Servo Motors Robot ٩ εŋ ß ٩ſ ٩d 5 R Ę Ē ЧB (P) (F 5 CNJ5 CRR86 CNGC CNJ1A CNGA 6-Axis Servo <u>Amplifie</u>r













Fig.B (y) Motor power connection (Group4) M-900*i*A/150P,260L,350



#### APPENDIX B. TOTAL CONNECTION DIAGRAM




Fig.B (aa) Motor Power Connection (group6-1) M-430*i*A/4FH




Fig.B (ab) Motor Power Connection (group6-2) M-430*i*A/2PH






Fig.B (ac) Motor Power Connection (Group 7) M-430*i*A/2P










Fig.B (ae) Motor Power Connection (Group 12) R-1000iA/120F-7B








Fig.B (ag) RI/RO Connection Diagram (Group6; M-430iA/2PH,4FH)




Fig.B (ah) RI/RO Connection Diagram (Group7; M-430*i*A/2P)





Fig.B (ai) RI/RO Connection Diagram (Group8; ARC Mate 100*i*C, ARC Mate 120*i*C)

There are many type EE connector of mechanical unit. The detail is shown on the mechanical unit manual.



#### Fig.B (aj) RI/RO Connection Diagram (Group11; M-2iA,M-3iA)




Fig.B (ak) Pulsecoder signal connection diagram (Group1 to 4, 11)

#### APPENDIX B. TOTAL CONNECTION DIAGRAM




Fig.B (al) Pulsecoder Signal Connection Diagram (Group5; M-900*i*A/400L,600,M-900*i*B/400L,700)

B-83195EN/09




Fig.B (am) Pulsecoder Signal Connection Diagram (group6; excluding M-430*i*A/2PH)

#### APPENDIX B. TOTAL CONNECTION DIAGRAM




Fig.B (an) Pulsecoder Signal Connection Diagram (group6; M-430*i*A/2PH)




Fig.B (ao) Pulsecoder Signal Connection Diagram (Group7; M-430iA/2P)

#### APPENDIX B. TOTAL CONNECTION DIAGRAM






Fig.B (ap) Pulsecoder Signal Connection Diagram (Group8; ARC Mate 100*i*C, ARC Mate 120*i*C)



B-83195EN/09

Fig.B (aq) Pulsecoder Signal Connection Diagram (Group12; R-1000iA/120F-7B)

	R 1 6	24VF-3	RO6	52 - 211 - 2	0V-7 0V-8	PR0J6 XPR0J6			1161	1561	1361	J5G	J6G	1261									
	36	37	38	39		41 × 41			36	37	38 39	40	41	42							Ì		
õ	R15	хгот	R05	52+ 511 5	04-5 04-6	PR0J5 XPR0J5			1 M I C	INSU	1 MCL	J5W	JGW	J2W1							İ		up2
& RI/RO	29	30	31			34 F 35 X		e)			- 6 - 6	33	34	35									Б С
	R14	хнвк		0V-1 0V-2		PR0J4 XPR0J4		& Brake)			1/10		JGV	12V1									Mechanical Unit Interface Group2 F-200 <i>i</i> B
ck Si	22	23				27 F 28 X	μ	Ner			24	26	27	28							İ		Jnit Inter F-200 <i>i</i> B
RP1 eedback	R13	R 19		24VF - 1 24VF - 2 21. 5		PR0J3 XPR0J3		(MOTOR Power			100		JGU	1201							Ì		Unit F-2(
der F	15	16	17			20 P		θ			17		20	21									ical
RP1 Pulsecoder Feedback Signal	R12 1	R18			-	PRQU2 2				+	BKC		BKC										chan
β	8	6	- -			13 PF					2 -		13	14							İ		Me
	R11 8	R17 9				PR0J1 1 XPR0J1 1					BRK3P 1 BRKAP 1		BRK6P 1	-							Ì		
	Я	2 R	е м		_	7 XPF				-	3 BR	_	6 BRI	7									
		VF-3	106	2-		toje la la la la la la la la la la la la la	 													 			C, 21 <i>i</i> A
	36 RI6	37 24VF-3			_	41 PRQJ6 42 XPRQJ6 42 XPRQJ6														 			000iC, 1 M421iA
	36	37	38	6E	40	41				1161	.261	1261	1361	1361		90	344		346	 			up1 R-2000 <i>i</i> C, гола М421iA
R1/R0)	R15 36	XR0T 37	R05 38	S2+ 39	0V-5 40	PRQJ5 41 XPRQJ5 42					36 J161		39 J3G1	1		43 J6G							Group1 US),R-2000;C, M-420iA M421;A
al & R1/R0)	29 R15 36	30 XROT 37	31 R05 38	32 S2+ 39	33 0V-5 40	34 PRQJ5 41 35 XPRQJ5 42		Brake)	34	32	36	38	66	40	41	46	44	j f	46				ace Group1 ,220US),R-2000 <i>i</i> C, 10 <i>i</i> C M-420 <i>i</i> a M431 iA
Signal	R14 29 R15 36	хнвк 30 хкот 37	R04 31 R05 38	0V-1 32 S2+ 39	0V-4 33 0V-5 40	PR0J4 34 PR0J5 41 XPR0J4 35 XPR0J5 42	Ξ	rer & Brake)	J1W1 34	J1W1 35	J2W1 36	J2W1 38	13W1 39	J3W1 40	41 41	.I5w 43	44	J6W 75	BK3 46				nterface Group1 20U,220US),R-2000 <i>i</i> C, M-710 <i>i</i> C M-420/iA M421 <i>i</i> A
Signal	22 R14 29 R15 36	23 XHBK 30 XROT 37	24 R04 31 R05 38	25 0V-1 32 S2+ 39	26 0v-3 33 0v-5 40	27 PR0J4 34 PR0J5 41 28 XPR0J4 35 XPR0J5 42		øð	24 J1W1 34	25 J1W1 35	26 J2W1 37	27 J2W1 38	28 J3W1 39	29 J3W1 40	30 JAW 41	31 J5w 43	44	32 J6W 75	33 BK3 46				ווו Interface Group1 0T,220U,220US),R-2000 <i>i</i> C, דאו M-210 <i>i</i> C M-420iA M421 <i>i</i> A
RP1 Feedback Signal	RI3 22 RI4 29 RI5 36	R19 23 XHBK 30 XR0T 37	R03 24 R04 31 R05 38	24VF-2 25 0V-2 32 S2+ 39	5v-5 26 0v-3 33 0v-5 40 5v-e 26 0v-4 33 0v-6 40	PR0J3 27 PR0J4 34 PR0J5 41 XPR0J3 28 XPR0J4 35 XPR0J5 42		æ	J1V1 24 J1W1 34	J1V1 25 J1W1 35	J2V1 26 J2W1 37	J2V1 27 J2W1 38	J3V1 28 J3W1 39	J3V1 29 J3W1 40	14V 30 14W 41	.15v 31 .15w 43		J6V 32 J6W 75	BK2 33 BK3 46				cal Unit Interface Group1 0/2007,220U,220US),R-2000 <i>i</i> C, 20F-7B) M-710 <i>i</i> C M-420 <i>i</i> A M421 <i>i</i> A
RP1 Feedback Signal	15 RI3 22 RI4 29 RI5 36	16 R19 23 XHBK 30 XR0T 37	17 R03 24 R04 31 R05 38	18 24VF-1 25 0V-1 32 S2+ 39	19 5v-5 26 0v-3 33 0v-6 40	20 PR0J3 27 PR0J4 34 PR0J5 41 21 XPR0J3 28 XPR0J4 35 XPR0J5 42		øð	14 J1V1 24 J1W1 34	15 J1V1 25 J1W1 35	16 J2V1 26 J2W1 37	17 J2V1 27 J2W1 38	18 J3V1 28 J3W1 39	19 J3V1 29 J3W1 40	20 14V 30 14W 41	21 J5V 31 J5W 43			23 BK2 33 BK3 26				anical Unit Interface Group1 ccept/200T,220U,220US),R-2000 <i>i</i> C, +/120F-7R) M-710 <i>i</i> C M-420 <i>i</i> A M421 <i>i</i> A
Signal	RI2 15 RI3 22 RI4 29 RI5 36	RIB 16 RI9 23 XHBK 30 XROT 37	R02 17 R03 24 R04 31 R05 38	RO8 18 24VF-1 25 0V-1 32 S2+ 39	5v-3 19 5v-5 26 0v-3 33 0v-5 40 5v-4 5v-6 26 0v-4 33 0v-6 40	PRQJ2         20         PRQJ3         27         PRQJ4         34         PRQJ5         41           XPRQJ2         21         XPRQJ3         28         XPRQJ4         35         XPRQJ5         42		øð	14 J1V1 24 J1W1 34	1101 15 J1V1 25 J1W1 35	1011 16 J2V1 26 J2W1 37	J2U1 17 J2V1 27 J2W1 38	J3U1 18 J3V1 28 J3W1 39	1301 19 J3V1 29 J3W1 40	140 000 140 000 140 41	J6U 21 J5V 31 J5W 43			BKC 23 BK2 33 BK3 46				Mechanical Unit Interface Group1 iB (except/200T,220U,220US),R-2000iC, excent /120E-7B) M-710iC M-420iA M421iA
RP1 Feedback Signal	15 RI3 22 RI4 29 RI5 36	16 R19 23 XHBK 30 XR0T 37	10 R02 17 R03 24 R04 31 R05 38	11 R08 18 24VF-1 25 0V-1 32 S2+ 39	12 5v-3 19 5v-5 26 0v-3 33 0v-5 40	20 PR0J3 27 PR0J4 34 PR0J5 41 21 XPR0J3 28 XPR0J4 35 XPR0J5 42	Σ	øð	14 J1V1 24 J1W1 34	1101 15 J1V1 25 J1W1 35	16 J2V1 26 J2W1 37	17 J2V1 27 J2W1 38	18 J3V1 28 J3W1 39	1301 19 J3V1 29 J3W1 40	20 14V 30 14W 41	Jeu 21 J5v 31 J5w 43			BKC 23 BK2 33 BK3 46				Mechanical Unit Interface Group1 R-2000iB (except/200T,220U,220US),R-2000iC, R-1000iA(excent /120F.7R) M-710iC M-420iA M421iA



I       RII       I       RI       I       RI       I       RI       I       I       I       RI       I       I       RI       I       I       I       I       RI       I       I       RI       I       I       I       I       I       I       I       RI       I       I       RI       I <t< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th> </th><th><math>\square</math></th><th>102</th><th>J162</th><th>J262</th><th>J3G2</th><th>1362   1462  </th><th>J5G2</th><th>J6G2</th><th>-</th><th></th><th></th></t<>										 	$\square$	102	J162	J262	J3G2	1362   1462	J5G2	J6G2	-		
Group A RII & RIZ RI RII & RIZ RIZ RIZ RIZ RIZ RIZ RIZ RIZ RIZ RIZ			-		RO6	- 2 S	0V-7 0V-8	PRQJ6	хрголб	5	W2 34	5	96	38	66		42	43		42	76
Group4 RP1 RP1 (Pulsecoder Feedback Signal & RI/ R11 8 R12 15 R13 22 R14 29 R01 10 R02 17 R03 24 R04 31 R07 11 R08 18 24V-1 32 5V-2 12 5V-3 19 5V-5 0V-3 33 5V-2 12 5V-3 19 5V-5 0V-3 33 5V-2 12 5V-3 19 5V-5 0V-3 33 FR0J1 13 PR0J2 20 PR0J3 27 PR0J4 35 X PR0J1 14 XPR0J2 21 XPR0J3 28 XPR0J4 35 X PR0J1 14 XPR0J2 21 XPR0J3 28 XPR0J4 35 X MOTOR Power & Brak 11 JU1 22V1 25 JJW1 35 J1G1 2 JJU2 15 1 JJU1 15 JJV1 22 JJW1 35 J1G1 2 JJU2 15 1 JJU1 15 JJV1 28 JJW1 33 J1G1 2 JJU2 15 1 JJU1 17 J2V1 27 J2W1 33 J2G1 2 JJU2 15 1 JJU1 17 J2V1 27 J2W1 33 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 17 J2V1 27 J2W1 33 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 17 J2V1 27 J2W1 33 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JJU2 15 1 JJU1 19 J3V1 29 J3W1 41 J2G1 2 JU2 2 1 JJU1 17 J2V1 27 J2W1 31 J5G1 2 JU2 2 1 JJU1 17 J2V1 27 J2W1 31 J5G1 2 JU2 2 1 JJU1 17 J2V1 27 J2W1 31 J5G1 2 JU2 2 1 JJU1 18 J3V1 28 J3W1 41 J2G1 2 JU2 2 1 JJU1 17 J2V1 27 J2W1 31 J5G1 2 JU2 2 1 JJU1 17 J2V1 27 J2W1 31 J5G1 2 JU2 2 1 JJU1 17 J2V1 27 J2W1 31 J5G1 2 JU2 2 1 JJU1 20 J4V1 30 J4W1 42 J5G1 2 JU2 2 1 J5W1 41 30 J4W1 42 J5G1 2 JU2 2 1 J5W1 41 30 J4W1 42 J5G1 2 JU2 2 1 J5W1 41 30 J4W1 42 J5G1 2 JU2 2 1 J5W1 2 J5W1 31 J5W1 41 3 J5G1 2 JU2 2 1 J5W1 2 J5W1 31 J5W1 41 3 J5G1 2 JU2 2 1 J5W1 2 J5W1 31 J5W1 41 3 J5G1 2 JU2 2 1 J5W1 2 J5W1 31 J5W1 41 3 J5G1 2 JU2 2 1 JU2 2 1 JU2 2 JU2 2 1 JU2 2 JU2 2 1 JU2 2 JU			36	37	38	39	40	41	42	20 % G	5	1						J5		_	_
Group 4 RPI RPI RPI RPI RPI RPI RPI RPI	 	/RO)	RIS	XROT	ROS	+2S	0V-5 0V-6	PRGJ5	XPRQJ5	RM. MOTOR										ee e	_
Group 4 RII 8 RI2 15 RI3 22 RI4 RIT 9 RI8 16 R19 23 XHBK R01 10 R02 17 R03 24 R04 R01 11 R08 18 24V-2 25 0V-2 5V-2 12 5V-3 19 5V-5 0V-3 5V-2 12 5V-3 19 5V-5 0V-3 5V-1 12 8V-4 19 31 9 5V-5 0V-3 7 PR0J1 13 PR0J2 21 XPR0J3 28 XPR0J4 PR0J1 13 PR0J2 21 XPR0J3 28 XPR0J4 11 J1V1 22 101 13 1 201 J1U1 15 J1V1 22 J1K1 35 J1G1 J2U1 17 J2V1 27 J2W1 35 J1G1 J2U1 17 J2V1 28 J1W1 35 J1G1 J2U1 18 J3V1 28 J3W1 41 J4G1 J3U1 19 J3V1 28 J3W1 33 J2G1 J3U1 19 J3V1 28 J3W1 31 J2G1 J3U1 19 J3V1 28 J3W1 31 J2G1 J3U1 19 J3V1 28 J3W1 31 J2G1 J3U1 19 J3V1 28 J3W1 31 J2G1 J3U1 19 J3V1 28 J3W1 31 J2G1 J3U1 19 J3V1 28 J3W1 31 J2G1 BK1 22 J6V1 32 J6W1 32 J6W1 31 J2G1 BK2 23 BK2 33 BK3 46 BK5 12 BK2 24 BK2 33 BK3 46 BK5 12 BK2 24 BK2 33 BK3 46 BK5 12 BK2 44 BK4 11 10 BK2 44 BK4 11 10			29	30	31	32	33	34	35		누	<u> </u>	<u> </u>	-	<u>г</u> – т	1-			22	53	1
Group RII 8 RI2 15 R13 22 R01 10 R02 17 R03 24 R01 10 R02 17 R03 24 Feedback 5 R17 3 R18 16 R19 23 Frou 1 2 Frou 1 2 Frou 2 21 Frou 1 1 2 Frou 2 21 Frou 1 1 2 Frou 2 21 Frou 1 2 Frou 2 21 Frou 1 2 Frou 2 21 Jun 1 1 Jun 2 Jun 3 Jun 1 Jun 3 Jun 1 Jun 2 Jun 3 Jun 1 Jun 1 Jun 3 Jun 1 Jun 1 Jun 1 Jun 3 Jun 1 Jun 1 Jun 3 Jun 1 Jun 1 Jun 3 Jun 1 Jun 1	7	i gna l	-	хнвк	R04	0V-1 0V-2	0V-3 0V-4	PR0J4	XPR0J4		$\vdash$	+	_	-		_	-		-	~ ~	m
Gr RII 8 RI2 15 R13 R01 10 R02 17 R03 R07 11 R08 18 244F-1 55V-3 19 5V-5 55V-1 12 5V-3 19 5V-5 55V-1 12 5V-3 19 5V-5 55V-1 12 5V-3 19 5V-5 55V-1 12 5V-3 19 5V-5 57V-5 12 12 17 R03 14 XPR0J1 13 PR0J2 21 XPR0J3 JUII 15 J1V1 25 J1W1 35 J1G JUII 15 J1V1 25 J1W1 31 J2G JUII 15 J1V1 25 J1W1 33 J3G J3U1 18 J3V1 28 J3W1 32 J1G J3U1 18 J3V1 28 J3W1 32 J1G J3U1 19 J3V1 28 J3W1 32 J1G J3U1 19 J3V1 28 J3W1 32 J1G J3U1 21 J2V1 25 J2W1 33 J3G J3U1 18 J3V1 28 J3W1 32 J1G J3U1 22 J5V1 31 J5W1 42 J6G BK1 22 J6V1 32 J6W1 42 J6G BK2 23 BK2 33 BK3 46 BK1 46 BK1	ЧD		22	23	24	25	26	27	8			_		-					-1	-   •	
RI1     8     R12     15       R17     9     R18     16       R01     10     R02     17       R01     10     R02     17       R01     10     R02     13       FR01     11     R08     16       FR01     11     R02     14       PR0J1     13     PR0J2     20       J1U1     15     J1V1     25     J1W1       J2U1     15     J1V1     25     J2W1       J3U1     16     J3V1     26     J3W1       J3U1     16     J3V1     26     J2W1       J5U1     17     J2V1     27     J2W1       J3U1     16     J3V1     26     J3W1       J5U1     16     J3V1     26     J3W1       J5U1     13     J5V1     31     J5W1       J5U1     20     J4V1     30     J4W1       J5U1     21     J5V1     31     J5W1       J5U1     21     J5V1     31     J5W1       J5U1     21     J5V1     31     J5W1       J5U1     23     J6V1     32     J6W1       J5V1     23     J6V1     32	<u>د</u>	e	13							ke)											
RI1         B         R12           R17         9         R18           R01         10         R02           R01         10         R02           R01         10         R02           Sv-1         12         Sv-3           Sv-1         12         Sv-3           Sv-1         12         Sv-3           Sv-1         12         Sv-3           J001         13         PR0.2           J101         15         J1V1         24           J101         15         J1V1         24           J101         15         J1V1         24           J301         16         J2V1         26           J501         20         J4V1         30           J501         20         J4V1         30           J501         26         J301         28           BK1         22         J6V1         32           BK2         23         BK2         33		der	15	16	17			20	51	<u>ب</u>		Τ-		Τ_	Τ_	1	-	_	-		Т
RI1 8 R17 9 R01 10 R07 11 R07 11 S5v-1 12 55v-1 12 55v-1 12 55v-1 12 10 10 10 11 11 12 11 11 12 12 10 10 10 10 10 10 10 10 10 10 10 10 10				_		~															
RI1 8 R17 9 R01 10 R07 11 R07 11 S5v-1 12 55v-1 12 55v-1 12 55v-1 12 1201 13 J201 13 J201 14 J201 16 J20 J201 16 J22V J301 19 J2V J301 19 J2V J301 19 J2V J301 19 J2V J301 21 J2V J301 22 J2V J301 23 BKC 23 BKC 23 BKC	T	Puls		RIE	RO2	ROE	5V-2	PRQU	(PRQ	RM	24	25			N	N	30				
R11 R17 R01 R01 R01 R01 R01 R01 R01 R01 101 111 11		0	8	<u></u> თ	10		12	e	4	<u>م</u>			1720	17SL	1341	13V1	1411	J5V1	16 1	BK2	
R0 1101 101 101 101 101 101 101 101 101										MOTC	4	5	6	~	8	5				23	-1
				R I 7	R01	R07	5V-1 5V-2	PRQJ	XPR0.	5			1010	1020	J3U1	1301 1401					
			-	2	ю	4	5	9	7			_		-		_	_		Ξ	~ .	13




Fig.B (as) Mechanical unit interface (Group3, Group4)

- 328 -

B-83195EN/09

Mechanical Unit Interface

Group4 M-900iA/260L,350,150P

(Pulseconder Feedback Slanal & R1/R0)		0V (J1A, J1B) 1 0 0V (J2A, J2B) 1 7 0V (J3A, J3B) 2 4 0V (J4, J5) 31 R12 38	11 PRQU2A 18 PRQU3A 25 SDU4 32 SDU5 39	5 XPRQJIA 12 XPRQJ2A 19 XPRQJ3A 26 XSDJ4 33 XSDJ5 40 R02	6 PROJIB 13 PROJ2B 20 PROJ3B 27 REGJ4 34 REGJ5 41 RO3 7 VEED 14 VEED 13 VEED 131 VEED 12 DE VEED 14 DE VEED 15 42 EVED	Afrauid 14 Afrauld 21 Afraudd 28 Areaut 33 Areaud 12 RM1	(MOTOR Power & Brake)	1 BK (J1A) 8 J1AU1 15 J1AV1 22 J1AW1 29 J1AG1 36 J5U1	2 BK (J2A) 9 J1BU1 16 J1BV1 23 J1BW1 30 J1BG1 37 J5V1	3 BK (J3A) 10 J2AU1 17 J2AV1 24 J2AW1 31 J2AG1 38 J5W1	BK (J4) 11 J2BU1 18 J2BV1 25 J2BW1 32 J2BG1	5 BK (J2 J3AUI 19 J3AVI 26 J3AWI 33 J3AGI 40	BKC 14 J4U1 21 J4V1 28 J4W1 35 J4G1 42	In case of M-430iA/2PH. this connectors are added	RPG (Pulsecoder Feedback Signal)	3 XSDJ6 2 SDJ6 8	-	4 XREQJE 5 REQJE 6 OV (JB)	RM6	(MUIOK Power & Brake)	C1 C2 C3 C4 C5	BK (JB) B2 BKC B3 J6W1 A4 J6G1		Mechanical Unit Intertace
RP1 RP1 Bulsecoder Feedback Signal & R1/R0)	RI4 29 XHRK 30 V	24 R04 31 R05 38	. 25 0V 32	19 5V (J5, J6) 26 0V (J1, J2) 33 0V (J3, J4) 40 0V (J5, J6)	20 PRQJ3 27 PRQJ4 34 PRQJ5 41 PRQJ6 31 VEDAJ3 20 VEDAJ4 35 VEDAJ5 43 VEDAJ6	20 AFR404 50 AFR400 46			(MOTOR Power & Brake) (MOTOR Power)	1 14 J1V2 24 J1W2 34	3 J1U2 15 J1V2 25 J1W2 36	J261 4 J2U2 P J2V2 49 J2W2 37 J262	6 J3U2 18 J3V2 28 J3W3 39	8 J4U2 19 J3V2 29 J3W4 41 8 J4U2 20 J4V2 30 J4W2 72	10 J6U2 21 J5V2 31 J5W2 43	22 J6V2	13 23 33						с, т т	Mechanical Unit Intertace

#### Fig.B (at) Mechanical Unit Interface (Group5, Group6)

7

വ G

-N ო

B-83195EN/09

#### **B. TOTAL CONNECTION DIAGRAM** APPENDIX

					6	ő	90	ò	õ	6	70	2	
	ē	(J5)		J5U1	J5V1	J5W1	J5G1	R15	RO5	R I 9 (XPPABN)	0V (J3, J4)	PRQJ5	XPRQJ5
	R1/R0)	9 BK	0	51 JI	52 JI	53 JI	54 J	55	26	57 (xP	58 0V (,	n	60 XPI
	~*	4	50									ß	
	6 igna Brak	BK (J4)		J4U1	J4V1	14W1	J4G1	R14	R04	R08	0V (J1, J2)	PRQJ4	XPRQJ4
	RMP back o over &	37	38	99	40	41	42	43	44	45	46	47	48
	RMP (Pulsecoder Feedback Signal 8 (MOTOR Power & Brake)	BK (J3)	13U1	13V1	J3W1	J3G1	XHBK	R13	RO3	R07	5V (J5, J6)	PRQJ3	хреалз
	der   (MOTC	25 B	26	27	28	29	0E	31	32	еe	34 5V	35 F	36 ×
	seco	(21)			_			N			(AU		
	(Pul	Ж	JZU1	J2V1	NSU.	J2G1	24VF	RI	R02	R18	5V (J3,	PRQJ2	XPRQJ2
		13	14	15	16	17	18	19	20	21	) 22	23	1 24
		K (J1)	J1U1	1 V I V	1 W I U	J1G1	XROT	R11	R01	R17	5V (J1, J2)	PRQJ1	XPRQJ1
		- BK	, N	ر س	4	۔ س	С О	7	8	თ	1 0 5V	1	12 XF
					L			L	<u> </u>	L			
		BK (J6)		Jeui	J6V1	J6W1	J6G1	0 \	SDJ6	XSDJ6	JV (J456)	REQJ6	XREQJ6
		61 BK (J6)	62	63 JBU1	64 J6V1	65 J6W1	66 J6G1	67 DV	68 SDJ6	69 XSDJ6	70 0V (J456)	71 REQJ6	72 XREQJ6
	Ro)	(J5) 61 BK	62								70		72
	å RI∕RO)	61 BK	50 62	63	64	65	66	67	68	69	58 0V (J23) 70 0V (J456)	71	
		(J4) 49 BK (J5) 61 BK	50	J5U1 63	J5V1 64	J5W1 65	J5G1 66	55 24VF 67	56 SDJ5 68	57 XSDJ5 69	58 0V (J23) 70	59 REQJ5 71	60 XREQJ5 72
- - -	Signal & & Brake)	49 BK (J5) 61 BK		51 J5U1 63	52 J5V1 64	53 J5W1 65	54 J5G1 66	24VF 67	56 SDJ5 68	XSDJ5 69	0V (J23) 70	REQU5 71	XREQJ5 72
٢	Signal & & Brake)	(J3) 37 BK (J4) 49 BK (J5) 61 BK	38 AC200B 50	J4U1 51 J5U1 63	J4V1 52 J5V1 64	J4W1 53 J5W1 65	J4G1 54 J5G1 66	43 (BLOWER) 55 24VF 67	44 SDJ4 56 SDJ5 68	XSDJ4 57 XSDJ5 69	46 0V (J1) 58 0V (J23) 70	REQJ4 59 REQJ5 71	48 XREQJ4 60 XREQJ5 72
5	Signal & & Brake)	37 BK (J4) 49 BK (J5) 61 BK	AC200B 50	39 J4U1 51 J5U1 63	40 J4V1 52 J5V1 64	41 J4W1 53 J5W1 65	42 J4G1 54 J5G1 66	24E 84 84 84 84 84 84 84 84 84 84 84 84 84	44 SDJ4 56 SDJ5 68	45 XSDJ4 57 XSDJ5 69	0V (J1) 58 0V (J23) 70	47 REQJ4 59 REQJ5 71	XREQJ4 60 XREQJ5 72
5	Signal & & Brake)	25 BK (J3) 37 BK (J4) 49 BK (J5) 61 BK	AC200A 38 AC200B 50	J3U1 39 J4U1 51 J5U1 63	J3V1 40 J4V1 52 J5V1 64	J3W1 41 J4W1 53 J5W1 65	J3G1 42 J4G1 54 J5G1 66	(BLOWER) 43 (BLOWER) 55 24VF 67	RI3 44 SDJ4 56 SDJ5 68	R03 45 XSDJ4 57 XSDJ5 69	34 5V (J456) 46 0V (J1) 58 0V (J23) 70	35 PRQJ3 47 REQJ4 59 REQJ5 71	36 XPRQJ3 48 XREQJ4 60 XREQJ5 72
5	MP ack Signal & er & Brake)	BK (J3) 37 BK (J4) 49 BK (J5) 61 BK	26 AC200A 38 AC200B 50	27 J3U1 39 J4U1 51 J5U1 63	28 J3V1 40 J4V1 52 J5V1 64	29 J3W1 41 J4W1 53 J5W1 65	30 J3G1 42 J4G1 54 J5G1 66	31 (BLOWER) 43 (BLOWER) 55 24VF 67	32 RI3 44 SDJ4 56 SDJ5 68	33 R03 45 XSDJ4 57 XSDJ5 69	5V (J456) 46 0V (J1) 58 0V (J23) 70	PRQJ3 47 REQJ4 59 REQJ5 71	XPRQJ3 48 XREQJ4 60 XREQJ5 72
5	Signal & & Brake)	13 BK (J2) 25 BK (J3) 37 BK (J4) 49 BK (J5) 61 BK	BKC 26 AC200A 38 AC200B 50	J2U1 27 J3U1 39 J4U1 51 J5U1 63	J2V1 28 J3V1 40 J4V1 52 J5V1 64	17 J2W1 29 J3W1 41 J4W1 53 J5W1 65	J2G1 30 J3G1 42 J4G1 54 J5G1 66	R04 31 (BLOWER) 43 (BLOWER) 55 24VF 67	RI2 32 RI3 44 SDJ4 56 SDJ5 68	R02 33 R03 45 XSDJ4 57 XSDJ5 69	22 5V (J23) 34 5V (J456) 46 0V (J1) 58 0V (J23) 70	23 PRQJ2 35 PRQJ3 47 REQJ4 59 REQJ5 71	24 XPRQJ2 36 XPRQJ3 48 XREQJ4 60 XREQJ5 72
5	Signal & & Brake)	BK (J2) 25 BK (J3) 37 BK (J4) 49 BK (J5) 61 BK	14 BKC 26 AC200A 38 AC200B 50	15 J2U1 27 J3U1 39 J4U1 51 J5U1 63	16 J2V1 28 J3V1 40 J4V1 52 J5V1 64	J2W1 29 J3W1 41 J4W1 53 J5W1 65	18 J2G1 30 J3G1 42 J4G1 54 J5G1 66	19 R04 31 (BLOWER) 43 (BLOWER) 55 24VF 67	20 RI2 32 RI3 44 SDJ4 56 SDJ5 68	21 R02 33 R03 45 XSDJ4 57 XSDJ5 69	5V (J23) 34 5V (J456) 46 0V (J1) 58 0V (J23) 70	PRQJ2 35 PRQJ3 47 REQJ4 59 REQJ5 71	XPRQJ2 36 XPRQJ3 48 XREQJ4 60 XREQJ5 72

XPRQJ6

72

7 0 0V (J5, J6) PRQJ6

71

R06

69

R16 ۸ 0

67 68

#### B. TOTAL CONNECTION DIAGRAM APPENDIX

J6U1 J6V1 J6W1

64 65 66

J6G1

BK (J6)

61

BKC

62 63 B-83195EN/09

M-10 i A M-20 i A

1001C, 1 Group8

Mate Mate

ARC ARC

Mechanical Unit Interface Group7 M-430iA/2P

Mechanical Unit Interface

Fig.B (au) Mechanical Unit Interface (Group7, Group8)

— — — — Group 11 — — — -RP1 (Pulsecoder Feedback Signal & RI/RO) RI1 8 RI2 15 RIЗ 22 RI4 29 R15 36 R16 1 24VF (FAN) 2 RI7 9 R18 16 R19 23 хнвк 30 37 24VF-3 R02 17 24 31 38 R06 З R01 10 RОЗ RO4 R05 24VF-1 24VF-2 0 V - 1 0 V - 2 25 4 R07 11 R08 18 32 S2+ 39 S2-5V-3 5V-4 0V-7 0V-8 5V-1 5V-2 5V-5 5V-6 0V-3 0V-4 0V-5 5 12 19 26 33 40 0V-6 6 PRQJ1 13 PRQJ2 20 PRQJ3 27 PRQJ4 34 PRQJ5 41 PRQJ6 7 XPRQJ1 14 XPRQJ2 21 XPRQJ3 28 XPRQJ4 35 XPRQJ5 42 XPRQJ6

		(1	MUTOR Po	wer	& Brake	e)	
1		14	J1V1	24	J1W1	34	
2	J1U1	15		25		35	JIGI
З	J1U1	15	J1V1	25	J1W1	36	JIGI
4	J2U1	16	J2V1	26	J2W1	37	J2G1
5	J2U1	17	J2V1	27	J2W1	38	J2G1
6	J3U1	18	J3V1	28	J3W1	39	J3G1
7	J3U1			0.0		40	J3G1
8	J4U1	19	J3V1	29	J3W1	41	J4G1
9	J5U1	20	J4V1	30	J4W1	42	J5G1
10	J6U1	21	J5V1	31	J5W1	43	J6G1
11	BK1_2 (J1)	22	J6V1	32	J6W1	44	BK4_5_6 (J4)
12	BKC (J1, J2, J3)		ВК1_2			45	BK4_5_6 (J5)
13	BKC (J4, J5, J6)	23	(J2)	33	ВКЗ	46	BK4_5_6 (J6)

	RM1		
(MOTOR	Power	&	Brake)


Mechanical	Un	i t	Inte	er f	ace
M-2 i	А,	M - 3	ЗіА		

Fig.B (av) Mechanical Unit Interface (Group11)

						RF	⊃ 1					
			(F	ulse	ecode	r Feedba	ck	Signal 8	& RI	/R0)		
1	RI1	e		RI2	15	RI3	22	RI4	29	RI5	36	RI6
2	RI7	9	1	RI8	16	RI9 (XPPABN)	23	хнвк	30	XROT	37	24VF (OT)
З	R01	1	0	R02	17	R03	24	R04	31	R05	38	R06
4	R07	1	1	R08	18	24VF	25	ΟV	32		39	
5	5¥ (J1, J7	) 1.	2 5	' (J3, J4	1) 19	5V (J5, J6)	26	0V (J1, J7)	33	0V (J3, J4)	40	0V (J5, J6)
6	PRQJ1	1	3 F	RQJ	7 20	PRQJ3	27	PRQJ4	34	PRQJ5	41	PRQJ6
7	XPRQJ	1 1.	4 XI	PRQJ	7 21	XPRQJ3	28	XPRQJ4	35	XPRQJ5	42	XPRQJ6
	-						7 ^				_	
				(F	⊃ulse	RP coder Fe	7A edb	ack Sigr	nal)			
1		5		V (J2	) 9	5V (J2)	13		17		21	
2		6	_	v (J2		5V (J2)	14		18		22	
3	PRQJ2	_	_	, (OL	11	57 (027	15		19		23	
4	XPRQJ	_	_		12		16		20		24	
-		-   0					1.0					
	() ( 0 = 0			RM1	<b>_</b> .	,		() ( )		RM		
	(MOTO	к Р(	ower	& t	3rake	power)	-					ake powe
1 2	1 	4 J	1 V 1	24	J1W1	34 35 J1G1	-	A 1 B 1	J2U J20			A3 J2W1 B3 BKC
3	J1U1 1	5 J	1 V 1	25	J1W1	36 J1G1			020		(02)	
4	J7U1 1	6 J	7 V 1	26	J7₩1	37 J7G1						
5	J7U1 1	7 J	7 V 1	27	J7W1	38 J7G1						
6	J3U1 1	8.1	3V1	28	J3W1	39 J3G1						
7	J3U1 -					40 J3G1						
8	J4U1	9 J	3V1	29	J3₩1	41 J4G1						
9	J5U1 2	0 J	4 V 1	30	J4₩1	42 J5G1						
10	J6U1 2	1 J	5V1	31	J5W1	43 J6G1						
	BK (J1)	-	6 V 1	32	J6W1	4.4 BK (J4)						
1 1		- 3	0 1 1		BK (J3)	45 BK (J5)	1					
-	BKC	3 вк	(J7)									

Mechanical Interface Group12 R-1000 i A/120F-7B

Fig.B (aw) Mechanical Unit Interface (Group12)



I/O Device in A-cabinet

Fig.B (ax) I/O device connection diagram (A-cabinet)

CRMABA (D1/D0) [n1] D183 [14] D081	D163 08 D065 14 D164 09 D066 15	D166 10 D067 17	DI67 11 D068 18 C		D169 13 D170 20											CRMA6B	(D1/D0)	D172 08 D073 15		D17E 11 D076 18	D176 12 D0SRC3 19	D177 13 D178 30																		
1001	DOUZ	D004	DOSRC1	D005		0017	DODB	ľ			100			D0SRC1		24V	24V			100	D041	0045	00400	D044	חטפערב	D045	D046	D007	D048	DOSRC2	D049	DOBO			ľ	חטפערק		24V	24V	
6	34	38	37	38	39	40	4	5	7 U 7 U	3	44		- -	44	- 48	49	50			с с С		t u	3		5	88	- 200	40	41	- 42	43	44	45	A R	2	<del>-</del> -	48	49	50	
CRMA5B (D1/D0)			D015		-					DOSRC1		D120	D121	0100					(D1/D0)			D053	D054		D056	10	D057									D162				
Г	6	20	121			24	25	- 26	27	- 28	29	30	31	66	;		_			Г		19	- 20	21	22	23	24	r r	3 9	3	27	58	29	90	31	32	]_		_	
6010	D104	D106	D107	D108	D109	0110	DIII	0110			0114 115		0110	D117	D118	۷٥	٧٥			0110	C T T T	1110	210	0140	D141	D148	D149	D150	D151	D152	D153	D154	D155	DISE	0157		D158	٥٧	٥٧	
E	5 6 6	3 2	05	90	17	B	3 8	Ę			<u>ч</u>	2	<u>, t</u>	5	16	17	18			2	- 2	1 6	3		5	90	5	80	60	10	=	5	. <u>m</u>	1	<u>t</u> <u>u</u>	2	9	17	18	
CMDENBL				HELD	FAULT	ATPERCH					ACK1 /GNO1			DOSRC1		24V	24V			1000				D0CD00	-			D027	D028	DOSRC2	D029				1	-			24V	
6	34	<u> </u>	<u> </u>	38	BE	· _		0	40	3	44		9 ! 	47	48	49	50			0	3 6	; <u> </u>			5	88	<u></u>	40	41	42	43	44	45	4 H	2 5	- - -	48	49	50	
CRMA5A (D1/D0)	19 ACK3/SN03	20 ACK4/SN04	21 ACK5/SN05	٦.	23 DOSKCI	24 ACK 1/ SNOT	Ā	2B SNACK	27 RESERVED	28 DOSRC1	29 PNSTROBE	30 PROD START	31 DI01	32 010					CRMA5C (D1 /D0)			19 D033	20 D034	21 D035	22 D036	15	P4 D037	2E 000				-				32 DI42				
A INCTP		CSTOP1	FAULT RESET	START	HOME	FNBI	RSR1/PNS1	CONC/ COSC	PCDA / DNCA	FON LAND	PCDE / DNCE		LOUND AND A		RSR8/PNS8	٥٧	٥٧			6610	Velu	0125	0160	0120	1710	D128	0128	D130	D131	D132	D133	D134	D135	DIBE	137	1010	D138	٥٧	٥٧	
2	- 20	20	05	90	10	80	60	-	2 :	-	<u>v</u> <u>c</u>	2	- I	-2	16	17	18			ċ	- 6	3 5		4	ß	90	5	80	60	0	Ξ	-		14	t <u>u</u>	-	9	-	18	




Fig.B (ay) Process I/O board connector table (JA, JB)

# I/O Device

С

## SPECIFICATIONS OF PERIPHERAL DEVICE INTERFACE

## C.1 SIGNAL

The following table lists the I/O signals used for the peripheral device interface in the R-30iB/R-30iB Plus controller.

Signal	Input signals (Refer to C.3.1) Description
*IMSTP	Instantaneous stop signal
*HOLD	Hold signal
*SFSPD	Safety speed signal
CSTOPI	Cycle stop signal
FAULT_RESET	Alarm release signal
START	Cycle start signal
HOME	Robot service request/program number select signal (*1)
ENBL	Enabling signal
RSR1/PNS1	Robot service request/program number select signal (*1)
RSR2/PNS2	Robot service request/program number select signal (*1)
RSR3/PNS3	Robot service request/program number select signal (*1)
RSR4/PNS4	Robot service request/program number select signal (*1)
RSR5/PNS5	Robot service request/program number select signal (*1)
RSR6/PNS6	Robot service request/program number select signal (*1)
RSR7/PNS7	Robot service request/program number select signal (*1)
RSR8/PNS8	Robot service request/program number select signal (*1)
PNSTROBE	PNS strobe signal
PROD_START	Automatic operation start signal
DI01	General-purpose input signal
DI02	General-purpose input signal
DI03	General-purpose input signal
DI04	General-purpose input signal
DI05	General-purpose input signal
DI06	General-purpose input signal
DI07	General-purpose input signal
DI08	General-purpose input signal
DI09	General-purpose input signal
DI10	General-purpose input signal
DI11	General-purpose input signal
DI12	General-purpose input signal
DI13	General-purpose input signal
DI14	General-purpose input signal
DI15	General-purpose input signal
DI16	General-purpose input signal
DI17	General-purpose input signal
DI18	General-purpose input signal
DI19	General-purpose input signal
DI20	General-purpose input signal
DI21	General-purpose input signal
DI22	General-purpose input signal

#### Input signals (Refer to C.3.1)

## NOTE\*1: RSR:Robot Service Request (RSR5 to RSR8 are optional)PNS:Program Number Select Input (optional)Whether RSR is used or PNS is used can be preset.

Output signals (Refer to C.3.2)

Signal	Description
CMDENBL	Command acceptance enabled signal
SYSRDY	System ready signal
PROGRUN	Program run signal
PAUSED	Program paused signal
HELD	Held signal
FAULT	Alarm signal
ATPERCH	Reference point signal
TPENBL	Teach pendant enabled signal
BATALM	Battery alarm signal
BUSY	Operating signal
ACK1/SNO1	RSR acknowledge/Selected program number signal
ACK2/SNO2	RSR acknowledge/Selected program number signal
ACK3/SNO3	RSR acknowledge/Selected program number signal
ACK4/SNO4	RSR acknowledge/Selected program number signal
ACK5/SNO5	RSR acknowledge/Selected program number signal
ACK6/SNO6	RSR acknowledge/Selected program number signal
ACK7/SNO7	RSR acknowledge/Selected program number signal
ACK8/SNO8	RSR acknowledge/Selected program number signal
SNACK	PNS acknowledge signal
	Not used (for future expansion)
DO01	General-purpose output signal
DO02	General-purpose output signal
DO03	General-purpose output signal
DO04	General-purpose output signal
DO05	General-purpose output signal
DO06	General-purpose output signal
DO07	General-purpose output signal
DO08	General-purpose output signal
DO09	General-purpose output signal
DO10	General-purpose output signal
DO11	General-purpose output signal
DO12	General-purpose output signal
DO13	General-purpose output signal
DO14	General-purpose output signal
DO15	General-purpose output signal
DO16	General-purpose output signal
DO17	General-purpose output signal
DO18	General-purpose output signal
DO19	General-purpose output signal
DO20	General-purpose output signal

## C.2 SETTING COMMON VOLTAGE

All process I/O boards have a jumper to set the common voltage of input signals to 0 V or 24 V. The system automatically adjusts the polarity by software according to the status of this pin. Therefore, you can operate the system without being concerned about the setting of the common voltage.

To ensure safety, the common reference voltage of the following four signals, is remains at +24V.

\*IMSTP \*HOLD \*SFSPD CSTOPI

## C.3 I/O SIGNALS

### C.3.1 Input Signals

This section describes the specifications of each input signal.

(1) Instantaneous stop signal (input) \*IMSTP

Effective: At any time

Function: Use the normally closed switch because it is a reverse signal. The system turns off power to the servo unit when the \*IMSTP is open (turned off). Do not use \*IMSTP as safety relevant signal. For safety purpose, use the external emergency stop signal.

(2) Alarm release signal (input) FAULT RESET

Effective: In the alarm status

Function: The FAULT RESET signal releases the alarm status. If the servo unit has been turned off, it also turns on the unit. At the same time, the alarm display on the teach pendant (the top line) is cleared.

Description: This signal releases only the alarm status. It does not re-start execution of the program. The robot will keep running if the signal is triggered "ON" during operation.

(3) Hold signal (input) \*HOLD

Effective: At any time

Function: Use the normally-closed switch because it is a reverse signal. The \*HOLD signal has the same function as the hold button on the teach pendant. It halts the current program and stops the operation of the robot. While this signal is being input, the held signal (output) HELD is turned on and the robot cannot be operated.

(4) Start signal (input) START

Effective: When the command acceptance enabled signal (output) CMDENBL is turned on. See the description of CMDENBL in Section C.3.2 (1) for details.

Function: This input signal starts the selected program at the falling edge when the signal is turned off after being turned on. Its function differs according to the setting of parameter \$SHELL\_CFG. \$CONT\_ONLY.

- If parameter \$SHELL\_CFG.\$CONT\_ONLY is set to DISABLED, the START signal starts the program which has been selected from the teach pendant. By default, the program starts from the current cursor position.
- If parameter \$SHELL\_CFG.\$CONT\_ONLY is set to ENABLED, the START signal only resumes the execution of the temporarily held program. To execute an inactivated program from the start, input the PROD\_START signal.

- (5) Cycle stop signal (input) CSTOPI Effective: At any time Function:
  - If parameter \$SHELL\_CFG.\$USE\_ABORT is set to DISABLED, the CSTOPI signal releases the program from the wait status caused by an RSR. It does not stop the execution of the current program and allows it to continue processing (by default).
  - If parameter \$SHELL\_CFG.\$USE\_ABORT is set to ENABLED, the CSTOPI signal immediately cancels the execution of the current program. The program returns to the status in which it was before execution, and the information for the subprogram to return to the main program is lost. At the same time, this signal also releases the program from the wait status caused by RSR.
- (6) Enabling signal (input) ENBL
  Effective: At any time
  Function: If the ENBL signal is turned off, the operation of the robot or the activation of a program is inhibited, and the execution of the current program is suspended.
- (7) Safety speed signal (input) \*SFSPD Effective: At any time Function:
  - Use the normally-closed switch because it is a reverse signal. Usually this switch should be connected to safety fence. It must be set normally on.
  - Since the \*SFSPD signal is counted as a remote condition, such input signals as RSR and START to the peripheral device interface cannot take effect unless this signal is turned on.
  - If this signal is turned from on to off during robot operation, the execution of the current program is suspended. At the same time, the overriding value is switched to a preset value (parameter \$SCR. \$FENCEOVER.)
  - As long as this signal is off, the overriding value cannot be increased beyond the preset value (\$SCR.\$SFJOGOVLIM: For jog, \$SCR. \$SFRUNOVLIM: For test execution.)

(8) Robot service request signal (input) RSR1/RSR2/RSR3/RSR4

When the command acceptance enabled signal (output) CMDENBL is turned on. See the description of CMDENBL in Section C.3.2 (1) for details.

Function:

Effective:

- The user can choose between RSR and PNS (optional), although they cannot be used simultaneously.
- Four input signals, RSR1 to RSR4, are used.
- If a signal is input to an RSR input, a specified program is started. The program number can be set by a menu.
- If another program has already started processing, the newly activated program enters the wait status. As soon as the current program terminates, the waiting program starts processing.
- By using an RSR instruction, each RSR in a program can be enabled or disabled.
- A menu is provided to register the program number of a specified program when each RSR is input. (Refer to the application manual for details of the menu).

B-83195EN/09	APPENDIX	C.SPECIFICATIONS OF APPENDIX PERIPHERAL DEVICE INTERFACE			
	1 Job selection: 2 RSR1 program number: 3 RSR2 program number: 4 RSR3 program number: 5 RSR4 program number: 6 Base number: 7 Acknowledge: 8 Acknowledge pulse width:	1/8 RSR 12 23 5 64 100 Enabled	   RSR or PNS   09999		

- When an RSR is input, the program whose program name consists of the specified program number plus a base value is started. For example, if a signal is input to RSR2 when program number 23 is registered in RSR2, the program to be started is the one with the program name calculated from the expression RSR + (RSR2 program number + base number), i.e., RSR0123.
  - The base number is stored in parameter \$SHELL\_CFG.\$JOB\_BASE, and can be changed in a program with a parameter instruction. (For example, \$SHELL\_CFG. \$JOB\_BASE =100). In this way, the combination of programs which can be started by RSRs can be changed.
- Whether the system should output an acknowledge signal to an RSR can be selected from the menu. If so specified, a pulse is output from the signal corresponding to the RSR, one of signals ACK1 to ACK4, when the input of the RSR is accepted. From the same menu, the width of the pulse can also be specified.
  - It is possible to accept other RSRs while outputting an acknowledge signal.
- Input of a CSTOPIT signal can clear the program queue waiting for execution after acceptance of RSRs.

#### (9) PNS/PNSTROBE (input)

Signal name: PNS: Program number select

- PNSTROBE: Strobe input for PNS
- Effective: When the command acceptance enabled signal (output) CMDENBL is turned on. See the description of CMDENBL in Section C.3.2 (1) for details.

Function:

- The PNS/PNSTROBE signal selects whether the RSR function is used or the PNS function (optional) is used. If the PNS function is enabled, the RSR function cannot be used.
- The eight signals PNS1 to PNS8 are used to specify a program at the instant the strobe signal PNSTROBE rises.
- A menu is provided to specify the information about PNS.

#### C.SPECIFICATIONS OF PERIPHERAL DEVICE INTERFACE APPENDIX

<pre>////////////////////////////////////</pre>	1/3 PNS 100	RSR or PNS 09999 09999msec	
   { TYPE } +			

If a number other than zero is entered to PNS input, a program is selected whose program number is the entered value plus the base number. For example, if the PNS value is 23, the program to be started has the program name calculated from the expression

PNS + (entered PNS value + base number), i.e., PNS0123.

If zero is entered to PNS input, it is cleared as if no selection has been made.

- A PNS signal, which can only select a program, cannot execute the selected program. The execution of the selected program can only be started after input of automatic operation start signal PROD\_START.
- For safety, the selected program cannot be changed from the teach pendant unless PNSTROBE is turned off.
- If a program is selected by PNS, the program number is output to selected program number signal (output) SNO, and a pulse is output to program selection acknowledge signal SNACK. Using these signals, peripheral devices can confirm the correct program has been selected. For the timing of these signals, see the sections describing SNO and SNACK.
- The following operations are effective for the program selected by PNS. You can:
- Start up a program by input of automatic operation start signal PROD\_START
- Restart the program that has been suspended.
   Inputting the START signal restarts the program selected by PNS when \$SHELL CFG.\$CONT ONLY is set to ENABLED.
- Input of CSTOPI cancels execution of the pro-grams selected by PNS when \$SHELL\_CFG.\$USE\_ABORT is set to ENABLED.
- (10) Automatic operation start signal (input) PROD\_START
  - Effective: When the command acceptance enabled signal (output) CMDENBL is turned on. See the description of CMDENBL in Section C.3.2 (1) for details.
  - Function: This input signal executes the selected program at the falling edge when the signal is turned off after being turned on.

### C.3.2 Output Signals

This section describes the specifications of output signals for the peripheral device interface.

- (1) Command acceptance enabled signal (output) CMDENBL
  - Turned on: When the remote conditions are satisfied and the system is not in the alarm status.
  - Turned off: When the remote conditions are not satisfied or the system is in the alarm status. The remote conditions are satisfied when all of the following are satisfied.
    - The teach pendant is in the DISABLED status.The remote/local setting is set to REMOTE.
    - Parameter \$RMT\_MASTER is set to 0 (external interface).


- Signal \*SFSPD is set to on, or in the normal status.
- (2) System ready signal (output) SYSRDYTurned on: When power is applied to the motor of the robot.Turned off: When power is not applied to the motor of the robot.
- (3) Program run signal (output) PROGRUN
   Turned on: When the program is being executed.
   Turned off: When the program is not being executed.
- (4) Held signal (output) HELD This signal is used to check the status of the hold input. Turned on: When the hold button on the teach pendant (or input) is being pressed down (or turned on). Turned off: When the hold button on the teach pendant (or input) is not being pressed down (or is
  - Turned off: When the hold button on the teach pendant (or input) is not being pressed down (or is turned off).
- (5) Program paused signal (output) PAUSED This signal is used together with output signal PROGRUN to determine whether a program can be restarted while it is being held.
  - Turned on: When a program is held and has not been restarted yet. While this signal is on, the program can be restarted and retains information such as that to return from a subprogram to the main program.
  - Turned off: When a program is being executed or is ready to start. If signal PROGRUN is on, the program is being executed. If signal PROGRUN is off, the program has not been executed and can be started from this status.
- (6) Alarm status signal (output) FAULT
  - Turned on: When the system is in the alarm status (or an alarm which can stop a program execution is detected.) The indicator lamp does not go on in warning.Turned off: When the alarm status is released by an alarm release operation.
- (7) Reference point signal (output) ATPERCH

Turned on: When the robot is in the reference position specified in the parameter. (The reference point No.1 in reference point setup screen.)

- Turned off: When the robot is not in the reference position specified in the parameter. (The reference point No.1 in reference point setup screen.) Up to three reference positions can be specified, but this signal is output when the robot is in the first reference position. For the other two reference positions, general-purpose signals can be assigned to output as such. (They can be set from the setup screen.)
- (8) Teach pendant enabled signal (output) TPENBL
  Turned on: When the teach pendant is enabled.
  Turned off: When the teach pendant is disabled.
- (9) Battery alarm signal (output) BATALM
   Turned on: When the voltage of the battery for the CMOS memory backup drops below the reference.
   Turned off: When the voltage of the battery for the CMOS memory backup is at the normal level.
- (10) Operating signal (output) BUSY
  - Turned on: When a program is being executed or is being processed from operation panels such as the teach pendant. (This has the same function as that of the BUSY lamp on the teach pendant.)

- Turned off: When a program is not being executed nor is being processed from operation panels such as the teach pendant.
- (11) RSR acknowledge signals (output) ACK1/ACK2/ACK3/ACK4
  These signals are used together with the RSR function. They can be specified to be enabled or disabled from the RSR setup menu.
  Turned on: When one of the signals from RSR1 to RSR4 is input and accepted. A pulse whose width is specified from the menu is output to acknowledge the signal.
  Turned off: Normally. Since these signals are always output as pulses, they are normally in the off status.

The following chart shows the timing of the RSR input and ACK output.



\* Other RSR signals can be accepted even when the ACK signal is being output.

		C.SPECIFICATIONS OF
B-83195EN/09	APPENDIX	PERIPHERAL DEVICE INTERFACE

#### (12) PNS acknowledge signal (output) SNO/SNACK

These signals are used together with the PNS function.

Turned on: Whenever the PNS function is enabled. The selected program number is displayed in binary code (SN01 to SN08) on the teach pendant. If the number cannot be represented as an eight-bit number, it becomes zero. After selecting a program by PNS, a pulse is output from signal SNACK as a part of the PNS operation. The width of the pulse can be specified from the menu. See the timing chart below.

CMDENBL (O)	(The remote conditions need to be satisfied.)
PNS1-8 (I)	(A value is input.)
PNSTROBE (I)	(A strobe is input for PNS.)
Detection and processing of PNSTROBE by software.	(PNS is read within a maximum of 32 msec after PNSTROBE is turned on.)
SNO1-8 (O)	
SNACK (O)	
PROD_START (I)	(Program execution starts within 32 msec.)
PROGRUN (O)	, 

### C.4 SPECIFICATIONS OF DIGITAL INPUT/OUTPUT

### C.4.1 Overview

This section describes the external specifications of digital and analog input/output in the R-30*i*B/R-30*i*B Plus controller.

## C.4.2 Input/Output Hardware Usable in the R-30*i*B/R-30*i*B Plus Controller

The R-30*i*B/R-30*i*B Plus controller can use up to 512 digital input and output points or an equivalent number of analog input and output points. One analog input/output point uses the resources equivalent to those used by 16 digital I/O points.

The R-30*i*B/R-30*i*B Plus can use a total of up to 512 I/O points.

The R-30*i*B/R-30*i*B Plus controller can use the following I/O hardware.

- Process I/O printed board
- I/O unit model A

The process I/O board and the I/O unit model A can be used together.

### C.4.3 Software Specifications

### (1) RI/RO

These are signals sent to the connector at the wrist of the robot. They cannot be assigned (redefined) and are fixed. The standard format is eight inputs and eight outputs. The number of points that can be used for the connector at the wrist depends on the individual robot.

#### (2) DI/DO

The signal No. that is determined at hardware can be changed by software operation.

(3) Analog I/O

An analog I/O signal can access the analog I/O port (optional) on the process I/O board or the I/O port on the analog I/O module (used together with the I/O unit model A).

It reads and writes the digital value converted from the analog value of the I/O voltage. It means that the value does not always represent the real I/O voltage.

(4) Group I/O

Group I/O is a function, which can input or output multiple DI/DO signals as binary codes. Any number of continuous signals of up to 16 bits can be set for its use. It can be set in the menu DETAILS on the group I/O screen.

## **D** OPTICAL FIBER CABLE

The R-30*i*B/R-30*i*B Plus uses fiber optic cables for communication between the main board and servo amplifiers. Observe the following cautions when handling these fiber optic cables. Handle fiber optic cables with utmost care, especially when installing the unit.

(1) Protection during storage

When the electrical/optical conversion module (mounted on the printed) circuit board and the fiber optic cable are not in use, their mating surfaces must be protected with the lid and caps with which they are supplied. If left uncovered, the mating surfaces are likely to become dirty, possibly resulting in a poor cable connection.




Fig.D (a) Protection of electrical/optical conversion module and fiber optic cable (when not in use)

#### (2) Fiber optic cable

External type	
Fiber optic cord diameter:	$\phi$ 2.2 mm x2 cords
Diameter of cable with reinforced cover:	φ 7.6 mm
Tensile strength:	
Cable with reinforced cover:	75 kg
Fiber optic cord:	7 kg per cord
Between fiber optic cord and connector:	2 kg
Minimum bending radius of fiber optic cord:	25 mm
Minimum bending radius of cable with reinforced cover:	50 mm
Bending resistance (cable with reinforced cover):	10 million bending cycles at room
	temperature (when the bending radius
	is 100 mm)
Flame resistance:	Equivalent to UL VW-1
Operating temperature:	-20 to 70°C

### D. OPTICAL FIBER CABLE

APPENDIX




Fig.D (b) External dimensions of external optical cable Unit: mm

Internal type	
Fiber optic cord diameter:	$\phi$ 2.2 mm×2 cords
Tensile strength:	
Fiber optic cord:	7 kg per cord
Between fiber optic cord and connector:	2 kg
Minimum bending radius of fiber optic cord:	25 mm
Flame resistance:	Equivalent to UL VW-1
Operating temperature:	-20 to 70°C




Fig.D (c) External dimensions of internal optical cable Unit: mm

- After it is connected, the optical connector is automatically locked by the lock levers on its top. To remove the connector, release the lock levers and pull the connector. (Do not pull on the fiber optic cord itself.)
- Although optical connectors cannot be connected in other than the correct orientation, always take note of the connector's orientation before making the connection.
- Take care to keep both parts of the optical connector (cable side and PCB side) clean. If they become dirty, wipe them with tissue paper or absorbent cotton to remove dirt. The tissue paper or absorbent cotton may be moistened with ethyl alcohol. Do not use any organic solvent other than ethyl alcohol.
- Fix the reinforcing cover by using a cable clamp, as shown in Fig.D(d), to prevent the weight of the fiber optic cable from being applied directly to the connecting part of the optical connector.
- Although the reinforcing cover of the external optical cable has sufficient mechanical strength, be careful not to drop heavy objects on the cable.




Fig.D (d) Fixing the cable with a clamp

- Any superfluous portion of the cable might be wound into loops. Should this prove necessary, make sure the diameter of each loop is at least 150 mm (for an external cable). Winding the cable into smaller loops can produce sharp curves that exceed the specified bend radius limit. Such bending can result in transmission loss, ultimately leading to a communication failure.
- When using a (cable tie) as a cable clamp, follow the instructions given below. Also, take care not to apply a bending force to one particular part of the cable when fixing it with a clamp. Failing to clamp the cable correctly might cut or damage it.

External cable:

Do not clamp the uncovered portion of the cable with a cable tie. When clamping the cable by the reinforcing cover, the clamping force is not an important factor to consider. However, ensure that the clamping force is as small as possible to ensure that the reinforcing cover is not deformed by the clamping.

If possible, the clamping force should be 5kg (111bs) or less.

Internal cable:

Lightly clamp the optical cable with a cable tie so that the cable shield is not deformed. Desirable clamping force is 1 to 2 kg (make sure that no force is applied to the cable).

Туре	Specification	Max. length	
Outside of cabinet	A66L-6001-0026#L~	50m (Slave to Slave:40m)	
Inside of cabinet	A66L-6001-0023#L~	10m	

#### Optical fiber cable for FSSB

## **E** BRAKE RELEASE UNIT

### E.1 SAFETY PRECAUTIONS

### 

- Support the robot arm by mechanical means to prevent it from falling down or rising up when the brake is released. Before using the brake release unit, read the Operator's manual of the robot on which you are trying to release the brake for more information.
- Confirm that the robot is fixed tightly to the floor to prevent it from falling down and to prevent unexpected movement of the robot.
- Confirm that an electrical outlet with an earth ground is used to supply power to the brake release unit and make sure that the earth ground of the brake release unit is securely connected to the earth ground of the power supply. There is danger of getting an electric shock if the earth ground is not connected.

### **E.2** CONFIRMATIONS BEFORE OPERATION

Confirm the followings before operation.

- (1) Confirm the exterior of the brake release unit and the power cable. Do not use it if the unit and the cable are damaged.
- (2) Confirm that the power supply of the robot controller is disconnected.
- (3) There are two types of brake release units according to the input voltage as shown in Table E.2 (a). Confirm the input voltage of the unit to refer to the input voltage label put to the unit (Fig.E.4).
- (4) Confirm that the voltage of power supply is correct before connecting the power supply to the brake release unit. It is possible to damage the brake or the brake release unit when the incorrect power supply is connected to the unit.

Brake release unit	Remarks			
Brake release unit (AC 100V)	Input voltage AC100-115V, single phase			
Brake release unit (AC 200V)	Input voltage AC200-240V, single phase			

#### Table E.2 (a) Specification of Brake release unit

(5) The brake release unit connection cable is different in each robot. Confirm the cable specification corresponding to the robot referring to Table E.2 (b).

APPENDIX

### E. BRAKE RELEASE UNIT




Fig.E.2 Brake release unit connection cable

Controller	Applicable robot types	Specification of cable		
	R-2000 <i>i</i> B, R-2000 <i>i</i> C, R-1000 <i>i</i> A,M-2 <i>i</i> A,M-3 <i>i</i> A			
	M-710 <i>i</i> C,M-410 <i>i</i> B,M-420 <i>i</i> A,M-421 <i>i</i> A,M-410 <i>i</i> C,	A660-2005-T559		
	M-900 <i>i</i> A, M-900 <i>i</i> B,M-2000 <i>i</i> A			
R-30 <i>i</i> B/R-30 <i>i</i> B Plus	F-200 <i>i</i> B	A660-2005-T871		
Stand alone type	M-10 <i>i</i> A,M-20 <i>i</i> A,M-20 <i>i</i> B,CR-35 <i>i</i> A,	A660-2006-T881		
	ARC Mate 100 <i>i</i> C,ARC Mate 120 <i>i</i> C	A000-2000-1881		
	M-430 <i>i</i> A/2PH,4FH	A660-2006-T888		
	M-430 <i>i</i> A/2P	A660-2006-T887		
	Aux. Axis	A660-2005-T711		
R-30iB/R-30iB Plus	M-410 <i>i</i> B.M-410 <i>i</i> C	ACCO 2000 T002		
Integrated type	WI-410/B,WI-410/C	A660-2006-T803		

### E.3 OPERATION

### E.3.1 In Case of Operating to the Robot

Operate the brake release unit according to the following procedures.

- (1) Support the robot arm by mechanical means to prevent it from falling down or rising up when brake is released. Refer to the Operator's manual for each robot for more information.
- (2) Connect the Brake Release Unit connection cable to Brake Release Unit.
- (3) Disconnect the RM1 connector from Robot, and connect the Brake Release Unit connection cable to the Robot. Keep the connection of Robot connection cable except RM1 cable.
- (4) Connect the power cable of Brake release unit to power supply.
- (5) Press and hold the deadman switch in the middle position.
- (6) Press the brake switch '1'..'6' according to the axis whose brake you are trying to release, then the brake will be released. (Refer to Table E.3.1) Two axes or more cannot be released at the same time.




Fig.E.3.1 (a) Brake release unit


Table E.3.1 The relation between brake switch and robot axis
--

Robot Type	Brake Unit Button					
	1	2	3	4	5	6
Robot with R-30 <i>i</i> B/R-30 <i>i</i> B Plus (in case of 6 axis robot)	J1	J2	J3	J4	J5	J6
M-410 <i>i</i> B (Integrated robot)	J1 to J4	-	-	-	-	-
In case of the auxiliary Axis	J1	-	-	-	-	-

- Refer to Fig.E.3.1 (c) for M-410*i*B (Integrated robot).

- Refer to Fig.E.3.2 for the auxiliary axis.

### Except M-410*i*B (Integrated robot)



### In case of M-410*i*B (Integrated robot)

Connect the Brake release unit cable to the servo motor brake connector. Only J1 switch is available.




Fig.E.3.1 (c) How to connect brake release unit (In case of M-410*i*B)

### **E.3.2** Releasing the Brake of an Auxiliary Axis

Operate the brake release unit according to the following procedures.

- (1) Support the auxiliary Axis by mechanical means to prevent it from falling down or rising up when the brake is released.
- (2) Connect the Brake Release Unit connection cable to Brake Release Unit.
- (3) Disconnect the aux. axis brake connector (CRR65A/B), and connect the CRR65A/B connector to the Brake Release Unit connection cable. Keep the connection of all cables of aux. axis motor (power, Pulsecoder, brake).
- (4) Connect the power cable of Brake release unit to power supply.
- (5) Press and hold the deadman switch in the middle position.
- (6) Press the brake switch'1', then brake will be released.




Fig.E.3.2 How to connect brake release unit (In case of operating to the Aux. Axis)

# **E.4** HOW TO CONNECT THE PLUG TO THE POWER CABLE (IN CASE OF NO POWER PLUG)

Connect the plug to the power cable as follows. This plug is provided by customer.




Fig.E.4 How to connect the plug to the power cable

### 

- Only a specialist having the relevant expertise knowledge is permitted to connect the plug to the power cable.
- In the EU area, only plug complying with the relevant European product standard can be used.
- Do not install the plugs without protective earth ground pin.

### E.5 DIMENSION






Fig.E.5 (a) Dimension of brake release unit (Front view)





### E. BRAKE RELEASE UNIT

APPENDIX

#### B-83195EN/09


### E.6 FUSE

The fuses are mounted inside this unit. Please check the fuse when the pilot lamp doesn't light even if deadman switch is pressed. When the fuse is blown, exchange the fuse after finding the root cause of failure, and taking the appropriate countermeasures.

Manufacturer:Daito Communication Co.Specification:P420HRating:2A

### 

When the fuse is replaced, the power cable of brake release unit must be disconnected.





### E.7 SPECIFICATIONS

### Input power supply

AC100-115V, 50/60Hz±1Hz, single phase, +10%/-15%, 1A AC200-240V, 50/60Hz±1Hz, single phase, +10%/-15%, 1A

### Weight

Brake Release Unit (AC 100V):2.3 kgBrake Release Unit (AC 200V):3.5 kg


F

### HOW TO SECURE THE COMPACT FLASH MEMORY CARD TO THE MAIN BOARD

An optional bracket (fixing plate) can be used along with an adapter to semi-permanently secure the compact flash memory card (CF card) to the main board. The CF card can then be used whenever it is necessary to perform a back-up.

#### Parts


- Fixing plate (Ordering number A05B-2500-J300)
- Adapter for CF card (made by FANUC) (Ordering number A02B-0303-K150)



### - Installation of the CF card

1. Insert the CF card into the Adapter.


APPENDIX




### - Removal of the CF card


1. Loosen the screw, and unlock the latch.

2. Lock the latch, and drive the screw.



2. Pull the CF card out of the Adapter.






## **G** THE CONTROLLER FOR M-900*i*A/200P, M-2000*i*A

Additional document of the controller specifically for the M-900iA/200P, M-2000iA.

### G.1 CONFIGURATION



(Controller 2) Fig.G.1(a) M-900*i*A/200P, M-2000*i*A CONTROLLER (B-cabinet)




Fig.G.1(b) M-2000*i*A, CONTROLLER (A-cabinet)

#### **G.2** TROUBLESHOOTING USING THE ALARM CODE

#### G.2.1 Troubleshooting Using the Alarm Code

### SRVO-101 Robot overtravel (Group:i)

(Explanation) The robot has moved beyond a hardware limit switch on the axes. (Action) Take the same actions as SRVO-005.

#### NOTE

It is factory-placed in the overtravel state for packing purposes. If the Overtravel signal is not in use, it may have been disabled by short-circuiting in the mechanical unit.

### SRVO-102 Hand broken (Group:i)

(Explanation) The safety joint (if in use) might have been broken. Alternatively, the HBK signal on the robot connection cable might be a ground fault or a cable disconnection. Take the same actions as SRVO-006. (Action)

### NOTE

If the Hand broken signal is not in use, it can be disabled by software setting. Refer to Subsection 5.5.3 How to Disable/Enable HBK in Part III, "CONNECTIONS" of "Maintenance Manual" to disable the Hand broken signal.

### SRVO-103 Pneumatic pressure abnormal (Group:i)

(Explanation) An abnormal air pressure was detected. The input signal is located on the EE interface of the robot. Refer to the manual of your robot. (Action)

Take the same actions as SRVO-009.

### SRVO-106 Door open or E-stop (Robot:i)

- (Explanation) The cabinet door is open.
  - When the door switch is mounted.
- (Action) Take the same actions as SRVO-105

### SRVO-244 Chain 1 (+24V) abnormal (Robot:i)

### SRVO-245 Chain 2 (0V) abnormal (Robot:i)

(Explanation) A mismatch occurred between duplicate safety signals.

SRVO-244 is issued if such a mismatch that a contact connected on the chain 1 side (between EES1 and EES11, between EAS1 and EAS11, between EGS1 and EGS11, and so forth) is closed, and a contact on the chain 2 side (between EES2 and EES21, between EAS2 and EAS21, 7between EGS2 and EGS21, and so forth) is open occurs. SRVO-245 is issued if such a mismatch that a contact on the chain 1 side is open, and a contact on the chain 2 sides is closed occurs.

If a chain error is detected, correct the cause of the alarm then reset the alarm according to the method described later.

Take the same actions as SRVO-230, 231. (Action)

### **∕ ₩ARNING**

If this alarm is issued, do not reset the chain error alarm until the failure is identified and repaired. If robot use is continued with one of the duplicate circuits being faulty, safety may not be guaranteed when the other circuit fails.

### 

- 1 The state of this alarm is preserved by software. After correcting the cause of the alarm, reset the chain error alarm according to the chain error reset procedure described later.
- 2 Until a chain error is reset, no ordinary reset operation must be performed. If an ordinary reset operation is performed before chain error resetting, the message "SRVO-237 Chain error cannot be reset" is displayed on the teach pendant.

### SRVO-301 Hand broken/HBK dsbl (Group:i) SRVO-303 Set HBK to ENABLE (Group:i)

(Explanation) Although HBK was disabled, the HBK signal was input.(Action) Take the same actions as SRVO-300, 302.

### **G.2.2** Alarms Detected by Servo Amplifier

The following alarms are detected by servo amplifier.

If the alarms in the following table are caused, find the controller, which the alarm is caused according to the table of relationship of axis. (F2.3)

And find the cause and take an appropriate measure according to the troubleshooting in MAINTENANCE PART Chapter 3.

Table G.2.2 Alarms detected by servo ampliner
Alarm
SRVO - 018 Brake abnormal (Group:i Axis:j)
SRVO - 043 DCAL alarm (Group:i Axis:j)
SRVO - 044 DCHVAL alarm (Group:i Axis:j)
SRVO - 047 LVAL alarm (Group:i Axis:j)
SRVO - 049 OHAL1 alarm (Group:i Axis:j)
SRVO - 136 DCLVAL alarm (Group:i Axis:j)

 Table G.2.2
 Alarms detected by servo amplifier

#### G.2.3 **Relationship of Axis**

The following table is shown the relation ship of each axes (Axis (j) displayed in the teach pendant, motor number, Controller, Connector of Amplifier) for M-900iA/200P, M-2000iA

If the alarm is occurred, find the motor number, the connector of Amplifier and the controller (which the alarm is caused) according to the relationship of the axis and the alarm displayed in the teach pendant (Axis (j)), and find the cause of alarm according to the trouble shooing.

ALARM displayed in the teach pendant.					
SRVO - *** ALARM (Group:i Axis:j)					
Table G.2.3 (a) Relation of axis (In case of M-900 <i>i</i> A/200P)					

	Axis (j)	Motor number	Controller	Connector of AMP
M-900 <i>i</i> A/200P	1	J1A	CONTROLLER 2	6 axis amplifier (AMP1): CNJ1
Without Aux. Axis AMP	2	J2	CONTROLLER 2	6 axis amplifier (AMP1): CNJ2
	3	J3	CONTROLLER 1	6 axis amplifier (AMP1): CNJ2
	4	J4	CONTROLLER 2	6 axis amplifier (AMP1): CNJ4
	5	J5	CONTROLLER 2	6 axis amplifier (AMP1): CNJ5
	6	J6	CONTROLLER 1	6 axis amplifier (AMP1): CNJ3
	7	J1B	CONTROLLER 1	6 axis amplifier (AMP1): CNJ1
M-900 <i>i</i> A/200P	1	J1A	CONTROLLER 2	6 axis amplifier (AMP1): CNJ1
In case of	2	J2	CONTROLLER 2	6 axis amplifier (AMP1): CNJ2
1 Aux. Axis amplifier	3	J3	CONTROLLER 1	6 axis amplifier (AMP1): CNJ2
	4	J4	CONTROLLER 2	6 axis amplifier (AMP1): CNJ4
	5	J5	CONTROLLER 2	6 axis amplifier (AMP1): CNJ5
	6	J6	CONTROLLER 1	6 axis amplifier (AMP1): CNJ3
	7	J7 (Aux. axis)	CONTROLLER 1	6 axis amplifier (AMP1): CNJ4
	8	J1B	CONTROLLER 1	6 axis amplifier (AMP1): CNJ1

#### Table G.2.3 (b) Relation of axis (In case of M-2000iA)

	Axis (j)	Motor number	Controller	Connector of AMP
M-2000 <i>i</i> A	1	J1	CONTROLLER 1	6 axis amplifier (AMP1): CNJ1
No Aux. Axis AMP	2	J2A	CONTROLLER 1	6 axis amplifier (AMP1): CNJ2
	3	J3A	CONTROLLER 1	6 axis amplifier (AMP1): CNJ3
	4	J4	CONTROLLER 1	Aux. axis amplifier (AMP2): CNJ1
	5	J5	CONTROLLER 2	6 axis amplifier (AMP1): CNJ1
	6	J6	CONTROLLER 2	Aux. axis amplifier (AMP2): CNJ1
	7	J2B	CONTROLLER 2	6 axis amplifier (AMP1): CNJ2
	8	J3B	CONTROLLER 2	6 axis amplifier (AMP1): CNJ3

Note) J1A and J1B show the tandem axis.

## G.3 INSTALLING THE CONNECTION CABLE BETWEEN CABINETS

The connection cable between cabinets (emergency stop cable, optical cable, and earth cable) is disconnected from the controller 1 at shipment.

Install the connection cable between cabinets as shown in the following Fig. G.3.




Fig.G.3 Installing the connection cable between cabinets

### **G.4** ROBOT CONNECTION CABLE

Following is the installation method of robot connection cable for M-900*i*A/200P, M-2000*i*A at installing. Cable route shown in CONNECTION PART Section 3.2.1.

There are two types of the robot connection cable;

Non-flex type: usage is restricted to fixed laying Flex type: possible to use in the cable track


Table G.4 Specification of cable							
		Non-flex type			Flex type		
	Robot	Diameter (mm)	Weight (kg/m)	Minimum bending radius (mm)	Diameter (mm)	Weight (kg/m)	Minimum bending radius (mm)
RP1,2	Group9 (M-900 <i>i</i> A/200P)	16.0	0.45	200	-	-	-
RM1,2,3,4		26.1	1.22	200	-	-	-
RP1, 2	Group10 (M-2000 <i>i</i> A)	16.0	0.45	200	20.5	0.71	200
RM1,2,3,4		26.1	1.22	200	25.4	1.2	200
EARTH	All models	4.7	0.065	200	4.7	0.065	200

### Table G.4 Specification of cable

### 

Before operating the robot, uncoil the interconnection cables from their shipping position to prevent excessive heat, which may damage the cables. (Coiled part should be shorter than 10 meter.)

- Detail of cable connection to servo amplifier





#### - Detail of cable connection to servo amplifier




Fig.G.4(b) Robot connection cable (Group10: M-2000*i*A)

### **G.5** CONNECTING THE INPUT POWER CABLE

M-900*i*A/200P, M-2000*i*A is composed of two cabinets, and need to connect the power supply with each main breaker as shown in figure G.5.

Refer to CONNECTION PART Chapter 3.2 for the method of connecting the power supply with each main breaker.




Fig.G.5(b) In case of B-cabinet

## **G.6** CONFIRMATIONS OF ON/OFF BY THE BREAKER FOR M-900*i*A/200P, M-2000*i*A

- (1) In case of turn on, turn on the MAIN MACHINE DISCONNECT-2 (Breaker of Controller 2) first, and then turn on the MAIN MACHINE DISCONNECT-1 (Breaker of Controller 1). Or turn on both controllers at the same time.
- (2) In case of turn off, turn off the MAIN MACHINE DISCONNECT-1 (Breaker of Controller 1) first, and then turn off the MAIN MACHINE DISCONNECT-2 (Breaker of Controller 2). Or turn off both controllers at the same time.




Fig.G.6(a) In case of A-cabinet




Fig.G.6(b) In case of B-cabinet







Fig.G.7(a) System block diagram (A-cabinet/Power supply regeneration/Controller 1)



APPENDIX G. THE CONTROLLER FOR M-900iA/200P, M-2000iA

Fig.G.7(b) System block diagram (A-cabinet/Power supply regeneration/Controller 2)




Fig.G.7(c) System block diagram (B-cabinet/Resistor discharge/Controller 1)




Fig.G.7(d) System block diagram (B-cabinet/ Resistor discharge/Controller 2)

いいいて

Input AC

I/O LINK i CONNECTION PE CONNECT I ON

OPT. CABLE




Fig.G.7(e) System block diagram (B-cabinet/Power supply regeneration/Controller 1)




Fig.G.7(f) System block diagram (B-cabinet/Power supply regeneration/Controller 2)

- 375 -







Fig.G.7(g) Emergency circuit connection diagram (A-cabinet/Power supply regeneration/Controller 1)







#### Fig.G.7(h) Emergency circuit connection diagram (A-cabinet/Power supply regeneration/Controller 2)



E-STOP CIRCUIT FOR B-CABINET (CONTROLLER 1) RESISTOR DISCHARGE





Fig.G.7(i) Emergency circuit connection diagram (B-cabinet/Resistor discharge/Controller 1)



E-STOP CIRCUIT FOR B-CABINET (CONTROLLER 2) RESISTOR DISCHARGE





Fig.G.7(j) Emergency circuit connection diagram (B-cabinet/ Resistor discharge/Controller 2)







Fig.G.7(k) Emergency circuit connection diagram (B-cabinet/Power supply regeneration/Controller 1)



E-STOP CIRCUIT FOR B-CABINET (CONTROLLER 2) POWER SUPPLY REGENERATION






Fig.G.7(I) Emergency circuit connection diagram (B-cabinet/Power supply regeneration/Controller 2)



B-83195EN/09






Fig.G.7(m) Connection between controller 1 and 2 (A-cabinet)




Fig.G.7(n) Connection between controller 1 and 2 (B-cabinet)




Fig.G.7(o) Motor power connection (Group 9:M-900*i*A/200P, Controller 1)

#### APPENDIX G. THE CONTROLLER FOR M-900iA/200P, M-2000iA





Fig.G.7(p) Motor power connection (Group 9:M-900*i*A/200P, Controller 2)

B-83195EN/09



RI/RO

Fig.G.7(q) RI/RO connection diagram (Group 9:M-900iA/200P)




Fig.G.7(r) Pulsecoder signal connection diagram (Group 9:M-900*i*A/200P)

B-83195EN/09

Mechanical Interface

Group9 M-900iA/200P




Fig.G.7(s) Mechanical unit interface (Group 9:M-900iA/200P)




Fig.G.7(t) Motor power connection (Group 10:M-2000iA, Controller 1)




Fig.G.7(u) Motor power connection (Group 10:M-2000*i*A, Controller 2)






Fig.G.7(v) RI/RO connection diagram (Group 10:M-2000iA)








Fig.G.7(x) Pulsecoder signal connection diagram (Group 10:M-2000iA, Controller 2)

		24VF (0T)			0V (A1, A2) PP0A2	XPRQA2	Brake     Pover)       J5W2     34       J5W2     35       J5W2     35       J5W2     39       J2BW2     39       J3BW2     39       J3BW2     39       J6W2     31       J2BW2     39       J2BW2     39       J3BW2     39       J6W2     31       J6W2     34       J6W2     41       J6W2     45
	36	37 <i>2</i> ,	38	39	40 07		4 Brake J5w2 J5w2 J3Bw2 J3Bw2 J6w2 J6w2 J6w2 J6w2
6		хгот			0V (J3B, J6) PROA 1		
& RI/RO)	29	30	31	32	33 0		O O O O O O O O O O O O O O O O O O O
Signal &		XHBK			0V (J2B, J5) 3		(MOT
s S S	22	23	24	25	26 0		
RP2 Feedback					5V (A1, A2) PR0.13R		
der	15	16		18	19 5	5 T Z	Brake JJSW1
(Pulsecoder					5V (J3B, J6) PRO. 12R		3 3 3 3 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5
	8	ი	-	Ξ	10	4	Power J5V1 J5V1 J2BV1 J2BV1 J3BV1 J6V1 J6V1 A1V BK (AJ)
					5V (J2B, J5) PRO. 15	XPRQJ5	(MOTOR 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	-	S	m	4	ы С	-	
	RI6	24VF (0T)	ROG		DV (A3. Ad)	XPRQA4	Pover) Pover)
	36 RI6	37 24VF (CT)	38 R05	68	40 0V (A3. A4)		Pover) Pover)
/RO)				-		42	A B Brake pover) 4 J1W2 34 5 J1W2 35 J1G2 5 J1W2 35 J1G2 6 J2AW2 37 J2AG2 9 J3AW2 39 J3AG2 9 J3AW2 40 J3AG2 9 J3AW2 41 J4G2 0 J4W2 42 J4G2 1 J4W2 42 J4G2 3 A4W 45 2 A4W 45 3 46 3 46 46 46 46 46 46 46 46 46 46 46 46 46 4
& RI/RO)	36	٤٤.	38	32	33 0V (J3A, J4) 40	XPRQA3 42	Power & Brake     Power)       Power & Brake     Power)       1 UV2     24 JIW2       5 J1V2     25 J1W2       5 J1V2     25 J1G2       5 J1V2     25 J1G2       5 J12A02     38 J2A62       J1V2     28 J3AV2       31 J402     39 J3A62       J3AV2     28 J3AV2       J3AV2     28 J3AV2       J3AV2     29 J3AV2       J4V     31 J4W2       2     A44       33     33
Signal & RI	RI4 29 RI5 36	XHBK 30 XROT 37	R04 31 R05 38	0V 32	0V (J1, J2A) 33 0V (J3A, J4) 40	XPRQA3 42	Power & Brake     Power)       Power & Brake     Power)       1 UV2     24 JIW2       5 J1V2     25 J1W2       5 J1V2     25 J1G2       5 J1V2     25 J1G2       5 J12A02     38 J2A62       J1V2     28 J3AV2       31 J402     39 J3A62       J3AV2     28 J3AV2       J3AV2     28 J3AV2       J3AV2     29 J3AV2       J4V     37 J4G2       J4V2     31 J4G2       J4V2     31 J4G2       J4V2     33 J4G2       J4V2     31 J4G2       J4V3     45
Signal & RI	22 R14 29 R15 36	23 XHBK 30 XROT 37	24 R04 31 R05 38	25 0V 32	26 0V(J1, J2A) 33 0V (J3A, J4) 40	XPRQA3 42	MOTOR Fover & Brake power) (MOTOR Fover & Brake power) 2 J1U2 15 J1V2 25 J1W2 35 J1G2 3 J1U2 15 J1V2 25 J1W2 36 J1G2 3 J1U2 25 J1W2 36 J1G2 1 J2AU2 16 J3AV2 26 J3AW2 37 J2AG2 1 5 J2AU2 16 J3AV2 28 J3AW2 39 J3G22 1 7 J3AU2 19 J3AV2 29 J3AW2 31 J4G2 1 9 J4U2 21 J4V2 31 J4W2 41 J4G2 1 0 A4U 21 J4V2 31 J4W2 42 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 22 A4V 32 A4W 45 1 2 2 3 3 3 44 45 1 3 44 45 1 3 44 45 1 4 5 44 45 1 5 2 44 45 1 5 2 44 45 1 6 3 3 44 45 1 7 3 44 5 1 7 45 5 1 7 45 5 1 8 44 45 1 7 45 5 1 8 44 45 1 9 44 5 1 9 4
Signal & RI	RI3 22 RI4 29 RI5 36	(XPPABN) 23 XHBK 30 XROT 37	F03 24 R04 31 R05 38	24VF 25 0V 32	5V (A3. A4) 26 0V (J1. J2A) 33 0V (J3A. J4) 40	XPRQA3 42	MOTOR Fover & Brake power) (MOTOR Fover & Brake power) 2 J1U2 15 J1V2 25 J1W2 35 J1G2 3 J1U2 15 J1V2 25 J1W2 36 J1G2 3 J1U2 25 J1W2 36 J1G2 1 J2AU2 16 J3AV2 26 J3AW2 37 J2AG2 1 5 J2AU2 16 J3AV2 28 J3AW2 39 J3G22 1 7 J3AU2 19 J3AV2 29 J3AW2 31 J4G2 1 9 J4U2 21 J4V2 31 J4W2 41 J4G2 1 0 A4U 21 J4V2 31 J4W2 42 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 22 A4V 32 A4W 45 1 2 2 3 3 3 44 45 1 3 44 45 1 3 44 45 1 4 5 44 45 1 5 2 44 45 1 5 2 44 45 1 6 3 3 44 45 1 7 3 44 5 1 7 45 5 1 7 45 5 1 8 44 45 1 7 45 5 1 8 44 45 1 9 44 5 1 9 4
Signal & RI	22 R14 29 R15 36	23 XHBK 30 XROT 37	24 R04 31 R05 38	18 24VF 25 0V 32	5V (A3. A4) 26 0V (J1. J2A) 33 0V (J3A. J4) 40	XPRQA3 42	MOTOR Fover & Brake power) (MOTOR Fover & Brake power) 2 J1U2 15 J1V2 25 J1W2 35 J1G2 3 J1U2 15 J1V2 25 J1W2 36 J1G2 3 J1U2 25 J1W2 36 J1G2 1 J2AU2 16 J3AV2 26 J3AW2 37 J2AG2 1 5 J2AU2 16 J3AV2 28 J3AW2 39 J3G22 1 7 J3AU2 19 J3AV2 29 J3AW2 31 J4G2 1 9 J4U2 21 J4V2 31 J4W2 41 J4G2 1 0 A4U 21 J4V2 31 J4W2 42 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 22 A4V 32 A4W 45 1 2 2 3 3 3 44 45 1 3 44 45 1 3 44 45 1 4 5 44 45 1 5 2 44 45 1 5 2 44 45 1 6 3 3 44 45 1 7 3 44 5 1 7 45 5 1 7 45 5 1 8 44 45 1 7 45 5 1 8 44 45 1 9 44 5 1 9 4
Signal & RI	RI3 22 RI4 29 RI5 36	R18 16 (XPPABN) 23 XHBK 30 XROT 37	R02 17 R03 24 R04 31 R05 38	R08 18 24VF 25 0V 32	5V (J3X, J4) 19 5V (A3, A4) 26 0V (J1, J2N) 33 0V (J3X, J4) 40 PPO 124 20 PPO 124 27 PPO 144 34 PPD 34 41	XPRQA3 42	MOTOR Fover & Brake power) (MOTOR Fover & Brake power) 2 J1U2 15 J1V2 25 J1W2 35 J1G2 3 J1U2 15 J1V2 25 J1W2 36 J1G2 3 J1U2 25 J1W2 36 J1G2 1 J2AU2 16 J3AV2 26 J3AW2 37 J2AG2 1 5 J2AU2 16 J3AV2 28 J3AW2 39 J3G22 1 7 J3AU2 19 J3AV2 29 J3AW2 31 J4G2 1 9 J4U2 21 J4V2 31 J4W2 41 J4G2 1 0 A4U 21 J4V2 31 J4W2 42 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 A4U 21 J4V2 31 J4W2 41 J4G2 1 1 22 A4V 32 A4W 45 1 2 2 3 3 3 44 45 1 3 44 45 1 3 44 45 1 4 5 44 45 1 5 2 44 45 1 5 2 44 45 1 6 3 3 44 45 1 7 3 44 5 1 7 45 5 1 7 45 5 1 8 44 45 1 7 45 5 1 8 44 45 1 9 44 5 1 9 4
Signal & RI	15 RI3 22 RI4 29 RI5 36	16 (XPPABN) 23 XHBK 30 XROT 37	17 R03 24 R04 31 R05 38	11 R08 18 24VF 25 0V 32	12 5V (J3h, Jul) 19 5V (h3, Ad) 26 0V (J1, J2h) 33 0V (J3h, Jul) 40 13 PPO J2h 20 PPO J3h 27 PPO J1h 34 PPO A3 71	14 XPRQJZA 21 XPRQJ3A 28 XPRQJ4A 35 XPRQA3 42	Power <sup>8</sup> / <sub>a</sub> Brake pover)       FM2         JIVI 22 JIVI 24 JIVI 25 JIVI 25 JIV2 25
Signal & RI	RI2 15 RI3 22 RI4 29 RI5 36	R18 16 (XPPABN) 23 XHBK 30 XROT 37	10 R02 17 R03 24 R04 31 R05 38	11 R08 18 24VF 25 0V 32	5V (J3X, J4) 19 5V (A3, A4) 26 0V (J1, J2N) 33 0V (J3X, J4) 40 PPO 124 20 PPO 124 27 PPO 144 34 PPD 34 41	14 XPRQJZA 21 XPRQJ3A 28 XPRQJ4A 35 XPRQA3 42	Power & Brake pover)       (MOTOR Fower & Brake pover)         JIVI 24 JIWI 24 JIWI 25 JIGI       JIVI 25 JIWI 34         JIVI 25 JIWI 35 JIGI       JIU2 15 JIV2 25 JIW2 35 JIGI         JZAVI 25 JIWI 36 JIGI       JIU2 15 JIV2 25 JIW2 36 JIG2         JZAVI 28 J3AVI 37 J2AGI       J JU2 15 JIV2 25 JIW2 36 JIG2         J2AVI 28 J3AVI 37 J2AGI       J J2AV2 26 J2AV2 38 J2AG2         J3AV1 29 J3AVI 28 J3AGI       6 J3AU2 16 J3AV2 28 J3AV

G. THE CONTROLLER FOR M-900iA/200P, M-2000iA APPENDIX

B-83195EN/09

Mechanical Interface Group10 M-2000iA


Fig.G.7(y) Mechanical unit interface (Group 10:M-2000*i*A)

# **INSTRUCTION FOR STACKING A-CABINETS**

This appendix shows instructions for stacking A-cabinets.

The A-cabinet fixing plate kit (A05B-2601-J342) includes following parts.

• Fixing plate (#A) • Bolt (M8 (#B)) · NUT (M8 (#C)) Action 2: Sling up the 1st cabinet by crane. Action 3: Remove (4) bolts. (M10(#D)) łłn 1st cabinet Action 1: Remove (2) top plates of 2nd cabinet. Action 6: Fix the bolt(#B) from top by nut(#C). Refer to the detail. Action 7: If necessary, remove bottom 2nd cabinet plate of 1st cabinet. 1st cabinet Bolt (M8 (#B))



Action 4: Fix the fixing plate(#A) by (4) bolts(M10).

(Note: The other (3) bolts (#D) are not used).

# TEACH PENDANT DISCONNECT FUNCTION (OPTION)

This appendix shows instructions for the teach pendant disconnect function (Option).

## I.1 CONFIGURATION




Fig. I.1 Teach pendant disconnect function

## I.2 PROCEDURE OF TEACH PENDANT DISCONNECT

### I.2.1 Teach Pendant Disconnect

- (1) Set AUTO mode.
- (2) Turn the disconnect switch to "Connect/Disconnect" position. (Robot stops because Operator's panel E-stop Alarm occurs and Power LED of the teach pendant is OFF.)
- (3) Disconnect the teach pendant cable.
- (4) Connect the jumper connector.
- (5) Turn the disconnect switch to "Normal" position.
- (6) Administrator should store the teach pendant and the teach pendant cable in the storage in order to avoid incorrect operation.


#### 1.2.2 **Teach Pendant Connect**

- (1) Set AUTO mode.
- Turn the disconnect switch to "Connect/Disconnect" position. (Robot stops because Operator's panel (2)E-stop Alarm occurs.)
- (3) Disconnect the jumper connector.
- (4) Connect the teach pendant cable with the teach pendant.
- (5) Turn the disconnect switch to "Normal" position.

#### 

When the LED (POWER) on the teach pendant turned on, this teach pendant is connected to the robot controller and emergency stop button of the teach pendant is active.


When the LED (POWER) on the teach pendant turned off, This teach pendant is not connected to robot controller and emergency stop button of the teach pendant is not inactive.




# J

# **INSTRUCTION FOR TERMINAL BLOCK**

This appendix shows instructions for working with the external on/off and external emergency stop signal input/output terminal block.






# K SEALING OF THE CABLE ENTRANCE OF THE CABINET

## K.1 CABLE ENTRANCE FOR A-CABINET

The external cables are connected through the cable entrance located on the rear surface of controller. The cable entrance consists of a hood, frame and Cable Seal Block with multiple circular shaped holes for cable sealing. There are different types of Cable Seal Block; the type used is determined by the controller and robot configuration. When all customer supplied cables are connected through the cable entrance, it may be necessary to increase the cable diameter of some cables to maintain an adequate seal at the cable entrance. It is also necessary to confirm Cable Seal Block has enough holes for all system and option cables. The number of available sealing holes for customer supplied cables varies depending on robot type and options. Reference the following illustrations.



#### 

If the cable diameter is not suitable for the hole size of Cable Seal Block, controller problems may occur because of insufficient environmental sealing of controller.


Without proper cable entrance sealing, airborne contaminates, both non-conductive and conductive may enter the interior of the controller. Foreign particulate entering the controller can have an impact on controller operation and reliability.

When customer supplied cables are connected through the cable seal entrance, the diameter of these cables should be adjusted to a suitable cable diameter to ensure proper controller cabinet sealing. Reference the following illustrations.

# K.2 HOLES OF CABLE SEAL BLOCK FOR CABLE

The cutout of Cable Seal Block at the cable Entrance is shown as follows (Rear side view) .

Type A(A230-0653-X028#A) : R-2000*i*B(except 200T/220U/220US) , R-2000*i*C(except 210L/270F), R-1000*i*A(except 120*i*F/7B), M-710*i*C, M-420*i*A




Type B(A230-0653-X028#B) : M-900*i*A/260L/350, M-410*i*B(Separated), M-410*i*C(Separated), R-2000*i*B/200T/220U/220US, R-2000*i*C/ 210L/270F, M-2000*i*A


∎e → (+

+


Κ



Type C(A230-0653-X028#C) : ARC Mate series, M-430iA, F-200iB, M-10iA, M-20iA, M-20iB, CR-35iA



Type D(A230-0653-X028#D) : M-410iC(Integrated)



Type K(A230-0653-X028#K) : R-1000iA/120F-7B

Robot power(RM1,RM2)Robot pulsecoder(RP1)Teach pendant cableRobot power(RM7A)Robot pulsecoder(RP7A)

Hole		Туре А Туре В		Т	Туре С Туре D			Т	ype K	Application (Include options)		
type	Diameter	Qty	For Options	Qty	For Options	Qty	For Options	Qty	For Options	Qty	For Options	
#A	¢27mm	1	0	2	0	0	0	0	0	2	0	Robot power (RM1,RM2,RM7A)
#B	φ20mm	3	2	3	2	4	2	2	2	3	1	Robot Pulsecoder Thick/Flex(RP1) Robot power(RM1,RM7A)
#C	¢ 12.5mm	8	8	6	6	8	8	6	6	5	4	Robot Pulsecoder(RP7A) Aux axis power, I/O Line tracking, Switch box DeviceNet Thick cable
#D	φ14.5mm	1	0	1	0	1	0	0	0	1	0	Robot Pulsecoder(RP1)
#E	¢8.5mm	13	12	13	12	14	13	7	6	14	12	Aux brake/Pulsecoder Robot Pulsecoder (RP7A) Camera, Ethernet DeviceNet Thin cable Teach pendant cable

# K.3 SUITABL

### SUITABLE CABLE DIAMETER

Hole type	Nominal	Tolerance	Suitable diameter	Q'ty Type A	Q'ty Type B	Q'ty Type C	Q'ty Type D	Q'ty Type K
#B	<i>ф</i> 20mm	±1mm	¢19mm-21mm	2	2	2	2	1
#C	φ12.5mm	±1mm	¢ 11.5mm−13.5mm	8	6	8	6	4
#E	$\phi$ 8.5mm	±1mm	$\phi$ 7.5mm-9.5mm	12	12	13	6	12


The suitable cable diameter for option cables are shown on the following table.

#### NOTE

The holes for options(#B,#C,#E) are used for all options(Aux. axis, I/O, Network, Sensor). So confirm that the available holes are enough for all option cables.

## K.4 ADJUST THE CABLE DIAMETER

To maintain proper sealing of controller enclosure, it may be necessary to adjust some cable diameters to work with an available cable port diameter. If the diameter of any cable is smaller than an available sealing port in the Cable Seal Block, increase the cable diameter to an appropriate diameter by applying acetate tape, adhesive sealing tape or heat shrink tubing over the cable jacket. If a foam type sealing tape is used, adjust the diameter to the compression state of foam for a particular cable diameter. The finished diameter of all cables should maintain an interference fit with Cable Seal Block. All unused cable ports must be plugged to ensure controller is sealed against contaminants. Sealing frame and hood must also be properly installed.




# **REPLACING THE PROTECTION SHEET**

This appendix shows instructions for replacing the protection sheet of the *i*Pendant with touch panel.

#### Replacement procedure

- 1. Remove the old protection sheet.
- 2. Peel clear sheets pasted on both sides of the new protect sheet.
- 3. Paste the new protection sheet so that the cutout part is placed on the lower right portion.



## **INDEX**

#### <Number>

100BASE-TX Connector (CD38A, CD38B) /
1000BASE-T Connector (CD38C) Pin Assignments249
6-AXIS SERVO AMPLIFIER SPECIFICATIONS 121
6-AXIS SERVO AMPLIFIERS116

#### <A>

ADJUST THE CABLE DIAMETER	408
ADJUSTMENT AND CHECKS AT INSTALLATION	ON269
ALARM SCREEN	16
Alarms Detected by Servo Amplifier	362
ARC Weld Connection Cables (CRW11; TE	
Connectivity 20 pin)	234
Assemble at Installation	266

#### <B>

BACKPLANE	101
Battery for Memory Backup (3 VDC)	155
BLOCK DIAGRAM	160
BLOCK DIAGRAM OF THE POWER SUPPLY	122
BRAKE RELEASE UNIT	348

#### <C>

Cable connection diagram of the I/O Link cable by	
using JRL8 connector	6
Cable connection diagram of the I/O Link cable when	
using JD1A connector16	4
CABLE CONNECTION FOR THE PERIPHERAL	
DEVICES, END EFFECTORS, AND ARC	
WELDERS	5
CABLE ENTRANCE FOR A-CABINET40	6
Check input voltage17	8
Check Items at Installation25	7
CHECKING THE POWER SUPPLY UNIT	
(A16B-2203-0910)12	
CHECKS AND MAINTENANCE1	
COMPONENT FUNCTIONS	9
CONFIGURATION4,359,40	2
CONFIRMATIONS BEFORE OPERATION	8
CONFIRMATIONS OF ON/OFF BY THE BREAKER	
CONFIRMATIONS OF ON/OFF BY THE BREAKER FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	9
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2
FOR M-900iA/200P, M-2000iA	2
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2 0 1
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2 0 1 4
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2 0 1 4
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2 0 1 4
FOR M-900 <i>i</i> A/200P, M-2000 <i>i</i> A	2 0 1 4 1 8
FOR M-900iA/200P, M-2000iA       36         Connecting HDI       24         Connecting the Auxiliary Axis Brake (CRR65 A/B)       19         Connecting the Auxiliary Axis Over Travel (CRM68) 19       19         CONNECTING THE COMMUNICATION UNIT       24         Connecting the External Emergency Stop       18         Connecting the External Power Supply ON/OFF Switch       17         Connecting the Input Power       17         Connecting the input power cable       176,36	2 0 1 4 1 8 6
FOR M-900iA/200P, M-2000iA       36         Connecting HDI       24         Connecting the Auxiliary Axis Brake (CRR65 A/B)       19         Connecting the Auxiliary Axis Over Travel (CRM68) 19       20         CONNECTING THE COMMUNICATION UNIT       24         Connecting the External Emergency Stop       18         Connecting the External Power Supply ON/OFF Switch       17         Connecting the Input Power       17         Connecting the Input Power cable       176,36         Connecting the Non-Teaching Enabling (NTED) Signal       17	2 0 1 4 1 8 6 8
FOR M-900iA/200P, M-2000iA       36         Connecting HDI       24         Connecting the Auxiliary Axis Brake (CRR65 A/B)       19         Connecting the Auxiliary Axis Over Travel (CRM68) 19       19         CONNECTING THE COMMUNICATION UNIT       24         Connecting the External Emergency Stop       18         Connecting the External Power Supply ON/OFF Switch       17         Connecting the Input Power       17         Connecting the input power cable       176,36	2 0 1 4 1 8 6 8
FOR M-900iA/200P, M-2000iA       36         Connecting HDI       24         Connecting the Auxiliary Axis Brake (CRR65 A/B)       19         Connecting the Auxiliary Axis Over Travel (CRM68) 19       20         CONNECTING THE COMMUNICATION UNIT       24         Connecting the External Emergency Stop       18         Connecting the External Power Supply ON/OFF Switch       17         Connecting the Input Power       17         Connecting the Input Power cable       176,36         Connecting the Non-Teaching Enabling (NTED) Signal       17	2 0 1 4 1 8 6 8
FOR M-900iA/200P, M-2000iA       36         Connecting HDI       24         Connecting the Auxiliary Axis Brake (CRR65 A/B)       19         Connecting the Auxiliary Axis Over Travel (CRM68) 19       19         CONNECTING THE COMMUNICATION UNIT       24         Connecting the External Emergency Stop       18         Connecting the External Power Supply ON/OFF Switch       17         Connecting the Input Power       17         Connecting the input power cable       176,36         Connecting the Non-Teaching Enabling (NTED) Signal (CRMA96)(For B-cabinet)       18	2 0 1 4 1 8 6 8 9

Connection between RS232C interface and I/O device245
Connection between the Mechanical Unit and End
Effector
Connection between the Process I/O Board KA, KB and
Welding Machines222
Connection between the Process I/O Board MA and
Peripheral Devices216
Connection between the Process I/O Board MB and
Welding Machines220
CONNECTION OF HDI242
Connection of I/O Link and I/O Link <i>i</i> when Using JRL8
Connector164
Connection of I/O Link by Using JD1A Connector 163
Connection of the I/O Link cable by using JD1A
connector
Connection of the I/O Link cable when using JRL8
connector164
Connection to Ethernet
CONNECTION TO FANUC I/O LINK AND FANUC
I/O LINK <i>i</i> 163
CONNECTIONS BETWEEN THE CONTROLLER
AND THE MECHANICAL UNIT AND OTHER
GENERAL CONTROLLER CONNECTIONS 161

#### <D>

DIGITAL I/O SIGNAL SPECIFICATIONS	227
DIMENSION	354

#### <E>

EE INTERFACE	.225,229
ELECTRICAL CONNECTIONS	161
Electrical Noise Countermeasures	253
EMERGENCY STOP BOARD	
A-cabinet:A20B-2200-0650/B-cabinet:A20B-2	2102-0
050	101
End Effector Cable Connector (EE interface)	240
Ethernet Interface	247
EXTERNAL CABLE WIRING DIAGRAM	167
EXTERNAL VIEW OF THE CONTROLLER	4

#### <F>

FUSE	56
FUSE-BASED TROUBLESHOOTING	74

#### <H>

HOLES OF CABLE SEAL BLOCK FOR CABLE	407
HOW TO CONNECT THE PLUG TO THE POWER	ł
CABLE (IN CASE OF NO POWER PLUG)	353
How to Disable/Enable HBK	270
How to Disable/Enable Pneumatic Pressure Alarm	
(PPABN)	271
HOW TO SECURE THE COMPACT FLASH	
MEMORY CARD TO THE MAIN BOARD	357

#### </>

I/O Signal Specifications for ARC-Welding Interf	lace
(A-cabinet/Process I/O Board MB)	230
I/O SIGNALS	337
In case of A-cabinet	198
In case of B-cabinet	199,200
In Case of Operating to the Robot	349
Input Signal Rules for the High-speed Skip (HDI)	243
Input Signals	337
Input/Output Hardware Usable in the R-30iB/R-30	$0i\mathbf{B}$
Plus Controller	343
INSTALLATION	260
INSTALLATION CONDITION	267
Installation Method	260
INSTALLING THE CONNECTION CABLE	
BETWEEN CABINETS	364
INSTRUCTION FOR STACKING A-CABINETS	S401
INSTRUCTION FOR TERMINAL BLOCK	404
Interface	244
INTERFACE FOR PERIPHERAL DEVICES	203
INTERFACE FOR WELDER	220

#### <L>

Leading out the Ethernet Cable	248
Leakage breaker	177
LEDS OF 6-AXIS SERVO AMPLIFIER	119
LEDS ON UNITS SUPPORTING I/O LINK i	95

#### <M>

MAIN BOARD97	7
MANUAL OPERATION IMPOSSIBLE94	4
MASTERING	0
Meanings of LEDs on Units Supporting I/O Link i95	5

#### <0>

ON/OFF timing by the breaker	178
OPERATION	
OPTICAL FIBER CABLE	
Output Signals	
OVERVIEW	

#### <P>

Peripheral Device and Controller Connection (Source	
Type DO)	3
Peripheral Device Cable Connector	7
Peripheral Device Connection Cable235	5
Peripheral Device Interface A	7
Peripheral Device Interface A Cable (CRMA5*:	
Honda Tsushin, 50 pins)233	3
Peripheral Device Interface B Cable (CRMA6*: Honda	
Tsushin, 20 pins)233	3
Peripheral Device Interface B1 and B2 Cables	
(CRMA52; TE Connectivity 30 pin)234	4
PERIPHERAL DEVICE INTERFACE BLOCK	
DIAGRAM195	5
Peripheral Device Interface Processing270	0
PERIPHERAL DEVICE, ARC WELDING, AND EE	
INTERFACES192	2

POWER CANNOT BE TURNED ON	12
POWER SUPPLY	
PREFACE	p-1
PRINTED CIRCUIT BOARDS	97
PROCEDURE OF TEACH PENDANT DISCON	NECT
	402
PROCESS I/O BOARD JA (A16B-2204-0010)	
PROCESS I/O BOARD JB (A16B-2204-0011)	104
PROCESS I/O BOARD KA (A20B-2101-0560).	110
PROCESS I/O BOARD KB (A20B-2101-0561).	113
PROCESS I/O BOARD MA (A20B-2004-0380,	
A20B-2004-0381)	107
PROCESS I/O BOARD MB (A20B-2101-0730,	
A20B-2101-0731)	109
PROCESS I/O BOARD SIGNALS	200

#### <R>

Recommended Cables
Relationship of Axis
Releasing the Brake of an Auxiliary Axis
Replacing a Module149
REPLACING CARDS AND MODULES ON THE
MAIN BOARD131
Replacing External Fan Unit and Door Fan (B-cabinet)154
REPLACING I/O UNIT-MODEL A149
Replacing Rear Fan Unit (A-cabinet)153
REPLACING SERVO AMPLIFIERS143
REPLACING THE AC FAN MOTOR152
Replacing the Backplane Board (Unit)129
Replacing the Base Unit of I/O Unit-MODEL A149
REPLACING THE BATTERY155
REPLACING THE CONTROL SECTION FAN
MOTOR151
REPLACING THE EMERGENCY STOP BOARD 137
REPLACING THE E-STOP UNIT136
Replacing the Heat Exchanger and Door Fan Unit
(A-cabinet)152
Replacing the Power Unit and Printed-Circuit Boards on
the Backplane129
REPLACING THE PRINTED-CIRCUIT BOARDS128
REPLACING THE PROTECTION SHEET409
REPLACING THE REGENERATIVE RESISTOR
UNIT
REPLACING THE TEACH PENDANT
REPLACING THE TRANSFORMER137
REPLACING UNITS128
Resetting Overtravel
RESETTING OVERTRAVEL AND EMERGENCY
STOP AT INSTALLATION
ROBOT CONNECTION CABLE
Robot Connection Cables167
RS232C Interface
RS232C interface signals245

#### <S>

SAFETY PRECAUTIONSs-1,348
SEALING OF THE CABLE ENTRANCE OF THE
CABINET406

#### <T>

Teach Pendant Cable175
Teach Pendant Connect403
Teach Pendant Disconnect
TEACH PENDANT DISCONNECT FUNCTION
(OPTION)402
THE CONTROLLER FOR M-900iA/200P, M-2000iA359
TOTAL CONNECTION DIAGRAM
TRANSFORMER124
TRANSPORTATION
TRANSPORTATION AND INSTALLATION259
TROUBLESHOOTING12
TROUBLESHOOTING BASED ON LED
INDICATIONS80
Troubleshooting by Alarm LEDs on the Process I/O
Board87
Troubleshooting by LED on the Emergency Stop Board
Troubleshooting by LEDs on Power Supply Unit84
Troubleshooting by LEDs on the $\alpha i$ PS
Troubleshooting by LEDs on the 6-Axis Servo
Amplifier
Troubleshooting by LEDs on the Sensor I/F Unit for
CR-35 <i>i</i> A93
Troubleshooting Using the Alarm Code
TROUBLESHOOTING USING THE ERROR CODE .22
Troubleshooting Using the LEDS on the Main Board80
Twisted-pair Cable Specification

#### <W>

When I/O Unit-MODEL A is Used198
When Process I/O Board JA/JB is Used (B-cabinet)195
When Process I/O Board KA/KB is Used (A-cabinet).197
When Process I/O Board MA is Used (A-cabinet)196
When Process I/O Board MB is Used (A-cabinet)196
When Two or More Process I/O Board and I/O
Unit-MODEL A are Used200

## **REVISION RECORD**

Edition	Data	Contento
Edition	Date	Contents
		<ul> <li>Addition of R-1000<i>i</i>A/120F-7B.</li> </ul>
09	Feb.,2017	Addition of R-30 <i>i</i> B Plus.
		Correction of errors.
		<ul> <li>Addition of R-2000iC/210L/270F, M-20iB/25, M-710iC/20M, M-410iC/500, F-100iA.</li> </ul>
08	Feb.,2016	<ul> <li>Addition of figure of process I/O board JA, JB, KA, KB, MA, MB.</li> </ul>
		Correction of errors.
		<ul> <li>Addition of M-2000iA/1700L/2300, ARC Mate 100iC/8L, M-10iA/8L</li> </ul>
07	Jul.,2015	<ul> <li>Addition of specification of FROM/SRAM module.</li> </ul>
		Addition of sensor I/F unit for CR35 <i>i</i> A.
		• Addition of R-2000 <i>i</i> C/125L,/165R,/210R, M-10 <i>i</i> A/7L,/12S, M-20 <i>i</i> A/12L,/20MT,/35MT,
06	Apr., 2015	ARC Mate 100iC/7L,/12S, ARC Mate 120iC/12L, M-900iB/280L, CR35iA
	•	Correction of errors.
05	Dec., 2013	Addition of R-2000 <i>i</i> C, M-410 <i>i</i> C. Correction of errors.
04	Dec.,2012	Addition of M-2iA. Correction of errors.
03	Aug.,2012	Addition of M-900 <i>i</i> A/200P. Correction of errors.
02	May.,2012	Addition of M-2000 <i>i</i> A.
01	Mar.,2012	

#### B-83195EN/09

